



Operating Instructions

Gas engine-generator set – Power container
Series 400

SS180138/02E

Product name	Model number	Engine model	Application group
mtu 12V400 GS	GG12V0400A1	B3042Z7 E3042Z6 B3042L8 B3042L9 E3042L8 E3042L9 E3042D4	3A, continuous operation, unrestricted
mtu 12V400 GS	GG12V0400C1	B3042Z7 E3042Z6 B3042L8 B3042L9 E3042L9 E3042D4	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R400A1	B3066Z8 E3066Z5 B3066L8 B3066L9 E3066L8 E3066L9	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R400A2	E3066D4	3A, continuous operation, unrestricted
mtu 6R400 GS	GG06R400C1	B3066Z8 E3066Z5 B3066L8 B3066L9 E3066L8 E3066L9	3A, continuous operation, unrestricted

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface		4.2.4	Engine-generator set	50
1.1	Preface	5	4.2.5	Engine	51
2	Safety		4.2.6	Generator and coupling	52
2.1	Important provisions for all products	6	4.3	Monitoring and Control	53
2.2	Intended use of gas systems	7	4.3.1	MMC and MIP control system	53
2.3	Personnel and organizational requirements	9	4.4	Charge-air System and Gas System	54
2.4	Safety regulations for commissioning and operation	10	4.4.1	Charge-air system and gas system - Engine-generator set	54
2.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	12	4.4.2	Gas system - Container	55
2.6	Safety regulations for assembly, maintenance, and repair work	14	4.5	Exhaust System	57
2.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	18	4.5.1	Exhaust system - Engine-generator set	57
2.8	Fire and environmental protection, indirect materials	19	4.5.2	Exhaust system - Container	58
2.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	22	4.5.3	Exhaust gas heat exchanger	61
2.10	Standards for warning notices in the text and highlighted information	23	4.6	Lube Oil System	62
2.11	Conventions for warning notices on safety signs on the engine-generator set	24	4.6.1	Lube oil system - Engine-generator set	62
2.12	Safety notices on engine-generator set - Overview	26	4.6.2	Lube oil system - Container	63
2.13	Safety notices on container - Overview	28	4.7	Cooling System and Heating Water System	66
3	Transport		4.7.1	Cooling system - Engine-generator set	66
3.1	Container standards	31	4.7.2	Cooling system - Container	67
3.2	Container - Lifting	32	4.8	Ventilation System	71
3.3	Tie-down instructions	35	4.8.1	Ventilation system	71
3.4	Engine and generator mounting - Transport locking device	37	4.9	Electrical System	73
3.5	Transport - Preparatory and final tasks	39	4.9.1	Electrical system - Engine-generator set	73
4	Functional Description		4.9.2	Generator power control panel (GLF)	74
4.1	Chapter overview	40	5	Technical Data	
4.2	Engine-Generator Set in Container	41	5.1	Technical data	75
4.2.1	Application group	41	6	Operation	
4.2.2	Nameplate and designation	42	6.1	Container - Operation	76
4.2.3	Container	47	6.2	Lube oil system - Operating phases	77
			7	Troubleshooting	
			7.1	Fault messages	79
			8	Maintenance	
			8.1	Maintenance activities - Engine-generator set	80
			8.2	Maintenance activities - Container	81
			9	Task Description	
			9.1	Chapter overview	82
			9.2	Container	83
			9.2.1	Container - External contamination check	83

9.2.2	Container - Door seal check	84	9.6	Cooling System and Heating Water System	101
9.2.3	Container - Door hinge check	85	9.6.1	Return-flow cooler - Check	101
9.2.4	Control cabinet door - Filter mats replacement	86	9.6.2	Fan - Cleaning	102
9.2.5	Control cabinet door - Fan check	87	9.6.3	Cooling system - Leak check	103
9.2.6	Ladders and handrails - Check	88	9.6.4	Coolant pressure - Check	104
9.2.7	Safety plates - Check	89	9.6.5	Engine coolant - Sample extraction and analysis	105
9.3	Ventilation	90	9.7	Electrical System	106
9.3.1	Weather guard - External contamination check	90	9.7.1	Grounding point - Check	106
9.3.2	Fan - Check	91	9.7.2	Heating, connector sockets and lighting - Function check	107
9.3.3	Fan - Cleaning	92			
9.3.4	Louver dampers - Function check	93	10	Appendix A	
9.4	Gas System	94	10.1	Abbreviations	108
9.4.1	Gas system - Gas lines leak check	94	10.2	Conversion tables	110
9.4.2	Gas alarm system - Function check	95	10.3	Contact person/Service partner	114
9.5	Exhaust System	96	11	Appendix B	
9.5.1	Condensate drain - Check for contamination	96	11.1	Index	115
9.5.2	Neutralization system - Check	97			
9.5.3	Neutralization system - Cleaning	98			
9.5.4	Flue bracing - Check	99			
9.5.5	Insulation - Check	100			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper operation of your engine-generator set from the manufacturer Rolls-Royce Solutions. It is vitally important that all persons working on or with the engine-generator set are familiar with all the contents of this manual and follow the instructions provided carefully at all times.

In some cases, it may prove necessary to depart from the guidelines specified in this manual in response to extraneous circumstances. Any such departure must comply with locally applicable directives and standards. All relevant safety directives and safety precautions shall be duly considered and respected.

Following these Operating Instructions will ensure that the plant operates efficiently and reliably.

All procedural instructions and safety precautions shall be followed closely to ensure that the plant operates as intended and to avoid injury or harm. Read and follow the instructions in the “Safety” section at the beginning of this manual.

All the instructions and diagrams have been checked to ensure accuracy and user-friendliness, however the skills and qualification of the operating personnel remain the most significant factor nevertheless. Rolls-Royce Solutions cannot give any assurances for the actual results of any work performed according to the descriptions provided in this manual, nor shall Rolls-Royce Solutions be held liable for any resultant personal injury or material damage. Personnel charged with running and operating the plant do so entirely at their own risk.

Other documents included in the scope of supply shall also be given due consideration in addition to these Operating Instructions.

All documents required by Machinery Directive 2006/42/EC are included in the standard scope of documentation for the engine-generator set. The following documents are supplied in addition:

- Test records
- Spare parts catalog
- Wiring diagrams

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of gas systems

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements.

For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator or the engine speed is increased accordingly. The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse or wrong parametrization, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, supplied accessory parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by Rolls-Royce Solutions in accordance with the (→ Preservation and Represervation Specifications).

Operation is only permissible after proper integration/installation.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

2.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- No persons wearing pacemakers or any other active implanted medical devices (AIMD) are present.
- Adequate ventilation of the operating room must be ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust pipework is leak-tight and that the gases are vented to atmosphere.
- The product must be free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) must always be freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated e.g. +/- polarity, fuel line/reduction agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.