



Operating Instructions

Gas engine-generator sets

MTU 8V4000 GS – GG08V4000A1/A2 with engines 8V4000L32/
L32FB/L33

MTU 12V4000 GS – GG12V4000A1/A2 with engines 12V4000L32/
L32FB/L33

MTU 16V4000 GS – GG16V4000A1/A2 with engines 16V4000L32/
L32FB/L33

MTU 20V4000 GS – GG20V4000A1/A2 with engines 20V4000L32/
L32FB/L33

SS180151/02E



A Rolls-Royce
solution

Product name	Model number	Engine model	Application group
MTU 8V4000 GS	GG08V4000A1	8V4000L32 8V4000L32FB 8V4000L33	3A, continuous operation, unrestricted
MTU 8V4000 GS	GG08V4000A2	8V4000L32 8V4000L32FB 8V4000L33	3A, continuous operation, unrestricted
MTU 12V4000 GS	GG12V4000A1	12V4000L32 12V4000L32FB 12V4000L33	3A, continuous operation, unrestricted
MTU 12V4000 GS	GG12V4000A2	12V4000L32 12V4000L32FB 12V4000L33	3A, continuous operation, unrestricted
MTU 16V4000 GS	GG16V4000A1	16V4000L32 16V4000L32FB 16V4000L33	3A, continuous operation, unrestricted
MTU 16V4000 GS	GG16V4000A2	16V4000L32 16V4000L32FB 16V4000L33	3A, continuous operation, unrestricted
MTU 20V4000 GS	GG20V4000A1	20V4000L32 20V4000L32FB 20V4000L33	3A, continuous operation, unrestricted
MTU 20V4000 GS	GG20V4000A2	20V4000L32 20V4000L32FB 20V4000L33	3A, continuous operation, unrestricted

Table of Contents

1	Preface				
1.1	Preface	6			
2	Safety				
2.1	Important provisions for all products	7			
2.2	Gas systems - Intended use	9			
2.3	Personnel and organizational requirements	11			
2.4	Safety regulations for initial start-up and operation	12			
2.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	14			
2.6	Safety regulations for assembly, maintenance, and repair work	16			
2.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	20			
2.8	Fire and environmental protection, indirect materials	21			
2.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	24			
2.10	Standards for warning notices in the text and highlighted information	25			
2.11	Conventions for warning notices on safety signs on the engine-generator set	26			
2.12	Safety signs on engine-generator set - Overview	28			
2.13	Overview of protective devices on the engine-generator set	30			
3	Transport				
3.1	Transport	32			
3.2	Transport locking device for engine mounting	39			
3.3	Transport locking device of generator mounting	40			
3.4	Crankshaft transport locking device	42			
3.5	Tie-down instructions	44			
4	Functional Description				
4.1	Chapter overview	48			
4.2	Engine-Generator Set	49			
4.2.1	General description	49			
4.2.2	Engine-generator set - Application group	50			
4.2.3	Engine-generator set - Nameplate and designation	51			
4.2.4	Engine-generator set - Standard scope of supply	54			
4.2.5	Engine-generator set - Optional scope of supply	64			
4.2.6	Engine-generator set - Operating modes	65			
4.3	Engine	66			
4.3.1	Engine - Overview	66			
4.3.2	Engine side and cylinder designations	73			
4.3.3	Sensors - Overview	74			
4.3.4	Mixture formation, turbocharging and exhaust system	78			
4.3.5	Lube oil system	81			
4.3.6	Cooling system	83			
4.4	Gearbox / Transmission	88			
4.4.1	Gearbox	88			
4.5	Generator	90			
4.5.1	Generator - General information	90			
4.5.2	Coupling	91			
4.6	Monitoring and Control	92			
4.6.1	MIP and MMC control system	92			
4.7	Charge-air System and Gas System	93			
4.7.1	Gas train	93			
4.7.2	Air filter	95			
4.8	Exhaust System	97			
4.8.1	Exhaust gas heat exchanger	97			
4.8.2	Catalytic converter	99			
4.8.3	Exhaust silencer	100			
4.9	Lube Oil System	101			
4.9.1	Lube oil system - Engine-generator set	101			
4.9.2	Oil priming pump	103			
4.10	Cooling System and Heating Water System	104			
4.10.1	Cooling system - Engine-generator set	104			
4.10.2	Heat module	107			
4.11	Base Frame	112			
4.11.1	Mounting	112			
4.12	Monitoring, Control and Regulation Equipment	114			
4.12.1	Gas engine phase 4 system - Overview	114			
4.12.2	Purpose of the units	116			
4.13	Electrical System	118			
4.13.1	Starter battery	118			
4.13.2	Battery charger	119			
4.14	Gas Alarm and Fire Alarm	120			
4.14.1	Gas alarm system	120			
4.14.2	Fire detector	121			

5	Technical Data		9.2.2	Starting sequence - Monitoring	443
5.1	Technical data	123	9.2.3	Operating data check after 3000 hours (natural gas)	444
6	Operation		9.2.4	Operating data check after 3000 hours (biogas)	446
6.1	Chapter overview	124	9.2.5	Shutdown criteria - Check	448
6.2	Conduct in case of activated gas alarm	125	9.3	Engine	449
6.3	Conduct in case of activated fire alarm	126	9.3.1	Work with special qualifications	449
6.4	Conduct in case of activation of safety functions	127	9.3.2	Engine - Barring manually	450
6.5	Operating room - Check for smell of gas	128	9.3.3	Oil separator - Filter replacement	451
6.6	Emission values - Check	129	9.3.4	Crankcase breather - Pressure control check and adjustment	453
6.7	Lockout/tagout procedure	131	9.3.5	Spark plug - Replacement	454
6.8	Unlocking procedure	133	9.3.6	Spark plug - Removal	455
6.9	Control, starting and stopping sequences	135	9.3.7	Spark plug - Installation	456
6.10	Runtimes at partial load	138	9.3.8	Spark plug connector - Replacement	458
6.11	Automatic start and shutdown	139	9.3.9	Spark plug connector - Removal	459
6.12	Engine-generator set - Starting in Manual mode	140	9.3.10	Spark plug connector - Cleaning and check	460
6.13	Status signals	142	9.3.11	Spark plug connector - Installation	461
6.14	Operational monitoring	156	9.3.12	Ignition system - Ignition timing check	463
6.15	Engine-generator set - Shutdown in Manual mode	158	9.3.13	Valve protrusion - Measurement	464
6.16	Emergency shutdown	159	9.3.14	Valve gear - Lubrication	467
6.17	After shutdown	160	9.3.15	Valve clearance - Check and adjustment	468
6.18	Re-starting the engine following an automatic safety shutdown	161	9.3.16	Cylinder head cover - Removal	471
6.19	Putting the engine-generator set into operation after extended out-of-service- period	162	9.3.17	Cylinder head cover - Installation	472
7	Troubleshooting		9.3.18	Starter - Replacement	473
7.1	Chapter overview	165	9.3.19	Engine oil level - Check	476
7.2	Fault messages - Key	166	9.3.20	Engine oil - Change	477
7.3	Fault messages in genset control system log	167	9.3.21	Engine oil - Sample extraction and analysis	478
7.4	MMC controller - Fault messages	232	9.3.22	Engine oil filter - Replacement	480
7.5	Engine Control Unit - Fault messages	394	9.3.23	Coolant and antifreeze - Check	482
8	Maintenance		9.3.24	Engine coolant level - Check	483
8.1	Maintenance task reference table [QL1] for natural gas	436	9.3.25	Engine coolant - Change	484
8.2	Maintenance task reference table [QL1], biogas	439	9.3.26	Engine coolant - Draining	485
9	Task Description		9.3.27	Engine coolant - Filling	487
9.1	Chapter overview	441	9.3.28	Coolant vent line (engine coolant circuit) - Replacement	488
9.2	Engine-Generator Set	442	9.3.29	Mixture cooler - Check	489
9.2.1	Performing test run	442	9.3.30	Mixture coolant level - Check	490
			9.3.31	Mixture coolant - Change	491
			9.3.32	Mixture coolant - Draining	492
			9.3.33	Mixture coolant - Filling	493
			9.3.34	Engine cabling - Check	494
			9.3.35	Sensors - Removal	495
			9.3.36	Sensors - Installation	497
			9.3.37	Engine mounting - Checking resilient element	498
			9.3.38	Engine mounting - Checking securing screws for firm seating	499
			9.4	Gearbox / Transmission	500
			9.4.1	Gearbox and oil circulation system - Check	500
			9.4.2	Gear oil - Check	501
			9.4.3	Gear oil - Sample extraction	502
			9.4.4	Gear oil - Change	504
			9.4.5	Gearbox - Cleaning	506
			9.4.6	Oil filter - Cleaning	507
			9.4.7	Bearing and housing temperature - Check	508
			9.5	Generator	509

9.5.1	Cummins Generator	509	9.9.2	Exhaust gas heat exchanger - Cleaning	555
9.5.1.1	Bearing and winding temperature - Check	509	9.9.3	Exhaust temperature before/after exhaust gas heat exchanger - Check	556
9.5.1.2	Intake grill - Cleaning	510	9.9.4	Exhaust back pressure before/after exhaust gas heat exchanger - Check	558
9.5.1.3	Air filter - Replacement	511	9.9.5	Exhaust back pressure before/after catalytic converter - Check	560
9.5.1.4	Antifriction bearings - Lubrication	512	9.9.6	Condensate and neutralization system - Check	561
9.5.1.5	Antifriction bearings - Replacement	514	9.9.7	Exhaust flap - Check	562
9.5.1.6	Oil separator - Cleaning	515	9.9.8	Coolant flow rate - Check	563
9.5.1.7	Coupling element - Check	517			
9.5.1.8	Windings - Check	519	9.10	Cooling System and Heating Water System	564
9.5.1.9	Windings - Drying	521	9.10.1	Rubber bellows and hoses - Check	564
9.5.2	Leroy-Somer Generator	523	9.10.2	Coolant pump - Engine mount lubrication	565
9.5.2.1	Bearing and winding temperature - Check	523	9.10.3	Coolant pump - Check	566
9.5.2.2	Intake grill - Cleaning	524			
9.5.2.3	Antifriction bearings - Lubrication	526	9.11	Electrical System	568
9.5.2.4	Coupling element - Check	528	9.11.1	Working in the control cabinet	568
9.5.2.5	Windings - Check	530	9.11.2	Starter battery - Check	569
9.5.2.6	Windings - Drying	532	9.11.3	Control cabinet - Filter fan contamination check	570
9.6	Air Intake / Mixture Supply	534	9.11.4	Control cabinet - Filter mat replacement	571
9.6.1	Air filter - Replacement	534	9.11.5	Control cabinet - Filter fan and noise generation check	572
9.6.2	Air filter - Removal and installation	535	9.11.6	Control cabinet - Cooling unit noise generation check	573
9.7	Gas System	536	9.11.7	Control cabinet - Cooling unit cooling function check	574
9.7.1	Gas filter differential pressure - Check	536	9.11.8	Control cabinet - Checking cooling louvers on cooling unit	575
9.7.2	Gas filter - Replacement	538	9.11.9	Control cabinet - Cleaning cooling louvers on cooling unit	576
9.7.3	Valve leak control - Function check	540			
9.7.4	Shut-off device - Check	542	10	Appendix A	
9.7.5	Gas supply - Checking gas lines for leaks	543	10.1	Abbreviations	577
9.7.6	Deflagration arrester and flame arrester - Check	544	10.2	Conversion tables	579
9.7.7	Deflagration arrester (without test opening) - Check	545	10.3	Contact person/Service partner	583
9.7.8	Deflagration arrester (with test opening) - Check	546			
9.7.9	Flame arrester - Replacement	548	11	Appendix B	
9.7.10	Deflagration arrester and flame arrester - Removal	549	11.1	Special Tools	584
9.7.11	Deflagration arrester and flame arrester - Installation	551	11.2	Consumables	590
9.7.12	Flame arrestor filter - Cleaning	552	11.3	Index	592
9.8	Lube Oil System, Lube Oil Circuit	553			
9.8.1	Lube oil tank - Removing water and oil sludge	553			
9.9	Exhaust System	554			
9.9.1	Exhaust gas heat exchanger - Check	554			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper operation of your engine-generator set from the manufacturer MTU. It is vitally important that all persons working on or with the engine-generator set are familiar with all the contents of this manual and follow the instructions provided carefully at all times.

In some cases, it may prove necessary to depart from the guidelines specified in this manual in response to extraneous circumstances. Any such departure must comply with locally applicable directives and standards. All relevant safety directives and safety precautions shall be duly considered and respected.

Following these Operating Instructions will ensure that the plant operates efficiently and reliably.

All procedural instructions and safety precautions shall be followed closely to ensure that the plant operates as intended and to avoid injury or harm. Read and follow the instructions in the "Safety" section at the beginning of this manual.

All the instructions and diagrams have been checked to ensure accuracy and user-friendliness, however the skills and qualification of the operating personnel remain the most significant factor nevertheless. MTU cannot give any assurances for the actual results of any work performed according to the descriptions provided in this manual, nor shall MTU be held liable for any resultant personal injury or material damage. Personnel charged with running and operating the plant do so entirely at their own risk.

Other documents included in the scope of supply shall also be given due consideration in addition to these Operating Instructions.

All documents required by Machinery Directive 2006/42/EC are included in the standard scope of documentation for the engine-generator set. The following documents are supplied in addition:

- Test records
- Spare parts catalog
- Wiring diagrams

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Gas systems – Intended use

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements. For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator (Series 4000) or the engine speed is increased accordingly (Series 400). The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by MTU in accordance with the (→ Preservation and Represervation Specifications).

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version of these are adopted. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.