



Operating Instructions

Gas engine-generator sets

MTU 8V4000 GS – GG08V4000A1/A2 with engine 8V4000L64

MTU 8V4000 GS – GG08V4000A1/A2 with engine 8V4000L64FNER

MTU 12V4000 GS – GG12V4000A1/A2 with engine 12V4000L64

**MTU 12V4000 GS – GG12V4000A1/A2 with engine
12V4000L64FNER**

MTU 16V4000 GS – GG16V4000A1/A2 with engine 16V4000L64

**MTU 16V4000 GS – GG16V4000A1/A2 with engine
16V4000L64FNER**

MTU 20V4000 GS – GG20V4000A1/A2 with engine 20V4000L64

**MTU 20V4000 GS – GG20V4000A1/A2 with engine
20V4000L64FNER**

SS180152/04E



A Rolls-Royce
solution

System designation		Engine model	Application group	Option
Product name	Model number			
MTU 8V4000 GS	GG08V4000A1	8V4000L64 8V4000L64FNER	3A, continuous operation, unrestricted	
MTU 8V4000 GS	GG08V4000A2	8V4000L64 8V4000L64FNER	3A, continuous operation, unrestricted	
MTU 12V4000 GS	GG12V4000A1	12V4000L64 12V4000L64FNER	3A, continuous operation, unrestricted	
MTU 12V4000 GS	GG12V4000A2	12V4000L64 12V4000L64FNER	3A, continuous operation, unrestricted	
MTU 16V4000 GS	GG16V4000A1	16V4000L64 16V4000L64FNER	3A, continuous operation, unrestricted	Fast Start 120 s.
MTU 16V4000 GS	GG16V4000A2	16V4000L64 16V4000L64FNER	3A, continuous operation, unrestricted	Fast Start 120 s.
MTU 20V4000 GS	GG20V4000A1	20V4000L64 20V4000L64FNER	3A, continuous operation, unrestricted	Fast Start 120 s.
MTU 20V4000 GS	GG20V4000A2	20V4000L64 20V4000L64FNER	3A, continuous operation, unrestricted	Fast Start 120 s.

© 2020 Copyright MTU

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU reserves the right to change, delete or supplement the information or data provided as and when required.

Table of Contents

1 Preface			
1.1 Preface	6		
2 Safety			
2.1 Important provisions for all products	7		
2.2 Gas systems - Intended use	9		
2.3 Personnel and organizational requirements	11		
2.4 Safety regulations for initial start-up and operation	12		
2.5 Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	14		
2.6 Safety regulations for assembly, maintenance, and repair work	16		
2.7 Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	20		
2.8 Fire and environmental protection, indirect materials	21		
2.9 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	24		
2.10 Standards for warning notices in the text and highlighted information	25		
2.11 Conventions for warning notices on safety signs on the engine-generator set	26		
2.12 Safety signs on engine-generator set - Overview	28		
2.13 Overview of protective devices on the engine-generator set	30		
3 Transport			
3.1 Transport	32		
3.2 Transport locking device for engine mounting	39		
3.3 Transport locking device of generator mounting	40		
3.4 Crankshaft transport locking device	42		
3.5 Tie-down instructions	44		
4 Functional Description			
4.1 Chapter overview	48		
4.2 Engine-Generator Set	49		
4.2.1 General description	49		
		4.2.2 Engine-generator set - Application group	50
		4.2.3 Engine-generator set - Nameplate and designation	51
		4.2.4 Engine-generator set - Standard scope of supply	54
		4.2.5 Engine-generator set - Optional scope of supply	64
		4.2.6 Engine-generator set - Operating modes	65
		4.3 Engine	66
		4.3.1 Engine - Overview	66
		4.3.2 Engine side and cylinder designations	73
		4.3.3 Sensors - Overview	74
		4.3.4 Mixture formation, turbocharging and exhaust system	78
		4.3.5 Lube oil system	81
		4.3.6 Cooling system	83
		4.4 Gearbox / Transmission	88
		4.4.1 Gearbox	88
		4.5 Generator	90
		4.5.1 Generator - General information	90
		4.5.2 Coupling	91
		4.6 Monitoring and Control	92
		4.6.1 MIP and MMC control system	92
		4.7 Charge-air System and Gas System	93
		4.7.1 Gas train	93
		4.7.2 Air filter	95
		4.8 Exhaust System	97
		4.8.1 Exhaust gas heat exchanger	97
		4.8.2 Catalytic converter	99
		4.8.3 Exhaust silencer	100
		4.9 Lube Oil System	101
		4.9.1 Lube oil system - Engine-generator set	101
		4.9.2 Oil priming pump	103
		4.10 Cooling System and Heating Water System	104
		4.10.1 Cooling system - Engine-generator set	104
		4.10.2 Heat module	108
		4.11 Base Frame	113
		4.11.1 Mounting	113
		4.12 Monitoring, Control and Regulation Equipment	115
		4.12.1 Gas engine phase 4 system - Overview	115
		4.12.2 Purpose of the units	117
		4.13 Electrical System	119
		4.13.1 Starter battery	119
		4.13.2 Battery charger	120
		4.14 Gas Alarm and Fire Alarm	121
		4.14.1 Gas alarm system	121
		4.14.2 Fire detector	122

5 Technical Data

5.1 Technical data	124
--------------------	-----

6 Operation

6.1 Chapter overview	125
6.2 Conduct in case of activated gas alarm	126
6.3 Conduct in case of activated fire alarm	127
6.4 Conduct in case of activation of safety functions	128
6.5 Operating room - Check for smell of gas	129
6.6 Lockout/tagout procedure	130
6.7 Unlocking procedure	132
6.8 Control, starting and stopping sequences	134
6.9 Runtimes at partial load	137
6.10 Automatic start and shutdown	138
6.11 Engine-generator set - Starting in Manual mode	139
6.12 Status signals	141
6.13 Operational monitoring	155
6.14 Engine-generator set - Shutdown in Manual mode	157
6.15 Emergency shutdown	158
6.16 After shutdown	159
6.17 Re-starting the engine following an automatic safety shutdown	160
6.18 Putting the engine-generator set into operation after extended out-of-service-period	161

7 Troubleshooting

7.1 Chapter overview	164
7.2 Fault messages - Key	165
7.3 Fault messages in genset control system log	166
7.4 MMC controller - Fault messages	231
7.5 Engine Control Unit - Fault messages	393

8 Maintenance

8.1 Maintenance task reference table [QL1]	435
--	-----

9 Task Description

9.1 Chapter overview	438
9.2 Engine-Generator Set	439
9.2.1 Performing test run	439
9.2.2 Operating data check after 3000 hours	440
9.2.3 Shutdown criteria - Check	442
9.3 Engine	443
9.3.1 Work with special qualifications	443

9.3.2 Engine - Barring manually	444
9.3.3 Oil separator - Filter replacement	445
9.3.4 Crankcase breather - Pressure control check and adjustment	447
9.3.5 Spark plug - Replacement	448
9.3.6 Spark plug - Removal	449
9.3.7 Spark plug - Installation	450
9.3.8 Spark plug connector - Replacement	452
9.3.9 Spark plug connector - Removal	453
9.3.10 Spark plug connector - Cleaning and check	454
9.3.11 Spark plug connector - Installation	455
9.3.12 Ignition system - Ignition timing check	457
9.3.13 Valve protrusion - Measurement	458
9.3.14 Valve gear - Lubrication	461
9.3.15 Valve clearance - Check and adjustment	462
9.3.16 Cylinder head cover - Removal	465
9.3.17 Cylinder head cover - Installation	466
9.3.18 Starter - Replacement	467
9.3.19 Engine oil level - Check	470
9.3.20 Engine oil - Change	471
9.3.21 Engine oil - Sample extraction and analysis	472
9.3.22 Engine oil filter - Replacement	474
9.3.23 Engine coolant level - Check	476
9.3.24 Engine coolant - Change	477
9.3.25 Engine coolant - Draining	478
9.3.26 Engine coolant - Filling	480
9.3.27 Coolant vent line (engine coolant circuit) - Replacement	481
9.3.28 Mixture coolant level - Check	482
9.3.29 Mixture coolant - Change	483
9.3.30 Mixture coolant - Draining	484
9.3.31 Mixture coolant - Filling	485
9.3.32 Engine mounting - Check	486
9.3.33 Engine mounting - Checking securing screws for secure seating	487
9.3.34 Engine cabling - Check	488
9.3.35 NOx sensor - Replacement	489

9.4 Gearbox / Transmission 491

9.4.1 Gearbox and oil circulation system - Check	491
9.4.2 Ring gear of transmission oil pump - Replacement	492
9.4.3 Gear oil - Sample extraction	495
9.4.4 Gear oil - Change	497
9.4.5 Gearbox - Cleaning	499
9.4.6 Oil filter - Removal and installation	500
9.4.7 Oil filter - Cleaning	502
9.4.8 Bearing and housing temperature - Check	503

9.5 Generator 504

9.5.1 Cummins Generator	504
9.5.1.1 Bearing and winding temperature - Check	504
9.5.1.2 Intake grill - Cleaning	505
9.5.1.3 Air filter - Replacement	506
9.5.1.4 Antifriction bearings - Lubrication	507
9.5.1.5 Antifriction bearings - Replacement	509
9.5.1.6 Oil separator - Cleaning	510
9.5.1.7 Coupling element - Check	512

9.5.2 Leroy-Somer Generator	514	9.9.3 Coolant pump - Check	545
9.5.2.1 Bearing and winding temperature - Check	514	9.10 Electrical System	547
9.5.2.2 Intake grill - Cleaning	515	9.10.1 Working in the control cabinet	547
9.5.2.3 Antifriction bearings - Lubrication	517	9.10.2 Starter battery - Check	548
9.5.2.4 Coupling element - Check	519	9.10.3 Control cabinet - Filter fan contamination check	549
9.6 Air Intake / Mixture Supply	521	9.10.4 Control cabinet - Filter mat replacement	550
9.6.1 Prefilter - Replacement	521	9.10.5 Control cabinet - Filter fan and noise generation check	551
9.6.2 Air filter - Replacement	522	9.10.6 Control cabinet - Cooling unit noise generation check	552
9.6.3 Air filter - Removal and installation	523	9.10.7 Control cabinet - Cooling unit cooling function check	553
9.7 Gas System	524	9.10.8 Control cabinet - Checking cooling louvers on cooling unit	554
9.7.1 Gas filter differential pressure - Check	524	9.10.9 Control cabinet - Cleaning cooling louvers on cooling unit	555
9.7.2 Gas filter - Replacement	526		
9.7.3 Valve leak control - Function check	528	10 Appendix A	
9.7.4 Shut-off device - Check	530	10.1 Abbreviations	556
9.7.5 Gas supply - Checking gas lines for leaks	531	10.2 Conversion tables	558
9.8 Exhaust System	532	10.3 Tightening specifications for screws, nuts and bolts	562
9.8.1 Exhaust gas heat exchanger - Check	532	10.4 Contact person/Service partner	575
9.8.2 Exhaust temperature before/after exhaust gas heat exchanger - Check	533	11 Appendix B	
9.8.3 Exhaust back pressure before/after exhaust gas heat exchanger - Check	535	11.1 Special Tools	576
9.8.4 Exhaust back pressure before/after catalytic converter - Check	537	11.2 Consumables	582
9.8.5 Emission values - Check	538	11.3 Index	584
9.8.6 Condensate and neutralization system - Check	540		
9.8.7 Exhaust flap - Check	541		
9.8.8 Coolant flow rate - Check	542		
9.9 Cooling System and Heating Water System	543		
9.9.1 Rubber bellows and hoses - Check	543		
9.9.2 Coolant pump - Engine mount lubrication	544		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper operation of your engine-generator set from the manufacturer MTU. It is vitally important that all persons working on or with the engine-generator set are familiar with all the contents of this manual and follow the instructions provided carefully at all times.

In some cases, it may prove necessary to depart from the guidelines specified in this manual in response to extraneous circumstances. Any such departure must comply with locally applicable directives and standards. All relevant safety directives and safety precautions shall be duly considered and respected.

Following these Operating Instructions will ensure that the plant operates efficiently and reliably.

All procedural instructions and safety precautions shall be followed closely to ensure that the plant operates as intended and to avoid injury or harm. Read and follow the instructions in the "Safety" section at the beginning of this manual.

All the instructions and diagrams have been checked to ensure accuracy and user-friendliness, however the skills and qualification of the operating personnel remain the most significant factor nevertheless. MTU cannot give any assurances for the actual results of any work performed according to the descriptions provided in this manual, nor shall MTU be held liable for any resultant personal injury or material damage. Personnel charged with running and operating the plant do so entirely at their own risk.

Other documents included in the scope of supply shall also be given due consideration in addition to these Operating Instructions.

All documents required by Machinery Directive 2006/42/EC are included in the standard scope of documentation for the engine-generator set. The following documents are supplied in addition:

- Test records
- Spare parts catalog
- Wiring diagrams

Definition of MTU

MTU refers to Rolls-Royce Power Systems AG and MTU Friedrichshafen GmbH or an affiliated company pursuant to Section § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture).

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations and emissions label

Responsibility for compliance with emissions regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emissions characteristics of the product are prohibited by emissions regulations. Emissions-related components must only be serviced, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these specifications will invalidate the design type approval or certification issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emissions regulations.

The product must be operated over its entire life cycle according to the conditions defined as "Intended use" (→ Page 9).

Emissions certification applicable to engines with EPA Nonroad Tier 4 emissions certification in accordance with 40 CFR 1039 and with EPA Locomotive emissions certification in accordance with 40 CFR 1033

Extract from the standard:

Failing to follow these instructions when installing a certified engine in a piece of nonroad equipment violates federal law (40 CFR 1068.105(b)), subject to fines or other penalties as described in the Clean Air Act.

Extract from the standard:

If you install the engine in a way that makes the engine's emission control information label hard to read during normal engine maintenance, you must place a duplicate label on the equipment, as described in 40 CFR 1068.105.

When fitting the second label, the requirements of 40 CFR 1068.105(c) must be followed and observed. This paragraph describes the process for requesting and fitting the label, the documentation obligations and storage obligations for the required documents.

Replacing components with emissions labels

On all engines from MTU fitted with emissions labels, these labels must remain on the engine throughout its operational life.

Exception: Engines used exclusively in land-based, military applications other than by US government agencies.

Please note the following when replacing components with emissions labels:

- The relevant emissions labels must be affixed to the spare part.
- Emissions labels shall not be transferred from the replaced part to the spare part.
- The emissions labels must be removed from the replaced part and destroyed.

2.2 Gas systems – Intended use

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements. For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator (Series 4000) or the engine speed is increased accordingly (Series 400). The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by MTU in accordance with the (→ Preservation and Represervation Specifications).

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version of these are adopted. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the “Installation conditions” document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.