



Operating Instructions

Gas engine-generator sets
GG08VA500A1 and GG08VA500A2

GG12VA500A1 and GG12VA500A2

SS180187/01E

Name	SLU name Model	Engine model	Application group
mtu 8V500 GS	GG08VA500A1	E408-ct80	3A, continuous operation, unrestricted
mtu 8V500 GS	GG08VA500A1	E408-ct70	3A, continuous operation, unrestricted
mtu 8V500 GS	GG08VA500A1	E408-bt70	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A1	E412-ct80	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A1	E412-ct70	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A1	E412-bt70	3A, continuous operation, unrestricted
mtu 8V500 GS	GG08VA500A2	E408-ct80	3A, continuous operation, unrestricted
mtu 8V500 GS	GG08VA500A2	E408-ct70	3A, continuous operation, unrestricted
mtu 8V500 GS	GG08VA500A2	E408-bt70	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A2	E412-ct80	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A2	E412-ct70	3A, continuous operation, unrestricted
mtu 12V500 GS	GG12VA500A2	E412-bt70	3A, continuous operation, unrestricted

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface		4.2	Application group	40
1.1	Preface	6	4.3	Nameplate and designation	41
2	Safety		4.4	Designation of sides and cylinders	46
2.1	Important provisions for all products	7	4.5	Gas Engine- Generator Set without Heat Recovery	48
2.2	Intended use of gas systems	8	4.5.1	Gas engine-generator set without heat recovery	48
2.3	Personnel and organizational requirements	10	4.5.2	Engine coolant circuit without heat recovery	51
2.4	Safety regulations for commissioning and operation	11	4.5.3	Mixture coolant circuit without heat recovery	52
2.5	Safety regulations for commissioning and operation, specific information for gaseous fuel supply or and dual fuel applications	13	4.6	Gas Engine-Generator Set with Heat Recovery	53
2.6	Safety regulations for assembly, maintenance, and repair work	15	4.6.1	Gas engine-generator set with heat recovery from the thermal energy of the engine	53
2.7	Safety regulations for assembly, maintenance and servicing work, specific information for gaseous fuel and dual fuel supply or applications	19	4.6.2	Gas engine-generator set with heat recovery from the thermal energy of the engine and the exhaust gas	56
2.8	Fire and environmental protection, indirect materials	20	4.6.3	Acoustic enclosure	59
2.9	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials, specific information for gaseous fuel supply in gaseous-fuel or dual-fuel applications	23	4.6.4	Engine coolant circuit with heat recovery	60
2.10	Standards for warning messages in the text and highlighted information	24	4.6.5	Mixture coolant circuit with heat recovery	62
2.11	Conventions for warning notices on safety signs on the engine-generator set	25	4.6.6	Heating water circuit	63
2.12	Safety functions on engine-generator set - Overview	27	4.6.7	Plate-core heat exchanger	65
2.13	Safety signs on the engine-generator set - Overview	28	4.6.8	Exhaust gas heat exchanger	66
2.14	Protective devices on engine-generator set - Overview	30	4.6.9	Exhaust gas aftertreatment (optional)	67
3	Transport		4.7	Engine	68
3.1	Transport	31	4.7.1	Engine overview 8/12V	68
3.2	Attachment points	32	4.8	Generator	70
3.3	Lifting specifications	33	4.8.1	Generator and coupling	70
3.4	Attachment points - Installation and removal	36	4.9	Monitoring and Control	71
3.5	Tie-down instructions	37	4.9.1	ECC control cabinet	71
3.6	Transport packaging	38	4.9.2	MMC control cabinet	73
4	Functional Description		4.9.3	Operating modes	75
4.1	Chapter overview	39	4.9.4	Isolated operation	78
			4.10	Charge-air System and Gas System	80
			4.10.1	Gas train	80
			4.10.2	Air filter	84
			4.11	Lube Oil System	86
			4.11.1	Automatic oil replenishment	86
			4.11.2	Extended lube oil volume (optional)	87
			4.12	Mounting / Support	88
			4.12.1	Base frame	88
			4.12.2	Frame for integrated heat recovery module	89
			4.13	Electrical System	90
			4.13.1	Starter battery	90
			4.13.2	Battery charger	91
			4.14	Gas Alarm and Fire Alarm	92
			4.14.1	Gas alarm system	92
			4.14.2	Fire detector	94

5	Technical Data		9.3.7	Valve protrusion - Measurement	293
5.1	Technical data	95	9.3.8	Valve clearance - Check and adjustment	294
6	Operation		9.3.9	Cylinder head cover - Removal	296
6.1	Chapter overview	96	9.3.10	Cylinder head cover - Installation	297
6.2	Conduct in case of activated gas alarm	97	9.3.11	Compression pressure - Check	298
6.3	Conduct in case of activated fire alarm	98	9.3.12	Spark plug - Replacement	300
6.4	Conduct in case of activation of safety functions	99	9.3.13	Spark plug - Removal	301
6.5	Operating room - Check for smell of gas	100	9.3.14	Spark plug - Check	303
6.6	Lockout/tagout procedures	101	9.3.15	Spark plug - Installation	304
6.7	Unlocking procedure	103	9.3.16	Ignition system - Cabling check	306
6.8	Control, starting and stopping sequences	105	9.3.17	Ignition voltage - Check	307
6.9	Runtimes at partial load	108	9.3.18	Ignition timing - Check	309
6.10	Automatic start and shutdown	109	9.3.19	Rocker arms, bearings and pushrods - Replacement	311
6.11	Starting the engine-generator set in Manual mode	110	9.3.20	Rocker arms, bearings and pushrods - Removal	312
6.12	Status messages	112	9.3.21	Rocker arms, bearings and pushrods - Installation	314
6.13	Operational checks	124	9.3.22	Rocker arms and bearings - Check	316
6.14	Engine-generator set - Shutdown in Manual mode	126	9.3.23	Pushrod - Check	317
6.15	Emergency shutdown	127	9.3.24	Pushrod - Cleaning	318
6.16	After shutdown	128	9.3.25	Exhaust turbocharger - Bearing clearance check	319
6.17	Re-starting engine following an automatic safety shutdown	129	9.3.26	Exhaust turbocharger - Cleaning	320
7	Troubleshooting		9.3.27	Starter - Replacement	321
7.1	Chapter overview	130	9.3.28	Engine oil level - Check	324
7.2	Fault messages	131	9.3.29	Engine oil level in storage tank - Check	325
8	Maintenance		9.3.30	Lube oil system - Overview	326
8.1	Maintenance task reference table [OL1]	276	9.3.31	Engine oil - Change	327
8.2	Specified checks	278	9.3.32	Changing engine oil (with electric pump)	328
9	Task Description		9.3.33	Changing engine oil (without electric pump)	330
9.1	Chapter overview	280	9.3.34	Engine oil - Sample extraction and analysis	332
9.2	Engine-Generator Set	281	9.3.35	Engine oil filter - Replacement	334
9.2.1	Performing test run	281	9.3.36	Oil level regulator vent hose - Obstruction check	336
9.2.2	Operating data check after 2000 hours	282	9.3.37	Mixture cooler - Check	337
9.3	Engine	284	9.3.38	Vent hose (engine coolant circuit) - Replacement	339
9.3.1	Engine - Barring manually	284	9.3.39	Engine coolant - Change	340
9.3.2	Combustion chambers - Endoscopic inspection	286	9.3.40	Engine coolant - Draining	341
9.3.3	Cylinder liner - Instructions and comments on endoscopic and visual examination	287	9.3.41	Engine coolant - Filling	343
9.3.4	Crankcase breather raw and clean gas hose - Check	289	9.3.42	Mixture coolant - Change	345
9.3.5	Crankcase breather raw and clean gas hose - Replacement	290	9.3.43	Mixture coolant - Draining	346
9.3.6	Crankcase breather - Filter replacement	291	9.3.44	Mixture coolant - Filling	347
			9.3.45	Engine mounting - Checking resilient element	348
			9.4	Generator	349
			9.4.1	Generator - Greasing antifriction bearing	349
			9.5	Monitoring and Control	351
			9.5.1	Main switch function - Check	351
			9.5.2	Protective function (emergency stop button) - Check	353
			9.6	Air Intake / Mixture Supply	354
			9.6.1	Throttle - Check	354
			9.6.2	Air filter - Check	355
			9.6.3	Air filter - Replacement	356

9.7 Gas System	358	9.10.1 Starter and backup batteries - Check	396
9.7.1 Gas-carrying lines -Leak check	358	9.10.2 Control cabinet - Filter mat replacement	398
9.7.2 Gas mixer - Check	360	9.10.3 Control cabinet - Cooling unit cooling function check	399
9.7.3 Gas filter - Replacement	361	9.10.4 Control cabinet - Cleaning cooling fins on cooling unit	400
9.7.4 Valve leak control - Function check	363	9.10.5 Control cabinet - PLC/PPC buffer battery check	401
9.7.5 Operation of safety pressure monitor min. (SPM min) - Check	364	9.10.6 Control cabinet- PLC buffer battery replacement	402
9.7.6 Operation of safety pressure monitor max. (SPM max) - Check	365	9.10.7 Control cabinet - PPC buffer battery replacement	403
9.7.7 Shut-off device - Check	367	9.10.8 Fire and smoke detectors - Check	404
9.8 Exhaust System	368	9.10.9 Fire and smoke detectors - Replacement	405
9.8.1 Condensate and neutralization system - Check	368		
9.8.2 NOx sensor - Replacement	370		
9.8.3 Exhaust system - Check	372		
9.8.4 Exhaust gas components after engine - Check	374		
9.8.5 Emission values - Check	376		
9.8.6 Exhaust gas heat exchanger - Check	378		
9.9 Cooling System and Heating Water System	380		
9.9.1 Antifreeze concentration - Check	380		
9.9.2 Coolant pressure - Check	381		
9.9.3 Coolant pump - Check	382		
9.9.4 Coolant pump rotary seal - Replacement	383		
9.9.5 Operation of safety valve - Check	387		
9.9.6 Safety temperature limiter - Check	388		
9.9.7 3-way mixer operation - Check	390		
9.9.8 Diaphragm expansion tank - Check	391		
9.9.9 Rubber bellows, hoses and coolant pump - Check	393		
9.9.10 Plate-core heat exchanger - Check	394		
9.10 Electrical System	396		
		10 Disassembly and Disposal	
		10.1 Disassembly	406
		10.2 Disposal	407
		10.3 Transport during or after disassembly	408
		11 Appendix A	
		11.1 Abbreviations	409
		11.2 Conversion tables	411
		11.3 Contact person/Service partner	415
		12 Appendix B	
		12.1 Index	416

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper operation of your engine-generator set from the manufacturer Rolls-Royce Solutions. It is vitally important that all persons working on or with the engine-generator set are familiar with all the contents of this manual and follow the instructions provided carefully at all times.

In some cases, it may prove necessary to depart from the guidelines specified in this manual in response to extraneous circumstances. Any such departure must comply with locally applicable directives and standards. All relevant safety directives and safety precautions shall be duly considered and respected.

Following these Operating Instructions will ensure that the plant operates efficiently and reliably.

All procedural instructions and safety precautions shall be followed closely to ensure that the plant operates as intended and to avoid injury or harm. Read and follow the instructions in the “Safety” section at the beginning of this manual.

All the instructions and diagrams have been checked to ensure accuracy and user-friendliness, however the skills and qualification of the operating personnel remain the most significant factor nevertheless. Rolls-Royce Solutions cannot give any assurances for the actual results of any work performed according to the descriptions provided in this manual, nor shall Rolls-Royce Solutions be held liable for any resultant personal injury or material damage. Personnel charged with running and operating the plant do so entirely at their own risk.

Other documents included in the scope of supply shall also be given due consideration in addition to these Operating Instructions.

All documents required by Machinery Directive 2006/42/EC are included in the standard scope of documentation for the engine-generator set. The following documents are supplied in addition:

- Test records
- Spare parts catalog
- Wiring diagrams

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at: <http://www.mtu-solutions.com>

2.2 Intended use of gas systems

Intended use

The machine is intended to be used exclusively for electrical power generation and waste heat utilization in stationary operation, either in sufficiently ventilated rooms or in container solutions.

A gas/air mixture is fed to the internal combustion reciprocating piston engine. This is converted into mechanical work in the individual cylinders through combustion. The flywheel of the engine drives the synchronous generator connected via an elastic coupling, resulting in a conversion to electric energy. The engine and the generator are joined to the base frame with resilient, vibration-damped elements.

For mains frequency 60 Hz, depending on the series either a gearbox is used between the engine and generator or the engine speed is increased accordingly. The waste heat generated during the combustion process is dissipated to the surroundings via coolers (power generator) and/or made available to the customer via heat exchangers (combined heat and power plant).

Area of application	Applicable	Comment
Industry	Yes	–
Business/Service	Yes	In some individual cases, however, such as with swimming pool facilities, schools, heating stations for apartment buildings and the like, no end user in the classic sense is involved
Household	No	Operation is excluded
Potentially explosive area	No	Operation is not permitted in potentially explosive areas
Underground	No	Operation is excluded
Mobile use	No	Operation is excluded

Table 1: Area of application of machine

There are 3 operating modes of the machine:

- Mains parallel operation
- Mains failure operation
- Isolated operation

Foreseeable misuse

Any other use, particularly misuse or wrong parametrization, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Operation

Operation is not permissible if the physical conditions specified on the technical data sheet or on/in other documents (concerning temperature, pressure, site altitude, etc.) are not complied with. Operation is not permissible without protective equipment, usage of approved spare parts, supplied accessory parts, exclusion of conversions, warning of foreseeable misuse.

Operation is only permissible with the use of fluids and lubricants (natural gas, biogas, quality-compliant gas, quality-compliant water, lubricants) in accordance with the (→ Fluids and Lubricants Specifications).

Operation is only permissible with preservation agents approved by Rolls-Royce Solutions in accordance with the (→ Preservation and Represervation Specifications).

Operation is only permissible after proper integration/installation.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Surroundings, climate, temperature

The weather plays no role with regard to the intended use of the engine-generator set/module provided that operation takes place inside an installation room. For container applications, however, the permissible outdoor temperatures at the installation site play a decisive role. The product-specific ambient conditions such as climate and temperature are indicated in the technical description.

Prerequisite for proper use

Fulfillment of all the requirements set out in the "Installation conditions" document.

Any use that does not fall within the described limits for use is regarded as improper.

Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufactur

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.