

Maintenance Schedule

Diesel engine-generator sets

DP00275D5SFA

DP00300D5SFA

DP00365D5S

DP00400D5S

DP00450D5S

DP00500D5S

DP00590D5S

DP00650D5S

Application group 3B

Built in Europe

MS50112/01E



System designation	Engine model	Application group
DP00365D5S	8V1600G10F	3B, Continuous operation, variable
DP00400D5S	8V1600G20F	3B, Continuous operation, variable
DP00450D5S	10V1600G10F	3B, Continuous operation, variable
DP00500D5S	10V1600G20F	3B, Continuous operation, variable
DP00590D5S	12V1600G10F	3B, Continuous operation, variable
DP00650D5S	12V1600G20F	3B, Continuous operation, variable
DP00275D5SFA	6R1600G10F	3B, Continuous operation, variable
DP00300D5SFA	6R1600G20F	3B, Continuous operation, variable

Table 1: Applicability

Printed in Germany

© 2013 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

1 Maintenance Schedule

1.1 Preface

MTU maintenance concept

Modification or removal of mechanical or electronic components or the installation of additional components as well as the execution of calibration processes that might affect the emission characteristics of the engine are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by MTU or equivalent components. Noncompliance with these guidelines might represent a violation of the Clean Air Act.

The maintenance system for MTU products is based on a preventive maintenance concept. Preventive maintenance facilitates advance operational planning and ensures a high level of equipment availability.

Special operating conditions and technical requirements may require additional maintenance work and/or modification of the maintenance intervals. The maintenance tasks are specified together with operating hour intervals and limit values. The first value that occurs is definitive in each case. In order to be authorized to carry out the individual maintenance jobs, maintenance personnel must have achieved a level of training and qualification appropriate to the complexity of the task in hand. The various Qualification Levels QL1 to QL4 reflect the levels of training offered in MTU courses and the contents of the tool kits required:

QL1: Operational monitoring and maintenance work which may be performed without disassembling the diesel engine-generator set when it is out of operation.

QL2: Component replacement (corrective only).

QL3: Maintenance work which requires partial disassembly of the diesel engine-generator set.

QL4: Maintenance work which requires complete disassembly of the diesel engine-generator set.

The maintenance schedule matrix normally finishes with extended component maintenance. Following this, maintenance work is to be continued at the intervals indicated.

The numbers stated in the task list serve as a reference for the scope of parts required.

Notes on maintenance

Specifications for fluids and lubricants, guideline values for their maintenance and change intervals and lists of recommended fluids and lubricants are contained in the MTU Onsite Energy Fluids and Lubricants Specifications A001064 and in the fluids and lubricants specifications produced by the component manufacturers. They are therefore not included in the system maintenance schedule (exception: deviations from the Fluids and Lubricants Specifications). All fluids and lubricants used must meet MTU specifications and be approved by the relevant component manufacturer.

Among other things, the operator/customer must carry out the following additional maintenance work:

- Protect components made of rubber or synthetic material from oil. Never treat them with organic detergents. Wipe with a dry cloth only.
- Starter battery:
Battery maintenance depends on the level of use and the ambient conditions. The specifications of the battery manufacturer apply.

The relevant manufacturer's instructions apply with respect to the maintenance of any components which do not appear in this system maintenance schedule.

Items listed in this system maintenance schedule but which are not included in the MTU Onsite Energy scope of delivery can be ignored.