

MTU_Value*Service* **Technical Documentation**

Engine Series 183

Base: Mercedes-Benz OM 400

6 R 183 TE 52/62/72/92 OM 447 LA

6 R 183 TE 93 OM 447 LA

Operating Instructions

M015245/10E



Printed in Germany

© 2004 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller ihrer Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten.

Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen.

Änderungen bleiben vorbehalten.

Printed in Germany

© 2004 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Imprimé en Allemagne

© 2004 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2004 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2004 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego o utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm e alla memorizzazione o all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

Printed in Germany

© 2004 Copyright MTU Friedrichshafen GmbH

A presente publicação, inclusive todas as suas partes, está protegida pelo direito autoral. Qualquer aproveitamento ou uso exige a autorização prévia e por escrito da MTU Friedrichshafen GmbH.

Isto diz respeito em particular à reprodução, divulgação, tratamento, tradução, microfilmagem, e a memorização e/ou processamento em sistemas eletrônicos, inclusive bancos de dados e serviços on-line.

Para evitar falhas ou danos durante a operação, os dizeres do manual devem ser respeitados. Quem explora o equipamento economicamente consequentemente deve colocá-lo à disposição do respectivo pessoal da conservação, e à disposição dos operadores.

Salvo alterações.

Amendment Service!

Any changes in contents will be sent to you in the form of an amendment,
provided you complete the reverse of this receipt card and return it to us.



	Postcard MTU Friedrichshafen GmbH Department SCT 88040 Friedrichshafen GERMANY
--	--

Please mark all filed amendments here.



No.	Date	Name
1.		
2.		
3.		
4.		
5.		
6.		
7.		
8.		
9.		
10.		
11.		
12.		
13.		
14.		
15.		
16.		

Please use block capitals!



Receipt <i>TICK ONE BOX ONLY!</i> ☐ Update as (PDF) file by E-mail ☐ Update as (PDF) file as CD-ROM ☐ Update in hardcopy form Publication number: M015245/10E Name Manufacturer Department E-mail Fax Telephone Street Postal box number (Postal code) City Country	Amendment No. <table border="1"> <tr><td>1.</td><td></td></tr> <tr><td>2.</td><td></td></tr> <tr><td>3.</td><td></td></tr> <tr><td>4.</td><td></td></tr> <tr><td>5.</td><td></td></tr> <tr><td>6.</td><td></td></tr> <tr><td>7.</td><td></td></tr> <tr><td>8.</td><td></td></tr> <tr><td>9.</td><td></td></tr> <tr><td>10.</td><td></td></tr> <tr><td>11.</td><td></td></tr> <tr><td>12.</td><td></td></tr> <tr><td>13.</td><td></td></tr> <tr><td>14.</td><td></td></tr> <tr><td>15.</td><td></td></tr> <tr><td>16.</td><td></td></tr> </table>	1.		2.		3.		4.		5.		6.		7.		8.		9.		10.		11.		12.		13.		14.		15.		16.	
1.																																	
2.																																	
3.																																	
4.																																	
5.																																	
6.																																	
7.																																	
8.																																	
9.																																	
10.																																	
11.																																	
12.																																	
13.																																	
14.																																	
15.																																	
16.																																	

Introduction/Important Information

This Operation Manual is a supplement to Mercedes-Benz documentation.



This publication contains descriptions of the components and systems of the ship version as well as additional instructions on operation, maintenance and troubleshooting and important information on accident prevention and environmental protection.

Your engine is equipped in accordance with how it is to be installed, i.e. not all components described in this Operation Manual are fitted in your engine.

We have made every effort to emphasize the differences clearly so that you can easily find the operating and maintenance information relevant to your engine.

During operation of the propulsion plant, certain regulations regarding operational reliability and environmental protection must be observed.

The operator is also obliged to familiarize himself with the information given below on the applicable regulations.

MTU accepts no responsibility for incorrect or illegal operation and maintenance of the propulsion plant.

Operation and maintenance are decisive factors in determining whether an engine is always fully operational and remains in serviceable condition for many years. These Operating Instructions are intended to provide answers to questions relating to operation and maintenance in a clearly arranged form.

We urgently recommend that you perform the scheduled maintenance work with care and at the specified intervals. Proper consideration should be given to the engine operating conditions varying from normal operating criteria. Failure to do so may invalidate the warranty. Lead seals affixed to the injection pump and to the governor must on no account be removed.

Should you have any questions relating to service, repairs or parts of the engine, please first contact the engine supplier. In all cases quote the complete engine number, which is stamped on the type plate of the engine. The supplying company will resort to the MTU or MERCEDES-BENZ service if necessary.

The MTU Service Department will also be available to you at any time in an advisory capacity:

MTU Motoren- und Turbinen-Union Friedrichshafen GmbH

88040 Friedrichshafen / Germany
Telefon (07541) 90-0
Telex 734 280-0 mt d
Telefax (07541) 90-39 28

**Safety regulations****IMPORTANT**

These safety regulations must be read and adhered to by all persons using, maintaining or repairing the described machinery plant.

In addition, the following must be observed:

- Safety instructions in other relevant MTU publications
- Warnings and safety instructions and operational and limit values attached to the products as required
- National accident prevention and workplace protection regulations
- Applicable branch-specific regulations
- Safety instructions contained in this publication

Safety instructions in the text

This publication contains, where necessary, special safety instructions that start with a signal word. These safety instructions must be followed in order to avoid injury to persons and damage to equipment.

**CAUTION!**

This sign draws attention to risks or dangers which, if ignored, may lead to **injury** or **death**.

**IMPORTANT**

This sign draws attention to risks or dangers which, if ignored, may lead to the **damage** or **destruction** of the described product or another component.

Correct use and user qualification

All equipment and components must be used only as specified.

Operation, care, maintenance and repairs must be carried out only by authorized, specially trained personnel.

Safety instructions for care, maintenance and repairs

Principal safety measures and symbols are listed in the "Maintenance" chapter of this publication.

Before carrying out work on the machinery plant, ensure that any unauthorized starting is prevented.

Personnel authorized to carry out maintenance and repair work must carry out the work in accordance with the instructions in the documentation.

Suitable tools, if necessary MTU special tools, must always be used for maintenance and repair work.

For the replacement of defective components or assemblies, only original spare parts must be used. The manufacturer rejects all liability for damage caused by the use of other spare parts. In addition, manufacturer warranty would no longer apply.

Spare parts must be stored properly before use, i.e. in particular they must be protected from dampness. Defective electronic components and assemblies must be packed properly before transportation for repair work, i.e. they must be protected from dampness and jolts, and if necessary wrapped in antistatic film.

In the event of damage which cannot be repaired by the plant operator, the MTU Product Support Service or its representative must be notified.

Any unauthorized conversions or alterations to the product invalidate the manufacturer's liability and warranty.

After completion of all maintenance and repair work, ensure that no unauthorized components (tools, etc.) have accidentally been left inside the plant.

After all repair work, a function check must be carried out on the plant. Separate inspection of the repaired component without checking its function within the system is insufficient.

Ensure that repair or maintenance work does not dirty the machinery plant.

User Information

This manual is split up into 7 chapters as listed on the opposite side.

Information Retrieval Guide

- ↓ Main directory
- ↓ Contents directory
- ↓ Headings / Sections

Description

System and Components Description

1

Operation

2

Maintenance

3

Fluids and Lubricants

4

Technical Data

5

Troubleshooting

6

Inspection and Installation

7

Table of Contents

1	Description of engine	9
1.1	General	9
1.2	Key to MTU engine designations	9
	Designation of engine ends	9
1.3	Illustrations of engines	10
1.4	Position of nameplate	17
1.5	Engine data card	17
1.6	Basic-configuration engine	18
1.6.1	Engine block	18
1.6.2	Cylinder heads	18
1.6.3	Crankshaft	18
1.6.4	Conrods	18
1.6.5	Pistons	18
1.6.6	Camshaft	18
1.6.7	Valves	18
1.6.8	Injector system	18
1.6.9	Speed and load control	18
1.6.10	Electrical equipment	18
1.6.11	Crankcase ventilation with oil separator	19
1.6.11.1	Oil separator	19
1.7	Air System/Exhaust system	20
1.7.1	Air filter (Donaldson)	20
1.7.2	Emergency air shut-off flaps	21
1.7.3	Intercooler	22
1.7.4	Exhaust turbocharger K36 (Kühnle, Kopp & Kausch)	23
1.7.4.1	"Waste – Gate" control (exhaust drain valve)	24
1.8	Engine oil system	25
1.8.1	Piston cooling and cam lubrication	26
1.9	Cooling system	26
1.9.1	Coolant cooler with plate-core cooler	30
1.9.1.a	Coolant connections for hull cooler	31
1.9.2	Coolant expansion tank	32
1.9.3	Breather valve	33
1.9.4	Coolant thermostat	34
1.9.5	Coolant pumps	35
1.10	Fuel system	39
1.10.1	Fuel prefilter – edge-type filter –	40
1.10.1.a	Fuel prefilter – water separator –	41
1.10.2	Fuel duplex filter	42
1.10.2.a	Fuel duplex filter	43
1.10.3	Leak-off fuel tank (distributor)	44
1.11	Compressed air starting system	45
1.11.1	Compressed air starter	46
1.11.2	Compressed air filter for starter	49
1.11.3	Compressed air lubricator	49
1.11.4	Solenoid three-way valve	50