

Technical Publication

Diesel Engine
12V 396 TE 74L

Description and
Operation Manual
M010900/20E

DETROIT DIESEL



Printed in Germany

© 2002 Copyright MTU Friedrichshafen GmbH

Diese Veröffentlichung einschließlich aller seiner Teile ist urheberrechtlich geschützt. Jede Verwertung oder Nutzung bedarf der vorherigen schriftlichen Zustimmung der MTU Friedrichshafen GmbH. Das gilt insbesondere für Vervielfältigung, Verbreitung, Bearbeitung, Übersetzung, Mikroverfilmungen und die Einspeicherung und / oder Verarbeitung in elektronischen Systemen, einschließlich Datenbanken und Online-Diensten.

Das Handbuch ist zur Vermeidung von Störungen oder Schäden beim Betrieb zu beachten und daher vom Betreiber dem jeweiligen Wartungs- und Bedienungspersonal zur Verfügung zu stellen.

Änderungen bleiben vorbehalten.

Printed in Germany

© 2002 Copyright MTU Friedrichshafen GmbH

This Publication is protected by copyright and may not be used in any way whether in whole or in part without the prior written permission of MTU Friedrichshafen GmbH. This restriction also applies to copyright, distribution, translation, microfilming and storage or processing on electronic systems including data bases and online services.

This handbook is provided for use by maintenance and operating personnel in order to avoid malfunctions or damage during operation.

Subject to alterations and amendments.

Imprimé en Allemagne

© 2002 Copyright MTU Friedrichshafen GmbH

Tout droit réservé pour cet ouvrage dans son intégralité. Toute utilisation ou exploitation requiert au préalable l'accord écrit de MTU Friedrichshafen GmbH. Ceci s'applique notamment à la reproduction, la diffusion, la modification, la traduction, l'archivage sur microfiches, la mémorisation et / ou le traitement sur des systèmes électroniques, y compris les bases de données et les services en ligne.

Le manuel devra être observé en vue d'éviter des incidents ou des endommagements pendant le service. Aussi recommandons-nous à l'exploitant de le mettre à la disposition du personnel chargé de l'entretien et de la conduite.

Modifications réservées.

Impreso en Alemania

© 2002 Copyright MTU Friedrichshafen GmbH

Esta publicación se encuentra protegida, en toda su extensión, por los derechos de autor. Cualquier utilización de la misma, así como su reproducción, difusión, transformación, traducción, microfilmación, grabación y/o procesamiento en sistemas electrónicos, entre los que se incluyen bancos de datos y servicios en línea, precisa de la autorización previa de MTU Friedrichshafen GmbH.

El manual debe tenerse presente para evitar fallos o daños durante el servicio, y, por dicho motivo, el usuario debe ponerlo a disposición del personal de mantenimiento y de servicio.

Nos reservamos el derecho de introducir modificaciones.

Stampato in Germania

© 2002 Copyright MTU Friedrichshafen GmbH

Questa pubblicazione è protetta dal diritto d'autore in tutte le sue parti. Ciascun impiego od utilizzo, con particolare riguardo alla riproduzione, alla diffusione, alla modifica, alla traduzione, all'archiviazione in microfilm ed alla memorizzazione od all'elaborazione in sistemi elettronici, comprese banche dati e servizi on line, deve essere espressamente autorizzato per iscritto dalla MTU Friedrichshafen GmbH.

Il manuale va consultato per evitare anomalie o guasti durante il servizio, per cui va messo a disposizione dall'utente al personale addetto alla manutenzione e alla condotta.

Con riserva di modifiche.

Printed in Germany

© 2002 Copyright MTU Friedrichshafen GmbH

A presente publicação, inclusive todas as suas partes, está protegida pelo direito autoral. Qualquer aproveitamento ou uso exige a autorização prévia e por escrito da MTU Friedrichshafen GmbH. Isto diz respeito em particular à reprodução, divulgação, tratamento, tradução, microfilmagem, e a memorização e/ou processamento em sistemas eletrônicos, inclusive bancos de dados e serviços on-line. Para evitar falhas ou danos durante a operação, os dizeres do manual devem ser respeitados. Quem explora o equipamento economicamente consequentemente deve colocá-lo à disposição do respectivo pessoal da conservação, e à disposição dos operadores. Salvo alterações.

Notes for the user

This Manual consists of 10 main sections, marked by tab-index sheets.

These sections are listed on this page.

Each Section has its own detailed Table of Contents.

The contents is subdivided into Groups and Subgroups.

The Groups in the Main Sections B and G correspond to the Groups in the Spare Parts Catalogue and other Product Support publications.

Using the Table of Contents to trace an entry

- ↓ Table of Contents (general)
- ↓ Contents
- ↓ Group / Subgroup
- ↓ Heading

Using the Alphabetical Index to trace an entry

- ↓ Term in Alphabetic Index
- ↓ Group / Subgroup
- ↓ Heading

Publication Amendment Service

Please complete and return the Confirmation of Receipt card; you will then receive amendments to your manual.

A Product Summary

Engine summary, technical data

B Description

System and subassembly descriptions

C Operating Instructions

Task descriptions

D Maintenance Schedule

Schedule and maintenance task chart

E Troubleshooting

Fault conditions, probable causes, remedies

F Drawings

Technical engine cross-section drawings

G Task Descriptions

Inspection and maintenance

K Preservation

Engine preservation

? Index


Alphabetical index of key terms

Z Appendix

Amendment Service !

Amendments to this publication will be sent to you in the form of Amendment Sets as and when they are issued provided that you complete and return the receipt section on the reverse of this page.

This also applies when this manual is used within the MTU group of companies.



Postcard

MTU Motoren- und Turbinen-Union
Friedrichshafen GmbH
Abteilung **VLT**

88040 Friedrichshafen

Germany



M010900/20E

Description and
Operation Manual

12 V 396 TE 74L

Amendment filed



No.	Date	Name
1.		
2.		
3.		
4.		
5.		
6.		
7.		
8.		
9.		
10.		
11.		
12.		
13.		
14.		
15.		
16.		

Please use block capitals!



Receipt

Amendment No.

Publication No.:
M010900/20E

Name
Company
Department
Fax Telephone
Street
P.O.Box
(ZIP) City
Country

1.	
2.	
3.	
4.	
5.	
6.	
7.	
8.	
9.	
10.	
11.	
12.	
13.	
14.	
15.	
16.	

Contents

A.000	Product summary - Group A
A.010	Engine layout Engine model designation Engine power Engine layout - cutaway drawings
A.020	Engine side and cylinder designations Designations and abbreviations Cylinder designations Abbreviations
A.030	General specifications Timing data Technical data Engine direction of rotation Firing order Fuel injection pressure Fuel injection timing Engine noise levels Exhaust noise levels
A.040	Main engine dimensions Engine weight Coolant capacity Main plant dimensions Plant weight Engine operational inclinations Oil capacity
A.050	Operational data Pressures Temperatures Consumption

Diesel Engine**Group A
Product Summary**

The product summary gives details of the engine and contains technical data such as engine power, general engine specifications, engine weight, oil and coolant capacities, settings and operational data.

ENGINE LAYOUT, ENGINE POWERKey to Engine Model Designation 12 V 396 TE 74L

12	=	number of cylinders
V	=	vee configuration
396	=	engine series - 100 times displacement of one cylinder in litres
T	=	exhaust turbocharging
E	=	charge air cooling in split-circuit coolant system
7	=	marine engine
4	=	design digit
L	=	power uprated


Engine Power

Fuel stop power 1500 kW at 1900 rpm to 2000 rpm

Reference conditions

- Intake air temperature	25 °C
- Raw water temperature	25 °C
- Fuel temperature	25 °C
- Intake pressure differential	20 mbar
- Exhaust pressure differential	30 mbar


ENGINE LAYOUT, CUTAWAY DRAWING



G 900144 c 0

- | | |
|---------------------------------|---------------------------|
| 1 Expansion tank | 12 Starter |
| 2 Coolant thermostat | 13 Cylinder head |
| 3 Fuel injection pump | 14 Oil pan |
| 4 Valve gear | 15 Crankcase |
| 5 Exhaust outlet | 16 Running gear |
| 6 Air inlet | 17 Engine oil pump |
| 7 Emergency air shut-off flap | 18 Vibration damper |
| 8 Intercooler | 19 Engine mount, free end |
| 9 Exhaust turbocharger | 20 Bilge pump |
| 10 Exhaust manifold | 21 Injection timer |
| 11 Engine mounting, driving end | 22 Engine coolant cooler |

ENGINE SIDE AND CYLINDER DESIGNATIONS



Engine sides are always designated as viewed from the driving end.

The cylinders on the left engine side are designated "A" and those of the right engine side "B" (as per DIN ISO 1204).

The cylinders of each bank are numbered consecutively, starting with no. 1 at the driving end.

The numbering of other engine components is also from the driving end, starting with No. 1.

Designations and Abbreviations

Driving end	=	KS
Free end	=	KGS
Left side		
Right side		
Top		
Bottom		

GENERAL SPECIFICATIONS

Operating method	Four-stroke cycle single-acting
Combustion method	Direct injection
Mode of supercharging	Exhaust turbocharging Single-stage sequential turbocharging
Cooling method	Liquid-cooled
Cylinder arrangement	90° Vee
Bore	165 mm
Piston stroke	185 mm
Displacement, cylinder	3.96 l
Number of cylinders	12
Displacement, total	47.5 l
Compression ratio	12.3 : 1
Direction of rotation (viewed from driving end)	c.c.w. (non reversible)
Firing order	A1 - B2 - A5 - B4 - A3 - B1- A6 - B5 - A2 - B3 - A4 - B6
Firing order, cylinder cutout	A1 - A5 - A3 - A6 - A2 - A4
Nozzle opening pressure	
- Setting pressure with new spring	280 bar to 288 bar
- Specified pressure with run-in spring	270 bar to 278 bar
- Minimum pressure with run-in spring	260 bar
Final compression pressure at 120 rpm, 1000 mbar and 5 °C engine coolant temperature	20 bar to 24 bar
Breakaway torque at 40 °C engine coolant temperature, allowance for acceleration included	approx. 600 Nm
Cranking torque at engine coolant temperature of 40 °C	approx. 560 Nm
Firing speed at engine coolant temperature of 40 °C	approx. 120 rpm
Mean piston speed	11.7 m/s at 1900 rpm
Engine noise mean free-field level	approx. 106 dB(A) at distance of 1 m
Exhaust noise, undamped free-field level	approx. 117 dB(A) at distance of 1 m from outlet