



Operating Instructions

Diesel Engine

8V396TE54

12V396TE54

16V396TE54

Application group 3A

M015600/03E

Engine model	kW/cyl.	Application group
8V396TE54	85 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 50 Hz
12V396TE54	86 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 50 Hz
16V396TE54	85 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 50 Hz
8V396TE54	99 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 60 Hz
12V396TE54	100 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 60 Hz
16V396TE54	99 kW/cyl.	3A, continuous operation, unrestricted, ICXN, 60 Hz

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface		6.8	Operational checks	58
1.1	Preface	6	6.9	Stopping the engine from LOP	59
2	Revision Overview		6.10	Engine - Emergency shutdown at LOP	60
2.1	Revision overview	7	6.11	After stopping the engine	61
3	Safety		6.12	Manual emergency oil priming	62
3.1	Important provisions for all products	8	6.13	Plant - Cleaning	63
3.2	Intended use of all products	9	7	Maintenance	
3.3	Personnel and organizational requirements	10	7.1	Maintenance task reference table [QL1]	65
3.4	Safety regulations for commissioning and operation	11	8	Monitoring and Control System MCS-5	
3.5	Safety regulations for assembly, maintenance, and repair work	13	8.1	Normal Operation: LOP with Display	66
3.6	Fire and environmental protection, indirect materials	17	8.1.1	Local control mode - Gearbox engagement/disengagement	66
3.7	Standards for warning messages in the text and highlighted information	20	8.1.2	Local control mode - Changing engine speed	67
4	General Information		9	Troubleshooting	
4.1	Engine side and cylinder designations	21	9.1	Troubleshooting - Diesel engine	68
4.2	Engine Series V 396 TE54	22	9.2	Oil priming pump - Troubleshooting	75
4.3	Product description	28	9.3	Fault indications and fault messages	77
5	Technical Data		9.4	Display forms of fault messages at the LOP	113
5.1	Engine data 8V396TE54 with IMO II D injection pump	34	9.5	ECU 2 governor - Troubleshooting	115
5.2	Engine data 12V396TE54 with IMO II D injection pump	37	10	Task Description	
5.3	Engine data 16V396TE54 with IMO II D injection pump	40	10.1	SOLAS	116
5.4	Engine - Main dimensions	43	10.1.1	SOLAS shielding as per MTN 5233 - Installation	116
5.5	Firing order	44	10.1.2	Adhesive tape for SOLAS shielding - Application	117
6	Operation		10.1.3	SOLAS shielding - Installation locations	118
6.1	LOP - Overview	45	10.2	Engine	127
6.2	Pump control - Control and displays	51	10.2.1	Engine - Barring manually	127
6.3	ECU-2 - Use	52	10.2.2	Cranking engine on starting system	128
6.4	Preheating unit control cabinet - Control elements	54	10.3	Cylinder Liner	129
6.5	Preparations for putting into operation after extended out-of-service periods (>3 months)	55	10.3.1	Cylinder liner - Endoscopic examination	129
6.6	Putting the engine into operation after scheduled out-of-service-period	56	10.3.2	Cylinder liner - Instructions and comments on endoscopic and visual examination	131
6.7	Engine - Starting at LOP	57	10.4	Crankcase Breather	133
			10.4.1	Crankcase ventilation - Cleaning oil pre-separator element	133
			10.5	Cylinder Head	134
			10.5.1	Diesel fuel thermocouple - Check	134
			10.5.2	Combustion chambers - Condensate draining	135
			10.6	Valve Drive	136
			10.6.1	Valve clearance - Check and adjustment	136

10.6.2	Cylinder head cover - Removal and installation	139	10.16.2	Starter - Condition check	181
			10.16.3	Starter - Check carbon brushes	182
10.7	Governor Actuator	140	10.16.4	Compressed-air filter - Cleaning	183
10.7.1	Start and stop position - Check	140	10.16.5	Starting, drain, and decompression valve - Visual check	184
10.8	Injector	141	10.17	Lube Oil System, Lube Oil Circuit	185
10.8.1	Injector - Removal and installation	141	10.17.1	Engine oil level - Check	185
10.8.2	Injector - Disassembly	144	10.17.2	Engine oil - Change	186
10.8.3	Injector - Cleaning	145	10.17.3	Engine oil - Sample extraction and analysis	187
10.8.4	Injector - Check	146	10.17.4	Oil sludge - Check for metallic residues	188
10.8.5	Injector - Assembly	148	10.17.5	Oil priming pump - Checking direction of rotation	189
10.8.6	Injector - Replacement	149			
10.8.7	Injector - Hole-type nozzle replacement	150	10.18	Oil Filtration / Cooling	190
10.9	Fuel System	151	10.18.1	Engine oil filter - Draining oil sludge	190
10.9.1	Fuel system - Venting	151	10.18.2	Engine oil filter - Edge-type filter element cleaning	191
10.9.2	Leak fuel tank - Draining	152	10.18.3	Engine oil filter - Replacement	192
10.10	Fuel Filter	153	10.18.4	Centrifugal oil filter - Cleaning and filter sleeve replacement	195
10.10.1	Fuel filter - Replacement	153	10.18.5	Engine oil bypass filter - Replacement	198
10.10.2	Fuel prefilter - Differential pressure check and adjustment of gauge	156	10.18.6	Oil priming pump - Manual operation	200
10.10.3	Fuel prefilter - Draining	157			
10.10.4	Fuel prefilter - Flushing	159	10.19	Coolant Circuit, General, High-Temperature Circuit	201
10.10.5	Fuel prefilter - Filter element replacement	162	10.19.1	Heat exchanger - Venting	201
10.11	Control and Regulation Equipment	164	10.19.2	Engine coolant level - Check	202
10.11.1	Engine - Manual shutdown	164	10.19.3	Engine coolant - Change	203
10.11.2	Control linkage - Lubrication	165	10.19.4	Engine coolant - Draining	204
10.12	Electronic Engine Governing (Engine-Mounted Equipment)	166	10.19.5	Engine coolant - Filling	205
10.12.1	Speed sensor - Check	166	10.19.6	Coolant return line - Cleaning strainer	206
10.12.2	Speed sensor - Removal and installation	167	10.19.7	Engine coolant pump - Relief bore check	207
10.13	Charge-Air Cooling	168	10.19.8	Engine coolant - Sample extraction and analysis	208
10.13.1	Intercooler - Checking condensate drain for coolant discharge and obstructions	168	10.20	Raw Water Pump with Connections	209
10.14	Air Filter	169	10.20.1	Raw water pump - Relief bore check	209
10.14.1	Air filter - Installation and removal	169	10.21	Battery-Charging Generator	210
10.14.2	Air filter - Removal and installation	171	10.21.1	Battery-charging generator - Condition check	210
10.14.3	Air filter element and dust bowl - Cleaning	172	10.21.2	Battery-charging generator - Checking condition of carbon brushes and coupling	211
10.14.4	Air filter - Replacement	173	10.21.3	Battery-charging generator - Checking carbon brushes and collector rings	212
10.15	Air Intake	174	10.22	Engine Mounting / Support	213
10.15.1	Contamination indicator - Signal ring position check	174	10.22.1	Engine mounting - Cleaning	213
10.15.2	Air intake housing - Cover plate removal and installation	175	10.22.2	Engine mounting - Checking securing screws for firm seating	214
10.15.3	Emergency air shut-off flap - Lubrication	176	10.23	Drive Systems, Driving End and Free End (Coupling)	215
10.15.4	Emergency-air shutoff flap - Electric control check	177	10.23.1	Torsionally resilient coupling - Check	215
10.15.5	Emergency air-shutoff flap - Manual closing/opening	178	10.24	Wiring (General) for Engine/Gearbox/Unit	216
10.15.6	Air supply - Check for leaks, damage and secure seating of screws	179	10.24.1	Engine cabling - Check	216
10.16	Starting Equipment	180	10.25	Accessories for (Electronic) Engine Governor / Control System	217
10.16.1	Air starter (emergency start) - Manual operation	180	10.25.1	ECS - Connectors and housing cleaning	217

10.25.2 Plug connections - Check	218	11.2 List of abbreviations	226
10.26 Control and Display Elements, General	219	11.3 Conversion tables	228
10.26.1 Incandescent indicator lamp - Replacement	219	11.4 Tightening specifications for screws, nuts and bolts	232
10.26.2 Indicator lamp - LED replacement	220	11.5 Tolerances and wear limits list - General information	245
10.26.3 Fluid level monitor - Check	222	11.6 Contact person/Service partner	246
10.27 Emergency Instrumentation (Local Operating Panel)	223		
10.27.1 Engine control system - Operational tests	223	12 Appendix B	
		12.1 Standard Tools and Special Tools	247
11 Appendix A		12.2 Index	254
11.1 Standard tools - Overview	225		

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Revision Overview

2.1 Revision overview

Revision overview – General

Chapter	Status M015600/02	Status M015600/03
–	Warning notices in general	Warning messages updated
–	Graphics in general	Graphics updated
–	Special tools, consumables, spare parts in general	Special tools, consumables, spare parts updated
–	Chapter “Safety” general	Chapter “Safety” updated
–	–	Chapter “Copyright” added
–	–	Chapter “Preface” added

3 Safety

3.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

3.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

3.3 Personnel and organizational requirements

Organizational measures of the user/manufactururer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

3.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/– polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear hearing protection.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.

3.5 Safety regulations for assembly, maintenance, and repair work

Safety regulations for work prior to assembly, maintenance, and repair

Have assembly, maintenance, or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion from oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable containers of adequate capacity to catch fluids and lubricants.

Release residual pressure before removing a component in the supply line. To depressurize pressurized lines, shut off the lines first, then release the residual pressure.

Work may only be carried out on lines when they are free of fluids and lubricants.

Ensure adequate ventilation of the operating room when conducting an oil change, working on the gaseous/liquid fuel system or working with process materials (e.g. adhesive, cleaner).

Never carry out assembly, maintenance, or repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- Close supply line for hydraulic starting.
- Close the main valve on the compressed-air system and vent the compressed-air line when air starters are fitted.

Attach “Do not operate” sign in the operating area or to control equipment.

Disconnect the battery cables or actuate the battery isolator switch, if fitted. Lock circuit breakers.

Before starting work on CaPoS, if used:

- Switch off the charging system (DC/DC converter).
- Discharge the UltraCap modules using the appropriate discharger.
- Short-circuit the UltraCap modules with a suitable wire jumper.

Before working on the exhaust gas aftertreatment system, close the shutoff valve on the reducing agent tank. Note that the reducing agent pumps continue to run for a certain period when the engine is stopped.

Disconnect the control equipment from the product.

Use the recommended special tools or suitable equivalents when instructed to do so.

Safety regulations when performing assembly, maintenance, and repair work

Special tools and lifting equipment

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Setting down, lifting and climbing

Carry out work only on assemblies or plants which are properly secured.

Use appropriate lifting equipment for all components. Use all specified attachment points and observe the center of gravity.

Never stand beneath a suspended load.

Never work on engines or components when they are held in place by lifting equipment.

Make sure components or assemblies are placed on stable surfaces and secured against tilting over or rolling away. Adopt suitable measures to prevent components/tools from falling down.

Assume a safe standing position when performing assembly work.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Special instructions for outdoor areas: There must be no risk of slipping e.g. due to icing.

Removing, installing and cleanliness

Pay particular attention to cleanliness at all times.

Completely wipe up escaped fluids and lubricants due to the risk of slipping.

Take special care when removing ventilation or plug screws from the product.

Ensure that O-rings are not installed in a slanted/twisted condition.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanliness (e.g. components carrying oil, fuel, or air).

Note cooling time for components which are heated for installation or removal (risk of burning).

Ensure that all mounts and dampers are installed correctly.

Remove any accumulation of condensate after assembling chilled components. Coat the components with a suitable corrosion inhibitor as necessary.

Lines

Ensure that lines for all fluids and lubricants and their connections are clean.

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Never bend lines and avoid damaging lines, particularly the fuel lines.

Ensure that the lines for all fluids and lubricants have sufficient play to avoid contact with other components. Do not place fuel or oil lines near hot components.

Miscellaneous

Follow good hygiene practices, e.g. washing hands after work and before eating.

Sufficient ventilation must be guaranteed during the work.

Wear a breathing mask offering protection against soot, dust, and mineral fibers (filter class P3) when working on exhaust components. Clean the work area with a dust extraction machine of class H. Wear protective gloves and goggles for protection against acidic condensate.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. Only install them after painting the engine or mask them prior to painting.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations after performing assembly, maintenance, and repair work

Before cranking the engine, make sure no one is in the danger zone of the engine.

Check that all access ports/apertures which have been opened to facilitate working are closed again.

All protective devices must be installed and all tools and loose parts must be removed (especially the barring tool).

Ensure that no unattached parts have been left in/on the product (e.g. including rags and cable straps).

Ensure that the grounding system is properly connected.

Welding work

Welding work on the product or any installed equipment may only be carried out by personnel authorized by Rolls-Royce Solutions. Cover the product when welding in its vicinity.

Before starting welding work:

- Switch off the power supply master switch.
- Disconnect the battery cables or actuate the battery isolator switch.
- Separate the electrical ground of electronic equipment from the ground of the unit.

No other assembly, maintenance, or repair work may be carried out in the vicinity of the product while welding is in progress. There is a risk of explosion or fire due to oil vapors or highly flammable fluids and lubricants.

Do not use product as ground terminal.

Never position the welding power supply cable adjacent to, or crossing wiring harnesses of the product. The welding current can induce interfering voltages in the wiring harnesses which may damage the electrical system.

Remove components (e.g. exhaust pipe) from the product before performing necessary welding work.

Hydraulic installation and removal

Check the function and safe operating condition of tools and fixtures to be used. Use only the specified jigs for the hydraulic removal/installation procedures.

Observe the max. permissible push-on pressure specified for the equipment.

Do not attempt to bend or apply force to lines which are under pressure.

Before starting work, pay attention to the following:

- Vent the installation/removal jig, the pumps and the pipework at the relevant designated points.
- For hydraulic installation, screw on the jig with the piston retracted.
- For hydraulic removal, screw on the jig with the piston extended.

For a hydraulic installation/removal jig with central expansion pressure supply, screw spindle into shaft end until correct sealing is established.

During hydraulic installation and removal of components, ensure that nobody is standing in the immediate vicinity of the component to be installed/removed.

Working with batteries

Observe the safety instructions of the manufacturer when working on batteries.

Gases released from the battery are explosive. Avoid sparks and naked flames.

Do not allow electrolyte to come into contact with skin or clothing.

Wear protective clothing, goggles and protective gloves.

Do not place objects on the battery.

Before connecting the cable to the battery, check the battery polarity. The battery may explode and spray acid if the battery terminals are connected incorrectly.

Working on electrical and electronic assemblies

Always obtain the permission of the person in charge before commencing any assembly, maintenance, and repair work or switching off any part of the electronics required to do so.

De-energize the relevant areas prior to working on assemblies.

ESD (Electrostatic Discharge): Work on components which could be damaged by electrostatic discharge must always be carried out with appropriate equipment. Appropriate equipment is e.g. electrically conductive work surfaces or antistatic wristbands.