



Operating Instructions

Diesel engine
12V1163TB93

MS15078/02E

Engine model	kW/cyl.	Application group
12V 1163 TB93	370 kW/cyl.	1DS, continuous operation at variable load, low load factors

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

California Proposition 65

This warning applies only to the State of California, USA, in compliance with Title 27 California Code of Regulations, Article 6, Clear and Reasonable Warnings.



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

(→ www.P65warnings.ca.gov/diesel)

Table of Contents

1	Safety		5.11	Priming Pump Controller PPC - Function check	52
1.1	Important provisions for all products	8	5.12	Engine - Prelubrication	53
1.2	Intended use of all products	9	5.13	Plant - Cleaning	54
1.3	Personnel and organizational requirements	10			
1.4	Safety regulations for commissioning and operation	11	6	Maintenance	
1.5	Safety regulations for assembly, maintenance, and repair work	13	6.1	50-hours service	56
1.6	Fire and environmental protection, indirect materials	17	6.2	Maintenance task reference table [QL1]	57
1.7	Standards for warning messages in the text and highlighted information	20	7	Troubleshooting	
2	Transport		7.1	Troubleshooting	59
2.1	Transport	21	7.2	Oil priming pump - Troubleshooting	69
2.2	Crankshaft transport locking device	22	7.3	Fault indications and fault messages	71
3	General Information		8	Task Description	
3.1	Engine side and cylinder designations	26	8.1	SOLAS	117
3.2	Product description	27	8.1.1	Installation locations for SOLAS shielding 12V	117
3.3	Engine - Overview	29	8.1.2	Adhesive tape for SOLAS shielding - Application	163
3.4	Sensors and actuators	30	8.1.3	SOLAS shielding as per MTN 5233 - Installation on 12V engine	164
4	Technical Data		8.2	Engine	165
4.1	Engine data 12V1163TB93	34	8.2.1	Engine barring - Manually	165
4.2	Firing order	39	8.2.2	Cranking engine on starting system	167
4.3	Engine - Main dimensions	40	8.3	Cylinder Liner	168
5	Operation		8.3.1	Combustion chambers - Draining condensate	168
5.1	Putting the engine into operation after extended out-of-service periods (>3 months)	41	8.3.2	Cylinder liner - Endoscopic examination	169
5.2	Preparations for putting into operation after scheduled out-of-service-period	42	8.3.3	Cylinder liner - Instructions and comments on endoscopic and visual examination	171
5.3	Starting the engine via the automation system	43	8.3.4	Decompression valve - Opening	173
5.4	Operational monitoring	44	8.3.5	Decompression valve - Closing	174
5.5	Engine shutdown via the automation system	45	8.4	Valve Drive	175
5.6	Emergency engine shutdown via automation system	46	8.4.1	Valve clearance - Check and adjustment	175
5.7	Pump control - Control and displays	47	8.4.2	Cylinder head cover - Removal and installation	177
5.8	Preheating unit	48	8.5	Injector	178
5.9	Regeneration burn-off routine after low-load operation	50	8.5.1	Injector - Removal and installation	178
5.10	After stopping the engine	51	8.5.2	Injector - Cleaning	182
			8.5.3	Injector - Check	184
			8.5.4	Injector - Disassembly	186
			8.5.5	Injector - Hole-type nozzle replacement	187
			8.5.6	Injector - Assembly	188
			8.5.7	Injector - Replacement	190
			8.6	Fuel System	191
			8.6.1	Fuel system - Diagram	191
			8.6.2	Leak fuel tank - Draining	192
			8.6.3	Fuel system - Venting	193

8.7	Fuel Filter	194	8.15.5	Oil sludge - Check for metallic residues	236
8.7.1	Fuel filter - Replacement	194	8.15.6	Oil priming pump - Checking direction of rotation	237
8.7.2	Fuel prefilter - Differential pressure indicator check and adjustment	197	8.16	Oil Filtration / Cooling	238
8.7.3	Fuel prefilter - Draining	198	8.16.1	Disk-pack filter - Cleaning	238
8.7.4	Fuel prefilter - Flushing	199	8.16.2	Disk-pack filter - Filter pack replacement	240
8.7.5	Fuel prefilter - Filter element replacement	201	8.16.3	Engine oil filter - Edge-type filter element cleaning	241
8.8	Preheater	204	8.16.4	Engine oil filter - Replacement	242
8.8.1	Preheater	204	8.16.5	Piston cooling-oil filter - Replacement	243
8.8.2	Preheater - Function and leak check	206	8.16.6	Engine oil bypass filter - Replacement	245
8.8.3	Preheater - Checking heating element(s) (electrical)	207	8.17	Coolant Circuit, General, High-Temperature Circuit	247
8.9	Control and Regulation Equipment	208	8.17.1	Coolant system on 12V engines - Diagram	247
8.9.1	Governor linkage - Coupling lubrication	208	8.17.2	Drain and vent points	248
8.10	Charge-Air Cooling	209	8.17.3	Vent line - Obstruction check	252
8.10.1	Intercooler - Checking drain line for coolant discharge and obstruction	209	8.17.4	Heat exchanger - Venting	253
8.10.2	Intercooler - Drain line check	210	8.17.5	Engine coolant level - Check	254
8.11	Air Filter	211	8.17.6	Engine coolant - Change	255
8.11.1	Air filter - Replacement	211	8.17.7	Draining engine coolant	256
8.11.2	Air filter - Removal and installation	212	8.17.8	Engine coolant - Sample extraction and analysis	257
8.11.3	Air filter element and dust bowl - Cleaning	213	8.17.9	Engine coolant - Filling	258
8.12	Air Intake	214	8.17.10	Engine coolant pump - Relief bore check	259
8.12.1	Contamination indicator - Signal ring position check	214	8.17.11	Preheater - Function and leak check	260
8.12.2	Emergency air shut-off flaps - Lubrication	215	8.17.12	Coolant system - Strainer removal	261
8.12.3	Emergency-air shut-off flap - Check operation with electric actuation	216	8.18	Raw Water Pump with Connections	262
8.12.4	Emergency-air shutoff flap - Manual closing/opening	217	8.18.1	Raw water system - Diagram	262
8.13	Exhaust Flap with Actuator	218	8.18.2	Raw water pump - Relief bore check	263
8.13.1	Supercharging and flap control - Diagram	218	8.18.3	Automatic seawater inductor - Function check	264
8.13.2	Exhaust turbocharger control linkage - Lubrication	220	8.19	Engine Mounting / Support	265
8.13.3	Air and exhaust flaps - Functional check	221	8.19.1	Engine mounting - Cleaning	265
8.14	Starting Equipment	222	8.19.2	Engine mounting - Check and adjustment	266
8.14.1	Pressure reducing station for control air - Putting into operation	222	8.19.3	Engine mounting - Checking securing screws for firm seating	268
8.14.2	Pressure reducing station for control air - Venting and shutdown	224	8.20	Drive Systems, Driving End and Free End (Coupling)	269
8.14.3	Pressure reducing station for control air - Filter cleaning	225	8.20.1	Coupling - Condition check	269
8.14.4	3/2-way directional solenoid control valve - Leak check	226	8.21	Cabling	270
8.14.5	3/2-way solenoid valve - Checking operation of electric actuation	227	8.21.1	Engine cabling - Check	270
8.14.6	Compressed-air tank - Draining condensate	228	8.22	Accessories for (Electronic) Engine Governor / Control System	271
8.14.7	Compressed-air tank - Checking for leaks	229	8.22.1	ECS - Connectors and housing cleaning	271
8.15	Lube Oil System, Lube Oil Circuit	230	8.22.2	Plug connections - Check	272
8.15.1	Lube oil system - Diagram	230	8.22.3	ECS - Removal and installation	273
8.15.2	Engine oil level - Check	231	8.23	Control and Display Elements, General	275
8.15.3	Engine oil - Change	233	8.23.1	Limit switch - Check	275
8.15.4	Engine oil - Sample extraction and analysis	235	8.23.2	Indicator lamp - LED replacement	276
			8.23.3	Fluid level monitor - Check	278
			8.24	Emergency Instrumentation (Local Operating Panel)	279
			8.24.1	Engine control system - Operational tests	279

9 Appendix A		9.3 Contact person/Service partner	297
9.1 Tightening specifications for screws, nuts and bolts	281	10 Appendix B	
9.2 Abbreviations	295	10.1 Standard Tools and Special Tools	298
		10.2 Index	306

1 Safety

1.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

1.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.