

# Operating Instructions

Diesel engine  
**6R1600M20x**

**MS15029/01E**



*Power. Passion. Partnership.*

| Engine model | kW/cyl.      | Hz    | rpm  | Application group                      |
|--------------|--------------|-------|------|----------------------------------------|
| 6R1600M20F   | 44.8 kW/cyl. | 50 Hz | 1500 | 3A, continuous operation, unrestricted |
| 6R1600M20S   | 53.8 kW/cyl. | 60 Hz | 1800 | 3A, continuous operation, unrestricted |

*Table 1: Applicability*

# Table of Contents

|     |                                                                                          |  |    |        |                                                          |  |     |
|-----|------------------------------------------------------------------------------------------|--|----|--------|----------------------------------------------------------|--|-----|
| 1   | Safety                                                                                   |  | 5  | 5      | Maintenance                                              |  |     |
| 1.1 | Important provisions for all products                                                    |  | 5  | 5.1    | Maintenance task reference table [QL1]                   |  | 53  |
| 1.2 | Personnel and organizational requirements                                                |  | 7  | 6      | Troubleshooting                                          |  |     |
| 1.3 | Safety regulations for startup and operation                                             |  | 8  | 6.1    | Troubleshooting                                          |  | 54  |
| 1.4 | Safety regulations for maintenance and repair work                                       |  | 10 | 6.2    | Engine governor ECU9 - Fault messages                    |  | 57  |
| 1.5 | Fire prevention and environmental protection, fluids and lubricants, auxiliary materials |  | 13 | 7      | Task Description                                         |  |     |
| 1.6 | Auxiliary materials, fire prevention and environmental protection                        |  | 15 | 7.1    | SOLAS                                                    |  | 67  |
| 1.7 | Standards for safety notices in the text                                                 |  | 17 | 7.1.1  | Installation locations for SOLAS shielding               |  | 67  |
| 1.8 | Transport                                                                                |  | 18 | 7.1.2  | SOLAS shielding as per MTN 5233 - Installation           |  | 69  |
| 2   | General Information                                                                      |  |    | 7.1.3  | Adhesive tape for SOLAS shielding - Application          |  | 70  |
| 2.1 | Engine side and cylinder designations                                                    |  | 19 | 7.2    | Engine                                                   |  | 71  |
| 2.2 | Product description                                                                      |  | 20 | 7.2.1  | Engine - Barring manually                                |  | 71  |
| 2.3 | Engine overview                                                                          |  | 23 | 7.2.2  | Engine - Barring with starting system                    |  | 73  |
| 2.4 | Sensors and actuators - Overview                                                         |  | 25 | 7.2.3  | Engine - Test run                                        |  | 74  |
| 3   | Technical Data                                                                           |  |    | 7.3    | Crankcase Breather                                       |  | 75  |
| 3.1 | Engine data 6R1600M20F, 6R1600M20S, engine-mounted heat exchanger, IMO Tier 2            |  | 29 | 7.3.1  | Crankcase breather - Fine oil mist separator replacement |  | 75  |
| 3.2 | Engine data 6R1600M20F, 6R1600M20S, remote heat exchanger, IMO Tier 2                    |  | 33 | 7.4    | Valve Drive                                              |  | 77  |
| 3.3 | Engine data 6R1600M20S, engine-mounted heat exchanger, EPA Tier 3                        |  | 36 | 7.4.1  | Valve clearance - Check and adjustment                   |  | 77  |
| 3.4 | Engine data 6R1600M20S, remote heat exchanger, EPA Tier 3                                |  | 39 | 7.4.2  | Cylinder head cover - Removal and installation           |  | 79  |
| 3.5 | Firing order                                                                             |  | 42 | 7.5    | Injector                                                 |  | 82  |
| 3.6 | Engine - Main dimensions                                                                 |  | 43 | 7.5.1  | Injector - Replacement                                   |  | 82  |
| 4   | Operation                                                                                |  |    | 7.5.2  | Injector - Removal and installation                      |  | 83  |
| 4.1 | Putting the engine into operation after extended out-of-service periods (>3 months)      |  | 44 | 7.6    | Fuel System                                              |  | 88  |
| 4.2 | Putting the engine into operation after scheduled out-of-service-period                  |  | 45 | 7.6.1  | Fuel system - Venting                                    |  | 88  |
| 4.3 | Engine start in manual operation (trials)                                                |  | 46 | 7.7    | Fuel Filter                                              |  | 89  |
| 4.4 | Safety system - Override                                                                 |  | 47 | 7.7.1  | Fuel filter - Replacement                                |  | 89  |
| 4.5 | Operational checks                                                                       |  | 48 | 7.8    | Air Filter                                               |  | 92  |
| 4.6 | Engine stop in manual operation (trials)                                                 |  | 49 | 7.8.1  | Air filter - Replacement                                 |  | 92  |
| 4.7 | Emergency stop                                                                           |  | 50 | 7.8.2  | Air filter - Removal and installation                    |  | 93  |
| 4.8 | After stopping the engine - Engine remains ready for operation                           |  | 51 | 7.9    | Air Intake                                               |  | 94  |
| 4.9 | After stopping engine - Putting engine out of operation                                  |  | 52 | 7.9.1  | Service indicator - Signal ring position check           |  | 94  |
|     |                                                                                          |  |    | 7.10   | Lube Oil System, Lube Oil Circuit                        |  | 95  |
|     |                                                                                          |  |    | 7.10.1 | Engine oil - Level check                                 |  | 95  |
|     |                                                                                          |  |    | 7.10.2 | Engine oil - Change                                      |  | 97  |
|     |                                                                                          |  |    | 7.11   | Oil Filtration / Cooling                                 |  | 98  |
|     |                                                                                          |  |    | 7.11.1 | Engine oil filter - Replacement                          |  | 98  |
|     |                                                                                          |  |    | 7.12   | Coolant System, General, High-Temperature Circuit        |  | 102 |
|     |                                                                                          |  |    | 7.12.1 | Engine coolant - Level check                             |  | 102 |

|        |                                                                       |     |        |                                                |     |
|--------|-----------------------------------------------------------------------|-----|--------|------------------------------------------------|-----|
| 7.12.2 | Engine coolant - Change                                               | 103 | 7.16.1 | Engine governor and connector - Cleaning       | 117 |
| 7.12.3 | Engine coolant - Draining                                             | 104 | 7.16.2 | Engine governor - Checking plug-in connections | 118 |
| 7.12.4 | Engine coolant - Filling                                              | 105 |        |                                                |     |
| 7.12.5 | Engine coolant pump - Relief bore check                               | 107 | 7.17   | Engine Mounting / Support                      | 119 |
| 7.13   | Low-Temperature Circuit                                               | 108 | 7.17.1 | Engine mounting - Check                        | 119 |
| 7.13.1 | Charge-air coolant pump - Relief bore check                           | 108 |        |                                                |     |
| 7.14   | Belt Drive                                                            | 109 | 8      | Appendix A                                     |     |
| 7.14.1 | Drive belt - Condition check                                          | 109 | 8.1    | Abbreviations                                  | 121 |
| 7.14.2 | Belt tensioner - Check                                                | 110 | 8.2    | MTU contact persons/service partners           | 123 |
| 7.14.3 | Drive belt - Replacement                                              | 111 |        |                                                |     |
| 7.14.4 | Belt tensioner - Tensioning element and tensioning roller replacement | 113 | 9      | Appendix B                                     |     |
| 7.15   | Wiring (General) for Engine/Gearbox/Unit                              | 116 | 9.1    | Special Tools                                  | 124 |
| 7.15.1 | Engine cabling - Check                                                | 116 | 9.2    | Index                                          | 131 |
| 7.16   | Accessories for (Electronic) Engine Governor / Control System         | 117 |        |                                                |     |

# 1 Safety

## 1.1 Important provisions for all products

### **Nameplate**

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

### **General information**

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

### **Correct use**

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

### **Modifications or conversions**

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

## **Emission regulations and emission labels**

### **Responsibility for compliance with emission regulations**

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

### **Replacing components with emission labels**

Emission labels are attached to all MTU engines. These must remain on the engine throughout its operational life.

Engines used exclusively in land-based, military applications other than by US government agencies are excepted from this proviso.

Please note the following when replacing components with emission labels:

- Appropriate emission labels must be affixed on spare parts.
- Emission labels may not be transferred from old components to new ones.
- Emission labels on old components must be removed and destroyed.

## 1.2 Personnel and organizational requirements

### **Organizational measures of the user/manufacturer**

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Personnel must receive instruction on product handling and maintenance on the basis of this manual with a special emphasis on safety requirements and warnings.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

### **Personnel requirements**

All work on the product shall be carried out by trained and qualified personnel only:

- Training at the Training Center of the manufacturer
- Technical personnel from the areas mechanical engineering, plant construction and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Personnel must not be under the influence of alcohol, drugs or strong medication.

### **Work clothing and personal protective equipment**

When working, always wear the necessary personal protective equipment (e.g. safety shoes, ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

## 1.3 Safety regulations for startup and operation

### Safety regulations for startup

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

When putting the product into operation, always ensure that

- All personnel is clear of the danger zone surrounding moving parts of the machine.  
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- Keep clear of the service room during the first operating hours. Hazardous gases may occur as a result of the combustion of paints or oils.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated (e.g. +/- polarity, direction).

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Smoking is prohibited in the area of the product.

### Safety regulations during operation

The operator must be familiar with the controls and displays.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

### Malfunctions and emergency stop

The procedures for emergencies, in particular, emergency stop, must be practiced regularly.

The following steps must be taken if a malfunction of the system is detected or reported by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond to the emergency appropriately, e.g. execute an emergency stop.

### Operation

Do not remain in the operating room when the product is running for any longer than absolutely necessary.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binder agent.

### Operation of electrical equipment

During operation of electrical devices, certain elements of these devices are live/under high voltage.



Observe the warning information applicable to the devices.

## 1.4 Safety regulations for maintenance and repair work

### **Safety regulations prior to maintenance and repair work**

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collecting vessels of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- With hydraulic starting system: shut off supply line.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock out circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

Use special tools if they are specified for the relevant work.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. They may only be installed after painting the engine or must be covered before painting work is carried out.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

### **Safety regulations during maintenance and repair work**

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down. Use the specified lifting equipment for all components.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Never work on engines or components that are held in place by lifting equipment.

Keep fuel injection lines and connections clean.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanness (e.g. components carrying oil, fuel, or air).