

Operating Instructions

Diesel engine
12 V 1600 R50

MS15033/02E



Power. Passion. Partnership.

Engine model	kW/cyl.	Application group
12V1600R50	58 kW/cyl.	2A, Continuous operation, unrestricted

Table 1: Applicability

© 2015 Copyright MTU Friedrichshafen GmbH

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of MTU Friedrichshafen GmbH. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. MTU Friedrichshafen GmbH reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Safety			
1.1	Important provisions for all products	5		
1.2	Personnel and organizational requirements	7		
1.3	Transportation	8		
1.4	Safety regulations for startup and operation	9		
1.5	Safety regulations for maintenance and repair work	10		
1.6	Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	13		
1.7	Standards for safety notices in the text	15		
2	General Information			
2.1	Engine side and cylinder designations	16		
2.2	Engine overview	17		
2.3	Sensors and actuators - Overview	18		
3	Technical Data			
3.1	Firing order	22		
3.2	Engine - Main dimensions	23		
3.3	12V1600R50 product data	24		
4	Operation			
4.1	Putting the engine into operation after scheduled out-of-service-period	27		
4.2	Putting the engine into operation after extended out-of-service periods (>3 months)	28		
4.3	Starting the engine	29		
4.4	Operational checks	30		
4.5	Engine - Stop	31		
4.6	After stopping the engine	32		
4.7	Plant - Cleaning	33		
4.8	Engine - Barring manually	34		
5	Maintenance			
5.1	Maintenance task reference table [QL1]	36		
6	Troubleshooting			
6.1	Troubleshooting	37		
6.2	Fault messages of engine governor ECU 9 for Series 1600, rail applications	40		
7	Task Description			
7.1	Valve Drive	83		
7.1.1	Valve clearance - Check and adjustment	83		
7.1.2	Cylinder head cover - Removal and installation	86		
7.2	Fuel System	87		
7.2.1	Fuel system - Venting	87		
7.3	Fuel Filter	89		
7.3.1	Fuel filter - Replacement	89		
7.3.2	Fuel prefilter - Drain condensate	91		
7.3.3	Fuel prefilter - Filter element replacement	92		
7.4	Air Filter	93		
7.4.1	Air filter element - Removal and installation (optional)	93		
7.4.2	Air filter element and (optional) dust bowl - Cleaning	94		
7.4.3	Air filter - Replacement (option)	95		
7.5	Air Intake	96		
7.5.1	Service indicator - Signal ring position check	96		
7.6	Lube Oil System, Lube Oil Circuit	97		
7.6.1	Engine oil level - Check	97		
7.6.2	Engine oil - Change	98		
7.7	Oil Filtration / Cooling	99		
7.7.1	Engine oil filter - Replacement	99		
7.8	Coolant Circuit, General, High-Temperature Circuit	100		
7.8.1	Engine coolant - Level check	100		
7.8.2	Engine coolant - Change	101		
7.8.3	Engine coolant - Draining	102		
7.8.4	Engine coolant - Filling	104		
7.8.5	Engine coolant pump - Relief bore check	106		
7.9	Low-Temperature Circuit	107		
7.9.1	Charge-air coolant level - Check	107		
7.9.2	Charge-air coolant - Change	108		
7.9.3	Charge-air coolant - Draining	109		
7.9.4	Charge-air coolant - Filling	110		
7.9.5	Charge-air coolant pump - Relief bore check	112		
7.10	Belt Drive	113		
7.10.1	Coolant pump - Drive belt replacement	113		
7.11	Battery-Charging Generator	115		
7.11.1	Battery-charging generator - Belt tensioner and diverter pulley replacement	115		
7.11.2	Battery-charging generator - Drive belt removal and installation	117		
7.12	Drive Systems, Driving End and Free End (Coupling)	118		
7.12.1	Coupling - Checking (radial / axial) play	118		
7.13	Wiring (General) for Engine/Gearbox/Unit	119		
7.13.1	Engine cabling - Check	119		

DCL-ID: 0000029795 - 003

7.14 Accessories for (Electronic) Engine Governor / Control System	120	8.2 MTU contact persons/service partners	129
7.14.1 Injector functions	120	9 Appendix B	
7.14.2 Engine governor and connectors - Cleaning	121	9.1 Special Tools	130
7.14.3 Engine governor - Checking plug-in connections	122	9.2 Index	134
7.14.4 NOx sensor - Replacement	123		
7.14.5 Lambda sensor - Replacement	125		
8 Appendix A			
8.1 Abbreviations	127		

1 Safety

1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

Replacing components with emission labels

Emission labels are attached to all MTU engines. These must remain on the engine throughout its operational life.

Engines used exclusively in land-based, military applications other than by US government agencies are excepted from this proviso.

Please note the following when replacing components with emission labels:

- Appropriate emission labels must be affixed on spare parts.
- Emission labels may not be transferred from old components to new ones.
- Emission labels on old components must be removed and destroyed.

1.2 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Personnel must receive instruction on product handling and maintenance on the basis of this manual with a special emphasis on safety requirements and warnings.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. safety footwear, ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Transportation

Transportation

Only use the lifting eyes provided to lift the engine.

Only use transport and lifting devices approved by MTU.

Take the engine's center of gravity into account.

Lift engines by approx. 10 mm and verify that the lifting ropes / chains between engine and lifting equipment run vertically or in accordance with the specifications on the installation drawing.

If this is not the case, the lifting equipment must be re-adjusted.

The engine must only be transported in installation position, max. permissible diagonal pull 10°.

If the engine is supplied with special aluminum foil packing, lift the engine at the lifting eyes of the bearing pedestal or use a means of transportation which is appropriate for the given weight (forklift truck).

Setting the engine down after transport

Only set down engine on a firm, level surface.

Make sure that the consistency and load-bearing capacity of the ground or support surface is adequate.

Never set an engine down on the oil pan unless expressly authorized to do so by MTU on a case-to-case basis .

1.4 Safety regulations for startup and operation

Safety requirements for startup

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

When putting the product into operation, always ensure that

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- Keep clear of the service room during the first operating hours. Hazardous gases may occur as a result of the combustion of paints or oils.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated (e.g. +/- polarity, direction).

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Safety requirements for operation

The operator must be familiar with the controls and displays.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

The procedures for emergencies, in particular, emergency stop, must be practiced regularly.

The following steps must be taken if a malfunction of the system is detected or reported by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond to the emergency appropriately, e.g. execute an emergency stop.

Operation

Do not remain in the operating room when the product is running for any longer than absolutely necessary.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binder agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Observe the safety instructions for these devices.

1.5 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collecting vessels of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- With hydraulic starting system: shut off supply line.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock out circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when air starters are fitted.

Disconnect the control equipment from the product.

Use special tools if they are specified for the relevant work.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. They may only be installed after painting the engine or must be covered before painting work is carried out.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down. Use the specified lifting equipment for all components.

Never use lines for climbing.

Keep fuel injection lines and connections clean.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanness (e.g. components carrying oil, fuel, or air).

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Avoid damaging lines, particularly the fuel lines.

TIM-10: 0000040535 - 008