

Operation and Maintenance Manual

Diesel engine-generator sets

DP00365D5S

DP00400D5S

DS00400D5S

DS00440D5S

Application groups 3B, 3D

Built in Europe

Control version 1

SS180012/02E



System designation	Engine model	Application group
DP00365D5S	8V1600G10F	3B, Continuous operation, variable
DP00400D5S	8V1600G20F	3B, Continuous operation, variable
DS00400D5S	8V1600G70F	3D, Short-term operation, fuel stop
DS00440D5S	8V1600G80F	3D, Short-term operation, fuel stop

Table 1: Applicability

Preface

This Operation & Maintenance Manual provides general instructions for operating your MTU Onsite Energy engine-generator set properly. It is essential that every person who works on or with the engine-generator set be completely familiar with the contents of this manual and that he/she carefully follows the instructions contained herein.

Each operation and maintenance may require some modification of the suggested guidelines in this manual. They must be consistent with locally applicable standards and take into consideration safety guidelines and measures.

Following this guide will result in an efficient and reliable installation.

Carefully follow all procedures and safety precautions to ensure proper equipment operation and to avoid bodily injury. Read and follow the Safety section at the beginning of this manual.

All instructions and diagrams have been checked for accuracy and simplicity of application, however, the skills of the operator are most important. MTU Onsite Energy does not guarantee the result of any operation contained in this manual nor can MTU Onsite Energy assume responsibility for any injury or damage to property. Persons engaging in operating do so entirely at their own risk.

In this publication the manufacturer of the engine-generator set is known as MTU Onsite Energy.

Table of Contents

1 Safety		2.8.2 Exhaust silencer	65
1.1 Important requirements for all products	7	2.9 Cooling System	67
1.2 Personnel and organizational requirements	8	2.9.1 Cooling system	67
1.3 Safety requirements for startup and operation	9	2.9.2 Coolant cooler	69
1.4 Safety requirements for maintenance and repair work	10	2.9.3 Preheater - Mounting location	71
1.5 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	13	2.9.4 Preheater	72
1.6 Standards for safety notices in the text	15	2.10 Electrical System	74
		2.10.1 Starter battery	74
		2.10.2 Battery charger	76
		2.10.3 Circuit breaker	78
		2.11 Base and mounting system	81
		2.12 Enclosure	82
2 Functional Description		3 Technical Data	
2.1 Chapter overview	16	3.1 Technical data DP00365D5S (fuel optimized)	85
2.2 Engine-Generator Set	17	3.2 Technical data DP00365D5S (exhaust optimized)	87
2.2.1 Engine-generator set - General information	17	3.3 Technical data DP00400D5S (fuel optimized)	89
2.2.2 Engine-generator set - Scope of supply	19	3.4 Technical data DP00400D5S (exhaust optimized)	91
2.3 Engine	22	3.5 Technical data DS00400D5S (fuel optimized)	93
2.3.1 MTU Series 1600 GxO engine	22	3.6 Technical data DS00440D5S (fuel optimized)	95
2.3.2 Sensors and actuators	24		
2.3.3 Engine side and cylinder designations	26	4 Transport	
2.3.4 Firing order	27	4.1 Transport	97
2.4 Generator	28	5 Operation	
2.4.1 Generator - General information	28	5.1 Chapter overview	99
2.4.2 Digital voltage regulator DVR2000E+	31	5.2 Lockout/tagout procedure	100
2.5 Monitoring and Control	35	5.3 Unlocking procedure	103
2.5.1 Control version 1	35	5.4 Putting the engine-generator set into operation	105
2.5.2 Terminal box	36	5.5 Start	108
2.5.3 Smart Connect	37	5.6 Stop	109
2.6 Fuel System	39	5.7 Emergency stop	110
2.6.1 Fuel system	39	5.8 Exercising checks	111
2.6.2 Fuel prefilter - Mounting location	41	5.9 Putting the engine-generator set out of operation	113
2.6.3 Fuel prefilter	42		
2.6.4 Fuel prefilter with water separator - Mounting location	44	6 Troubleshooting	
2.6.5 Fuel prefilter with water separator (single)	46	6.1 Chapter overview	114
2.6.6 Fuel prefilter with water separator (double)	48	6.2 Troubleshooting by symptoms	115
2.6.7 Fuel cooler - Mounting location	50		
2.6.8 Fuel cooler	51		
2.6.9 Day tank	52		
2.6.10 Sub-base fuel tank	54		
2.7 Air System	56		
2.7.1 Air system	56		
2.7.2 Air filter	58		
2.7.3 Heavy duty air filter - Mounting location	60		
2.7.4 Heavy duty air filter	61		
2.8 Exhaust System	63		
2.8.1 Exhaust system	63		

6.3 Engine Fault Codes	120	8.5 Fuel System	200
6.3.1 Fault codes on Smart Connect display	120	8.5.1 Fuel prefilter with water separator (double) - Differential pressure check	200
6.3.2 List of MTU fault codes in numerical order (ADEC-ECU8)	121	8.5.2 Fuel prefilter - Draining overview	201
7 Maintenance		8.5.3 Fuel prefilter - Draining	202
7.1 Maintenance task reference table [QL1]	165	8.5.4 Fuel prefilter with water separator - Draining	203
8 Task Description		8.5.5 Fuel prefilter - Replacement overview	204
8.1 Chapter overview	166	8.5.6 Fuel prefilter - Replacement	205
8.2 Engine-Generator Set	167	8.5.7 Fuel prefilter with water separator - Filter element replacement	206
8.2.1 Engine-generator set - Test run	167	8.6 Air System	208
8.3 Engine	168	8.6.1 Service indicator - Signal ring position check	208
8.3.1 Engine - Barring with starting system	168	8.6.2 Air filter - Replacement	209
8.3.2 Valve clearance - Check and adjustment	169	8.6.3 Air filter - Removal and installation	210
8.3.3 Cylinder head cover - Removal and installation	172	8.6.4 Heavy duty air filter - Removal and installation	211
8.3.4 Fuel system - Venting	173	8.7 Cooling System	212
8.3.5 Fuel filter - Replacement	174	8.7.1 Coolant cooler - Check for leaks and contamination	212
8.3.6 Engine oil - Level check	175	8.7.2 Coolant cooler - Core face cleaning	213
8.3.7 Engine oil - Change	176	8.7.3 Preheater - Coolant line check	215
8.3.8 Engine oil filter - Replacement	178	8.7.4 Preheater - Heating element housing wiring check	216
8.3.9 Engine coolant - Level check	179	8.8 Electrical System	217
8.3.10 Engine coolant - Change	180	8.8.1 Circuit breaker - Check and function test	217
8.3.11 Engine coolant - Draining	181	9 Appendix A	
8.3.12 Engine coolant - Filling	183	9.1 Abbreviations	219
8.3.13 Engine coolant pump - Relief bore check	185	9.2 Conversion tables	222
8.3.14 Drive belt - Adjustment	186	9.3 Glossary	226
8.3.15 Drive belt - Condition check	187	9.4 MTU contact persons/service partners	242
8.3.16 Drive belt - Tension check	188	10 Appendix B	
8.3.17 Drive belt - Replacement	190	10.1 Special Tools	243
8.3.18 Engine wiring - Check	192	10.2 Consumables	246
8.3.19 Engine governor and connectors - Cleaning	193	10.3 Index	247
8.3.20 Engine governor - Checking plug connections	194		
8.4 Generator	195		
8.4.1 Generator - Check	195		
8.4.2 Generator - Wiring check	196		
8.4.3 Generator - Greasing antifriction bearing	197		
8.4.4 Generator mounting securing screws - Security check	199		

1 Safety

1.1 Important requirements for all products

Nameplate

The product is identified by a nameplate, model designation or serial number which must match the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

General information

This product may pose a risk of injury or damage in the following cases:

- Improper use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications
- Noncompliance with the safety instructions and warning notices

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine management/parameters)
- In compliance with all safety regulations and in accordance with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use shall be considered non-intended. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Changes or modifications

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

1.2 Personnel and organizational requirements

Organizational measures of the operator

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Use this manual as a basis for instructing personnel on product operation and repair, whereby the safety-relevant instructions, in particular, must be read and understood.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only.

- Training at the Training Center of the manufacturer
- Qualified personnel specialized in mechanical and plant engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Working clothes and personal protective equipment

Wear proper protective clothing for all work.

When working, always wear the necessary personal protective equipment (e.g. ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Safety requirements for startup and operation

Safety requirements for startup

The product must be installed and accepted in accordance with manufacturers' specifications prior to initial startup.

All the requisite regulatory approvals must have been granted and all startup requirements fulfilled prior to initial startup.

Whenever the product is started, always ensure that:

- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- Wearers of cardiac pacemakers or other active medical implants are well clear.
- The operating room is adequately ventilated.
- Exhaust pipework is leak-tight and routed to atmosphere.
- Battery terminals, generator terminals and cables are guarded to preclude accidental contact.
- All personnel is clear of the danger zone represented by moving parts.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Safety requirements for operation

The operator must be familiar with the controls and displays.

The operator must be aware of the consequences of any operations he/she performs.

During operation, the display instruments and monitoring units must be constantly observed in regard of present operating status, limit value violation and warning or alarm messages.

Malfunctions and emergency stop

Emergency procedures, in particular emergency stop, must be practiced on a regular basis.

Take the following steps if a system malfunction is detected or signaled by the system:

- Inform the duty supervisor(s).
- Evaluate the message.
- Respond to the emergency stop appropriately, e.g. execute an emergency stop.

Operation

Do not stay in the operating room when the product is running unless absolutely necessary and then as briefly as possible.

Keep a safe distance away from the product whenever possible. Do not touch the product unless expressly instructed to do so.

Do not inhale exhaust gases emitted by the product.

Ensure that the following requirements have been fulfilled before starting the product:

- Ear protectors are worn.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

Some components are live (high voltage) when electrical equipment is in operation.

Observe the safety instructions for these appliances.

1.4 Safety requirements for maintenance and repair work

Safety requirements before commencing maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50°C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collection vessels with a sufficient filling volume.

Ensure that the operating room is adequately ventilated when changing the oil or working on the fuel system.

Do not perform maintenance or repair work when the product is running unless:

- expressly instructed to do so.
- the product is running in the low load range and only for as long as necessary to complete the task.

Lock-out the product to preclude undesired starting, e.g. start interlock.

Tag-out the product with a “Do Not Start” sign in the operation room or on the control facility.

Disconnect the battery. Lock the contactor.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control facility from the product.

For starters with pinions made of copper-beryllium alloy:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the interior of the flywheel housing with a class H dust extractor.
- Observe the safety data sheet.

Safety requirements during maintenance and repair work

Take special care when removing vent plugs or plug screws from the product. Hold a cloth over the screw or plug to prevent discharge of highly pressurized liquids.

Take care when draining hot fluids and lubricants (risk of burning).

Use suitable and calibrated tools only. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies and/or installations which are properly secured.

Never climb up on the lines.

Keep fuel injection lines and connections clean.

Always seal connections with caps or covers if a line is removed or opened.

Fit new seals when re-installing lines.

Avoid damaging lines, particularly the fuel lines.

Ensure that all retainers and dampers are installed correctly.

Ensure that all fuel injection and pressurized oil lines are installed with enough clearance to prevent contact with other components. Never route fuel or oil lines in the vicinity of hot components.

Do not touch elastomeric seals (e.g. Viton sealing rings) with your bare hands if they have a carbonized or resinous appearance.

Observe the cooling time for components which have been heated for installation or removal (risk of burning!).

Always use suitable ladders and work platforms when working above head-height. Ensure that components or assemblies are placed on stable surfaces.