

Operating Instructions

Diesel engine
6R1600M20x

MS15029/01E



Power. Passion. Partnership.

Engine model	kW/cyl.	Hz	rpm	Application group
6R1600M20F	44.8 kW/cyl.	50 Hz	1500	3A, continuous operation, unrestricted
6R1600M20S	53.8 kW/cyl.	60 Hz	1800	3A, continuous operation, unrestricted

Table 1: Applicability

Table of Contents

1 Safety		5 Maintenance	
1.1 Important provisions for all products	5	5.1 Maintenance task reference table [QL1]	53
1.2 Personnel and organizational requirements	7		
1.3 Safety regulations for startup and operation	8	6 Troubleshooting	
1.4 Safety regulations for maintenance and repair work	10	6.1 Troubleshooting	54
1.5 Fire prevention and environmental protection, fluids and lubricants, auxiliary materials	13	6.2 Engine governor ECU9 - Fault messages	57
1.6 Auxiliary materials, fire prevention and environmental protection	15		
1.7 Standards for safety notices in the text	17	7 Task Description	
1.8 Transport	18	7.1 SOLAS	67
		7.1.1 Installation locations for SOLAS shielding	67
2 General Information		7.1.2 SOLAS shielding as per MTN 5233 - Installation	69
2.1 Engine side and cylinder designations	19	7.1.3 Adhesive tape for SOLAS shielding - Application	70
2.2 Product description	20	7.2 Engine	71
2.3 Engine overview	23	7.2.1 Engine - Barring manually	71
2.4 Sensors and actuators - Overview	25	7.2.2 Engine - Barring with starting system	73
		7.2.3 Engine - Test run	74
3 Technical Data		7.3 Crankcase Breather	75
3.1 Engine data 6R1600M20F, 6R1600M20S, engine-mounted heat exchanger, IMO Tier 2	29	7.3.1 Crankcase breather - Fine oil mist separator replacement	75
3.2 Engine data 6R1600M20F, 6R1600M20S, remote heat exchanger, IMO Tier 2	33	7.4 Valve Drive	77
3.3 Engine data 6R1600M20S, engine-mounted heat exchanger, EPA Tier 3	36	7.4.1 Valve clearance - Check and adjustment	77
3.4 Engine data 6R1600M20S, remote heat exchanger, EPA Tier 3	39	7.4.2 Cylinder head cover - Removal and installation	79
3.5 Firing order	42	7.5 Injector	82
3.6 Engine - Main dimensions	43	7.5.1 Injector - Replacement	82
		7.5.2 Injector - Removal and installation	83
4 Operation		7.6 Fuel System	88
4.1 Putting the engine into operation after extended out-of-service periods (>3 months)	44	7.6.1 Fuel system - Venting	88
4.2 Putting the engine into operation after scheduled out-of-service-period	45	7.7 Fuel Filter	89
4.3 Engine start in manual operation (trials)	46	7.7.1 Fuel filter - Replacement	89
4.4 Safety system - Override	47	7.8 Air Filter	92
4.5 Operational checks	48	7.8.1 Air filter - Replacement	92
4.6 Engine stop in manual operation (trials)	49	7.8.2 Air filter - Removal and installation	93
4.7 Emergency stop	50	7.9 Air Intake	94
4.8 After stopping the engine - Engine remains ready for operation	51	7.9.1 Service indicator - Signal ring position check	94
4.9 After stopping engine - Putting engine out of operation	52	7.10 Lube Oil System, Lube Oil Circuit	95
		7.10.1 Engine oil - Level check	95
		7.10.2 Engine oil - Change	97
		7.11 Oil Filtration / Cooling	98
		7.11.1 Engine oil filter - Replacement	98
		7.12 Coolant System, General, High-Temperature Circuit	102
		7.12.1 Engine coolant - Level check	102

7.12.2	Engine coolant - Change	103	7.16.1	Engine governor and connector - Cleaning	117
7.12.3	Engine coolant - Draining	104	7.16.2	Engine governor - Checking plug-in connections	118
7.12.4	Engine coolant - Filling	105			
7.12.5	Engine coolant pump - Relief bore check	107	7.17	Engine Mounting / Support	119
7.13	Low-Temperature Circuit	108	7.17.1	Engine mounting - Check	119
7.13.1	Charge-air coolant pump - Relief bore check	108			
7.14	Belt Drive	109	8	Appendix A	
7.14.1	Drive belt - Condition check	109	8.1	Abbreviations	121
7.14.2	Belt tensioner - Check	110	8.2	MTU contact persons/service partners	123
7.14.3	Drive belt - Replacement	111			
7.14.4	Belt tensioner - Tensioning element and tensioning roller replacement	113	9	Appendix B	
7.15	Wiring (General) for Engine/Gearbox/Unit	116	9.1	Special Tools	124
7.15.1	Engine cabling - Check	116	9.2	Index	131
7.16	Accessories for (Electronic) Engine Governor / Control System	117			

1 Safety

1.1 Important provisions for all products

Nameplate

The product is identified by nameplate, model designation or serial number and must match with the information on the title page of this manual.

Nameplate, model designation or serial number can be found on the product.

All EU-certified engines delivered by MTU come with a second nameplate. When operating the machine in the EU: The second nameplate must be affixed in a prominent position as described in the accompanying specifications.

General information

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Modifications or conversions
- Noncompliance with the safety instructions and warning notices

Correct use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/MTU contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (including engine control/parameters)
- In compliance with all safety regulations and in adherence with all warning notices in this manual
- With maintenance work performed in accordance with the (→ Maintenance Schedule) throughout the useful life of the product
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair
- By contracting only workshops authorized by the manufacturer to carry out repair and overhaul

Any other use is considered improper use. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

Emission regulations and emission labels

Responsibility for compliance with emission regulations

Modification or removal of any mechanical/electronic components or the installation of additional components including the execution of calibration processes that might affect the emission characteristics of the product are prohibited by emission regulations. Emission control units/systems may only be maintained, exchanged or repaired if the components used for this purpose are approved by the manufacturer.

Noncompliance with these regulations will invalidate the design type approval issued by the emissions regulation authorities. The manufacturer does not accept any liability for violations of the emission regulations. The maintenance schedules of the manufacturer must be observed over the entire life cycle of the product.

Replacing components with emission labels

Emission labels are attached to all MTU engines. These must remain on the engine throughout its operational life.

Engines used exclusively in land-based, military applications other than by US government agencies are excepted from this proviso.

Please note the following when replacing components with emission labels:

- Appropriate emission labels must be affixed on spare parts.
- Emission labels may not be transferred from old components to new ones.
- Emission labels on old components must be removed and destroyed.

1.2 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair and transport personnel at all times.

Personnel must receive instruction on product handling and maintenance on the basis of this manual with a special emphasis on safety requirements and warnings.

This is particularly important in the case of personnel who only occasionally perform work on or around the product. This personnel must be instructed repeatedly.

Personnel requirements

All work on the product shall be carried out by trained and qualified personnel only:

- Training at the Training Center of the manufacturer
- Technical personnel from the areas mechanical engineering, plant construction and electrical engineering

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair and transport.

Personnel must not be under the influence of alcohol, drugs or strong medication.

Work clothing and personal protective equipment

When working, always wear the necessary personal protective equipment (e.g. safety shoes, ear protectors, protective gloves, goggles, breathing protection). Observe the information on personal protective equipment in the respective activity description.

1.3 Safety regulations for startup and operation

Safety regulations for startup

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before putting the product into service. All necessary approvals must be granted by the relevant authorities and all requirements for initial startup must be fulfilled.

When putting the product into operation, always ensure that

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All safety equipment is in place.
- No persons wearing pacemakers or any other technical body aids are present.
- The service room is adequately ventilated.
- Keep clear of the service room during the first operating hours. Hazardous gases may occur as a result of the combustion of paints or oils.
- The exhaust system is leak-tight and that the gases are vented to atmosphere.
- Protect battery terminals, generator terminals or cables against accidental contact.
- Check that all connections have been correctly allocated (e.g. +/- polarity, direction).

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems are working properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the controls and displays.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be permanently observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

The procedures for emergencies, in particular, emergency stop, must be practiced regularly.

The following steps must be taken if a malfunction of the system is detected or reported by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond to the emergency appropriately, e.g. execute an emergency stop.

Operation

Do not remain in the operating room when the product is running for any longer than absolutely necessary.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear ear protectors.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binder agent.

Operation of electrical equipment

During operation of electrical devices, certain elements of these devices are live/under high voltage.

Observe the warning information applicable to the devices.

1.4 Safety regulations for maintenance and repair work

Safety regulations prior to maintenance and repair work

Have maintenance or repair work carried out by qualified and authorized personnel only.

Allow the product to cool down to less than 50 °C (risk of explosion for oil vapors, fluids and lubricants, risk of burning).

Relieve pressure in fluid and lubricant systems and compressed-air lines which are to be opened. Use suitable collecting vessels of adequate capacity to catch fluids and lubricants.

When changing the oil or working on the fuel system, ensure that the service room is adequately ventilated.

Never carry out maintenance and repair work with the product in operation, unless:

- It is expressly permitted to do so following a written procedure.
- The product is running in the low load range and only for as long as absolutely necessary.

Lock-out the product to preclude undesired starting, e.g.

- Start interlock
- Key switch
- With hydraulic starting system: shut off supply line.

Attach "Do not operate" sign in the operating area or to control equipment.

Disconnect the battery. Lock out circuit breakers.

Close the main valve on the compressed-air system and vent the compressed-air line when pneumatic starters are fitted.

Disconnect the control equipment from the product.

Use special tools if they are specified for the relevant work.

Elastomer components (e.g. engine mounts, damping elements, couplings and V-belts) must not be painted. They may only be installed after painting the engine or must be covered before painting work is carried out.

The following applies to starters with copper-beryllium alloy pinions:

- Wear a respirator mask (filter class P3). Do not blow out the interior of the flywheel housing or the starter with compressed air. Clean the flywheel housing inside with a class H dust extraction device.
- Observe the safety data sheet.

Safety regulations during maintenance and repair work

Take special care when removing ventilation or plug screws from the product. Cover the screw or plug with a rag to prevent fluids escaping under pressure.

Take care when draining hot fluids and lubricants (risk of burning).

Use only proper and calibrated tools. Observe the specified tightening torques during assembly or disassembly.

Carry out work only on assemblies or plants which are properly secured.

Make sure components or assemblies are placed on stable surfaces. Adopt suitable measures to avoid that components/tools fall down. Use the specified lifting equipment for all components.

Never use the product as a climbing aid.

When working high on the equipment, always use suitable ladders and work platforms. Never work on engines or components that are held in place by lifting equipment.

Keep fuel injection lines and connections clean.

Carry out appropriate cleaning procedures to clean and inspect components requiring special cleanness (e.g. components carrying oil, fuel, or air).