



Operating Instructions

Diesel engine-generator set
mtu 10V1600 DS500 / DG10V1600A1I
mtu 10V1600 DS540 / DG10V1600A2I
mtu 12V1600 DS650 / DG12V1600A1I
mtu 12V1600 DS715 / DG12V1600A2I
Application groups 3B, 3D, 3E and 3F

Controller AGC-4

SS180188/00E

System designation	Engine model	Application group
mtu 10V1600 DS500 / DG10V1600A1I	10V1600G10F	3B, continuous service, variable load, ICXN
mtu 10V1600 DS540 / DG10V1600A2I	10V1600G20F	3B, continuous service, variable load, ICXN
mtu 12V1600 DS650 / DG12V1600A1I	12V1600G10F	3B, continuous service, variable load, ICXN
mtu 12V1600 DS715 / DG12V1600A2I	12V1600G20F	3B, continuous service, variable load, ICXN
mtu 10V1600 DS500 / DG10V1600A1I	10V1600G70F	3D, emergency standby power, IFN
mtu 10V1600 DS540 / DG10V1600A2I	10V1600G80F	3D, emergency standby power, IFN
mtu 12V1600 DS650 / DG12V1600A1I	12V1600G70F	3D, emergency standby power, IFN
mtu 12V1600 DS715 / DG12V1600A2I	12V1600G80F	3D, emergency standby power, IFN
mtu 10V1600 DS500 / DG10V1600A1I	10V1600G10F	3E, emergency service, ICXN
mtu 10V1600 DS540 / DG10V1600A2I	10V1600G20F	3E, emergency service, ICXN
mtu 12V1600 DS650 / DG12V1600A1I	12V1600G10F	3E, emergency service, ICXN
mtu 12V1600 DS715 / DG12V1600A2I	12V1600G20F	3E, emergency service, ICXN
mtu 10V1600 DS500 / DG10V1600A1I	10V1600G10F	3F, heavy duty for DCP, unrestricted, ICXN
mtu 10V1600 DS540 / DG10V1600A2I	10V1600G20F	3F, heavy duty for DCP, unrestricted, ICXN
mtu 12V1600 DS650 / DG12V1600A1I	12V1600G10F	3F, heavy duty for DCP, unrestricted, ICXN
mtu 12V1600 DS715 / DG12V1600A2I	12V1600G20F	3F, heavy duty for DCP, unrestricted, ICXN

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface			
1.1	Preface	7		
2	Safety			
2.1	Important provisions for all products	8		
2.2	Intended use of engine-generator sets	9		
2.3	Personnel and organizational requirements	11		
2.4	Safety regulations for commissioning and operation	12		
2.5	Safety regulations for assembly, maintenance, and repair work	14		
2.6	Fire and environmental protection, indirect materials	18		
2.7	Standards for warning messages in the text and highlighted information	21		
2.8	Safety signs and markings	22		
2.9	Safety signs on engine-generator set - Overview	27		
2.10	Protective devices on engine-generator set - Overview	34		
3	Transport			
3.1	Transport	35		
3.2	Tie-down instructions	37		
4	General Information			
4.1	Data acquisition and data transmission	39		
5	Functional Description			
5.1	Engine-Generator Set	40		
5.1.1	Engine-generator set - Application groups	40		
5.1.2	Engine-generator set - Nameplate and designation	42		
5.1.3	Engine-generator set - Standard scope of delivery	45		
5.1.4	Engine-generator set - Optional scope of delivery	48		
5.2	Engine	51		
5.2.1	Engine - Overview	51		
5.2.2	Engine side and cylinder designations	52		
5.2.3	Sensors - Overview	53		
5.2.4	Firing order	55		
5.3	Generator	56		
5.3.1	Generator - General information	56		
5.3.2	Voltage regulator D350	58		
5.4	Monitoring and Control	59		
5.4.1	Isolated operation (control version 2)	59		
5.4.2	Isolated Operation with Automatic Transfer Switch (control version 3a)	60		
5.4.3	Isolated operation with two electrically locked circuit breakers (control version 3b)	62		
5.4.4	Isolated parallel operation (control version 4)	64		
5.4.5	Temporary mains parallel operation (control version 5)	66		
5.4.6	Permanent mains parallel operation with certification acc. to VDE 4110 (control versions 6a and 6b)	68		
5.4.7	Continuous mains parallel operation with several engine-generator sets (control version 7)	70		
5.4.8	Control cabinet with AGC-4 controller	72		
5.4.9	Control cabinet acc. to VDE 4110	74		
5.4.10	AGC-4 controller	76		
5.4.11	Smart Connect	79		
5.5	Fuel System	81		
5.5.1	Fuel system with common-rail injection	81		
5.5.2	Fuel prefilter - Installation position	83		
5.5.3	Fuel prefilter	84		
5.5.4	Fuel prefilter with water separator	86		
5.6	Charge-Air System and Exhaust System	88		
5.6.1	Charge-air and exhaust system	88		
5.6.2	Air filter	90		
5.6.3	Heavy-duty air filter	92		
5.6.4	Exhaust silencer	95		
5.7	Lube Oil System	96		
5.7.1	Lube oil system	96		
5.7.2	Lube oil extraction pump	97		
5.8	Cooling System	98		
5.8.1	Cooling system	98		
5.8.2	Preheater (2.5 kW)	100		
5.9	Electrical System	102		
5.9.1	Starter battery	102		
5.9.2	Battery charger	104		
5.9.3	Battery disconnecter	106		
6	Technical Data			
6.1	Reference tables for technical data	107		
6.2	Technical data mtu 10V1600 DS500, application group 3B	108		
6.3	Technical data mtu 10V1600 DS540, application group 3B	110		
6.4	Technical data mtu 12V1600 DS650, application group 3B	112		
6.5	Technical data mtu 12V1600 DS715, application group 3B	114		

6.6	Technical data mtu 10V1600 DS500, application group 3D	116	7.9.3	Engine-generator set – Start in Manual mode	161
6.7	Technical data mtu 10V1600 DS540, application group 3D	118	7.9.4	Engine-generator set – Shutdown in Manual mode	162
6.8	Technical data mtu 12V1600 DS650, application group 3D	120	7.10	Isolated Parallel Operation	163
6.9	Technical data mtu 12V1600 DS715, application group 3D	122	7.10.1	Isolated parallel operation – Overview	163
6.10	Technical data mtu 10V1600 DS500, application group 3E	124	7.10.2	Automatic start and shutdown	164
6.11	Technical data mtu 10V1600 DS540, application group 3E	126	7.10.3	Engine-generator set – Start in Manual mode	166
6.12	Technical data mtu 12V1600 DS650, application group 3E	128	7.10.4	Engine-generator set – Shutdown in Manual mode	167
6.13	Technical data mtu 12V1600 DS715, application group 3E	130	7.11	Temporary Mains Parallel Operation	168
6.14	Technical data mtu 10V1600 DS500, application group 3F	132	7.11.1	Temporary mains parallel operation – Overview	168
6.15	Technical data mtu 10V1600 DS540, application group 3F	134	7.11.2	Automatic start and shutdown	169
6.16	Technical data mtu 12V1600 DS650, application group 3F	136	7.11.3	Engine-generator set – Start in Manual mode	170
6.17	Technical data mtu 12V1600 DS715, application group 3F	138	7.11.4	Engine-generator set – Shutdown in Manual mode	171
7	Operation		7.12	Permanent Mains Parallel Operation	172
7.1	Chapter overview	140	7.12.1	Permanent mains parallel operation with certification acc. to VDE 4110 – Overview	172
7.2	Lockout/tagout procedures	141	7.12.2	Automatic start and shutdown	173
7.3	Unlocking procedure	143	7.12.3	Engine-generator set – Start in Manual mode	174
7.4	Preparations for putting into operation after extended out-of-service periods	145	7.12.4	Engine-generator set – Shutdown in Manual mode	175
7.5	Starting sequences – Overview	148	7.13	Permanent Mains Parallel Operation with Multiple Engine-Generator Sets	176
7.6	Shutdown sequences – Overview	149	7.13.1	Permanent mains parallel operation with multiple engine-generator sets – Overview	176
7.7	Isolated Operation	150	7.13.2	Automatic start and shutdown	177
7.7.1	Isolated operation – Overview	150	7.13.3	Engine-generator set – Start in Manual mode	179
7.7.2	Automatic start and shutdown	151	7.13.4	Engine-generator set – Shutdown in Manual mode	180
7.7.3	Engine-generator set – Start in Manual mode	152	7.14	Operational monitoring	181
7.7.4	Engine-generator set – Shutdown in Manual mode	153	7.15	Re-starting the engine following an automatic safety shutdown	182
7.8	Isolated Operation with Automatic Transfer Switch	154	7.16	Emergency shutdown	183
7.8.1	Isolated operation with Automatic Transfer Switch – Overview	154	7.17	After shutdown – Taking the engine-generator set out of operation	184
7.8.2	Automatic start and shutdown	155	8	Maintenance	
7.8.3	Engine-generator set – Start in Manual mode	156	8.1	Noncyclical maintenance tasks	185
7.8.4	Engine-generator set – Shutdown in Manual mode	158	8.2	Maintenance Schedule Task Reference Table [QL1]	186
7.9	Isolated Operation with Two Electrically Locked Circuit Breakers	159	9	Troubleshooting	
7.9.1	Isolated operation with two electrically locked circuit breakers – Overview	159	9.1	Chapter overview	188
7.9.2	Automatic start and shutdown	160	9.2	Smart Connect fault messages	189
			9.3	Smart Connect status displays	194
			9.4	ECU 8 fault messages	196

10 Task Description			
10.1 Chapter overview	211		
10.2 Acoustic Enclosure	212		
10.2.1 Acoustic enclosure - Check	212		
10.2.2 Acoustic enclosure - External contamination check	213		
10.2.3 Acoustic enclosure door - Checking seal	214		
10.2.4 Acoustic enclosure door - Checking hinges	215		
10.2.5 Grounding cable - Check	216		
10.2.6 Grounding cable - Continuity test	217		
10.3 Engine-Generator Set	218		
10.3.1 Engine-generator set - Test run	218		
10.4 Engine	219		
10.4.1 Engine - Barring with starting system	219		
10.5 Generator	220		
10.5.1 Leroy-Somer Generator	220		
10.5.1.1 Generator - Winding temperature check	220		
10.5.1.2 Generator - Cleaning air inlet and air outlet	221		
10.5.1.3 Generator - Cleaning terminal box and checking screw connections for secure seating	222		
10.5.1.4 Generator - Bearings securing screws check	223		
10.5.1.5 Generator - Check of protective equipment	225		
10.5.1.6 Generator - Diode cleaning	226		
10.5.1.7 Generator - Re-tightening securing screws of diodes	227		
10.5.1.8 Generator - Drying windings	228		
10.5.1.9 Generator - Polarization index check	230		
10.5.2 Generator mount - Measuring height of rubber element	231		
10.5.3 Generator mounting - Securing screw firm seating check	232		
10.5.4 Resilient mounts of generator mounting - Check	233		
10.6 Monitoring and Control	234		
10.6.1 Protective function (emergency stop button) - Check	234		
10.7 Belt Drive	235		
10.7.1 Drive belt - Condition check	235		
10.7.2 Drive belt - Tension check	236		
10.7.3 Drive belt - Replacement	238		
10.7.4 Drive belt - Adjustment	240		
10.8 Valve Drive	241		
10.8.1 Valve clearance - Check and adjustment	241		
10.8.2 Cylinder head cover - Removal and installation	244		
10.9 Fuel System	247		
10.9.1 Fuel system - Venting	247		
10.10 Fuel Filter	248		
10.10.1 Fuel filter - Replacement	248		
10.10.2 Fuel prefilter - Draining	249		
10.10.3 Fuel prefilter with water separator - Draining	250		
10.10.4 Fuel prefilter - Replacement	251		
10.10.5 Fuel prefilter with water separator - Replacement	252		
10.11 Charge-Air Cooling	253		
10.11.1 Intercooler - Checking condensate drain for coolant discharge and obstructions	253		
10.12 Air Filter	254		
10.12.1 Air filter - Replacement	254		
10.12.2 Air filter - Removal and installation	255		
10.12.3 Heavy-duty air filter - Removal and installation	256		
10.13 Air Intake	258		
10.13.1 Service indicator - Signal ring position check	258		
10.13.2 Heavy-duty air filter - Service indicator check	259		
10.14 Exhaust System	260		
10.14.1 Exhaust silencer - Condensate drain check	260		
10.15 Starting Equipment	261		
10.15.1 Starter - Condition check	261		
10.16 Lube Oil System, Lube Oil Circuit	262		
10.16.1 Engine oil - Level check	262		
10.16.2 Engine oil - Change	263		
10.16.3 Engine oil filter - Replacement	265		
10.17 Coolant Circuit, General, High-Temperature Circuit	266		
10.17.1 Engine coolant - Level check	266		
10.17.2 Engine coolant - Change	267		
10.17.3 Engine coolant - Draining	268		
10.17.4 Engine coolant - Filling	269		
10.17.5 Engine coolant pump - Relief bore check	271		
10.18 Cooling System	272		
10.18.1 Coolant cooler - External contamination and leak-tightness check	272		
10.18.2 Coolant cooler - Cleaning	273		
10.18.3 Fuel cooler - External contamination and leak-tightness check	275		
10.19 Preheater	276		
10.19.1 Preheater - Coolant line check	276		
10.19.2 Preheater - Replacement	277		
10.19.3 Preheater - Thermostat replacement	279		
10.20 Wiring (General) for Engine/Gearbox/Unit	280		
10.20.1 Engine cabling - Check	280		
10.21 Accessories for (Electronic) Engine Governor / Control System	281		
10.21.1 Engine governor and connectors - Cleaning	281		
10.21.2 Engine governor - Checking plug connections	282		
11 Appendix A			
11.1 Abbreviations		283	
11.2 Conversion tables		286	

11.3 Contact person/Service partner	290	12.3 Index	296
12 Appendix B		13 Appendix C	
12.1 Standard Tools and Special Tools	291	13.1 Safety Data Sheet – Valve Regulated Lead	
12.2 Consumables	295	Acid Batteries (VRLA)	303

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

Store these Operating Instructions where they can be accessed by all persons entrusted with operating or servicing this product.

Before starting any work, read these Operating Instructions carefully. For safe operation of the product, always follow all safety instructions and work instructions.

Local accident prevention regulations and general safety regulations for the area of application of the product also apply.

These Operating Instructions form part of the product and refer to the latest design version of the product at the time of publication. They are subject to modification to reflect technical enhancements. Actual product may vary from figures shown.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of engine-generator sets

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- As generating set, stationary applications, for on-site power generation (isolated operation), for power generation as mains backup system (standby power), as well as for mains parallel operation
- As generating set to produce electric power at the voltages / frequencies/ temperatures and the possible maximum power specified on the nameplate
- As generating set in closed rooms, which provide the required technical equipment, such as supply and exhaust air opening, exhaust pipe routing through the wall to the outside, and a fuel supply facility
- Within the admissible operating parameters in accordance with the (→ technical sales documents – product data – TVU data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and observance of all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques

The product shall not be operated in explosive atmospheres unless it fulfills the conditions for such use and an approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to use, ensure that the most recent version is available. The latest version can be found at:

- <http://www.mtu-solutions.com>

Reasonably foreseeable misuse

- The engine-generator set was not designed for outdoor usage.
- The engine-generator set was not designed for mobile applications.
- The engine-generator set must not be operated with fluids and lubricants which are not listed in the specifications.
- The engine-generator set was not designed for the usage as combined heat and power plant or in applications where special requirements apply, e.g. nuclear power plant, oil&gas, fracking.
- When the specified operating hours, i.e. the expected lifetime of the product, is exceeded, the need for maintenance is expected to increase.
- The engine-generator set shall not be operated at other voltages and frequencies than those specified on the nameplate.
- The total rated power consumption of all consumers connected to the engine-generator set shall not exceed the total output of the engine-generator set specified on the nameplate.

Without safety certification according to IBC or Eurocode8, it is not recommended to use engine-generator sets in regions with high seismic activity, with the influence coefficient being defined as 1.5.

If lower requirements apply, the seismic force can be estimated according to the FEMA 450 guide using the terms and definitions of DIN 4149 and of DIN EN 1998-1 (2010) respectively. If a_{gR} is lower than 0.39 m/s^2 , no proof of the seismic safety is required as per EN1998.

Modifications or conversions

Unauthorized changes to the product breach the conditions concerning its intended use and compromise safety.

Only modifications or conversions expressly authorized by the manufacturer are regarded as compliant in this sense. The manufacturer shall not be held liable for any damage resulting from unauthorized modifications or conversions.