



Operating Instructions

PowerPack®
CAF Wales&Borders
EU Stage 5
RP06H1800C4-1IU
6H1800R86
Application group 2A

MA15608/01E

System designation	Engine model	Application group
RP06H1800C4-1IU	6H1800R86	2A, continuous operation, unrestricted

Table 1: Applicability

Rolls-Royce Solutions refers to Rolls-Royce Solutions GmbH or an affiliated company pursuant to § 15 AktG (German Stock Corporation Act) or a controlled company (joint venture), and Rolls-Royce Solutions Ruhstorf GmbH.

© Copyright Rolls-Royce Solutions

This publication is protected by copyright and may not be used in any way, whether in whole or in part, without the prior written consent of Rolls-Royce Solutions. This particularly applies to its reproduction, distribution, editing, translation, microfilming and storage and/or processing in electronic systems including databases and online services.

All information in this publication was the latest information available at the time of going to print. Rolls-Royce Solutions reserves the right to change, delete or supplement the information provided as and when required.

Table of Contents

1	Preface		8	Maintenance	
1.1	Preface	5	8.1	Unscheduled maintenance tasks	52
2	Safety		8.2	Maintenance task reference table [QL1]	53
2.1	Important provisions for all products	6	9	Troubleshooting	
2.2	Intended use of all products	7	9.1	Troubleshooting	55
2.3	Personnel and organizational requirements	8	9.2	Fault indication - Service and Automation Module (SAM)	58
2.4	Safety regulations for commissioning and operation	9	10	Task Description	
2.5	Safety regulations for assembly, maintenance, and repair work	11	10.1	PowerPack®	73
2.6	Fire and environmental protection, indirect materials	15	10.1.1	PowerPack® - Cleaning	73
2.7	Standards for warning messages in the text and highlighted information	18	10.1.2	Radiator - Cleaning	75
3	Transport		10.1.3	PowerPack® - Barring manually	79
3.1	Transport	19	10.1.4	PowerPack® - Test run	80
4	General Information		10.1.5	PowerPack® - Check	81
4.1	Engine side and cylinder designations	21	10.1.6	Operating fluids - Level check	82
4.2	Data acquisition and data transmission	22	10.1.7	Elastomer bellows / hose lines - Check	83
4.3	PowerPack® - Overview	23	10.1.8	Elastomer bellows / hose lines - Replacement	84
4.4	Tightening specifications for screws, nuts and bolts	25	10.1.9	Hose lines - Replacement	87
5	Technical Data		10.1.10	Charge-air system - Retightening clamps	88
5.1	PowerPack® 6H1800R86	38	10.2	Crankcase Breather	90
5.2	Firing order	41	10.2.1	Vent line - Removal and installation	90
6	Service and Automation Module SAM		10.3	Valve Drive	91
6.1	Service and Automation Module (SAM) - Operation	42	10.3.1	Valve clearance - Check and adjustment	91
7	Operation		10.3.2	Cylinder head cover - Removal and installation	94
7.1	Operational monitoring	47	10.4	Fuel System	95
7.2	Preparation for startup (with PowerPack® installed) after out-of-service-periods (< 3 months)	48	10.4.1	Notes on HP fuel lines	95
7.3	Preparation for startup (with PowerPack® installed) after extended out-of-service-periods (>3 months)	49	10.4.2	HP fuel line - Replacement	96
7.4	PowerPack® - Starting	50	10.4.3	Leak-off fuel line - Removal and installation	99
7.5	PowerPack® - Shutdown	51	10.5	Injection Valve / Injector	101
			10.5.1	Injector - Pressure pipe neck replacement	101
			10.6	Injection Pump / HP Pump	104
			10.6.1	Injection pump - Replacement	104
			10.7	Fuel Filter	107
			10.7.1	Fuel prefilter - Filter element replacement	107
			10.7.2	Fuel filter - Replacement	109
			10.8	Charge-Air Cooling	110
			10.8.1	Intercooler - Condensate draining	110
			10.9	Air Filter	111
			10.9.1	Air filter - Replacement	111
			10.10	Air Intake	112
			10.10.1	Intake air pipework - Removal and installation	112

10.10.2	Air pipework from exhaust turbocharger to intercooler - Removal and installation	114	10.17.5	Cooling system - Pressure test	164
10.10.3	Air pipework from intercooler to cylinders - Removal and installation	116	10.17.6	Coolant expansion tank - Valve replacement	165
10.11	Exhaust Turbocharger	118	10.17.7	Cooling system - Check	166
10.11.1	Exhaust turbocharger - Replacement	118	10.17.8	Coolant - Sample extraction and analysis	168
10.11.2	Wastegate linkage and hose - Visual check	121	10.18	Belt Drive	169
10.12	Exhaust Pipework	123	10.18.1	Engine coolant pump belt drive - Check	169
10.12.1	Exhaust pipe - Removal and installation	123	10.18.2	Drive belt - Condition check	170
10.12.2	Exhaust flap - Check	125	10.18.3	Engine coolant pump - Checking belt tensioner and diverter pulley	171
10.13	Exhaust Gas Aftertreatment System	126	10.18.4	Engine coolant pump - Drive belt replacement	172
10.13.1	Reducing agent - Level check	126	10.18.5	Engine coolant pump drive belt - Removal and installation	173
10.13.2	Urea solution - Filling	127	10.18.6	Engine coolant pump - Belt tensioner and diverter pulley replacement	174
10.13.3	SCR related data - Reading out	128	10.18.7	Engine coolant pump belt drive - Belt tensioner replacement	175
10.13.4	Coolant and reducing agent lines - Replacement	129	10.18.8	Engine coolant pump belt drive - Diverter pulley replacement	176
10.13.5	Coolant and reducing agent hoses - Replacement	130	10.19	Drive Systems, Driving End and Free End (Coupling)	177
10.13.6	Diesel particulate filter (DPF) - Replacement	131	10.19.1	Coupling on free end (KGS) - Check	177
10.14	Starting Equipment	135	10.19.2	Coupling on hydraulic pump - Removal and installation	178
10.14.1	Starter - Check condition	135	10.19.3	Rubber element of generator coupling - Check	180
10.14.2	Starter - Replacement	136	10.19.4	Hydraulic motor of generator - Removal and installation	181
10.15	Lube Oil System, Lube Oil Circuit	138	10.19.5	Generator torsionally elastic coupling - Replacement	183
10.15.1	Engine oil level - Check	138	10.20	Gearbox / Transmission	185
10.15.2	Engine oil - Change	141	10.20.1	Transmission oil - Level check	185
10.15.3	Engine oil - Draining	142	10.20.2	Transmission oil - Change	187
10.15.4	Engine oil filter - Replacement	143	10.20.3	Transmission oil - Draining	188
10.15.5	Engine oil - Filling	145	10.20.4	Transmission oil filter - Replacement	189
10.15.6	Oil lines on exhaust turbocharger - Removal and installation	146	10.20.5	Transmission oil - Filling	191
10.16	Hydraulic System	148	10.21	Wiring (General) for Engine/Gearbox/Unit	193
10.16.1	Hydraulic system - Oil level check	148	10.21.1	Cabling - Check	193
10.16.2	Hydraulic system - Oil change	149	11	Appendix A	
10.16.3	Hydraulic system - Oil draining	150	11.1	Abbreviations	194
10.16.4	Hydraulic system - Oil filter replacement	152	11.2	Contact person/Service partner	197
10.16.5	Hydraulic system - Oil filling	154	12	Appendix B	
10.16.6	Hydraulic system - Air filter on oil tank replacement	155	12.1	Standard Tools and Special Tools	198
10.16.7	Hydraulic hoses - Replacement	156	12.2	Index	208
10.17	Coolant Circuit, General, High-Temperature Circuit	157			
10.17.1	Engine coolant - Level check	157			
10.17.2	Engine coolant - Change	158			
10.17.3	Engine coolant - Draining	159			
10.17.4	Engine coolant - Filling	163			

1 Preface

1.1 Preface

These Operating Instructions contain general instructions for the proper and safe operation of your product from the manufacturer Rolls-Royce Solutions.

2 Safety

2.1 Important provisions for all products

General

This product may pose a risk of injury or damage in the following cases:

- Incorrect use
- Operation, maintenance and repair by unqualified personnel
- Changes or modifications which are neither made nor authorized by the manufacturer
- Noncompliance with the safety instructions and warning notices

Nameplates

The product is identified by nameplate, model designation or serial number. This data must match the specifications in these instructions.

Nameplates, model designation or serial number can be found on the product.

All EU-certified engines delivered by Rolls-Royce Solutions come with a second nameplate. This second nameplate is delivered "loosely" with the engine. If the nameplate secured to the engine after installation in the vehicle/system is not visible without the removal of components, the system integrator must install the second nameplate in a clearly visible area on the vehicle/system.

Emissions regulations

Prior to operation, make sure that the latest version is used. The latest version can be found at:<http://www.mtu-solutions.com>

2.2 Intended use of all products

Intended use

The product is intended for use in accordance with its contractually-defined purpose as described in the relevant technical documents only.

Intended use entails operation:

- Within the permissible operating parameters in accordance with the (→ Technical data)
- With fluids and lubricants approved by the manufacturer in accordance with the (→ Fluids and Lubricants Specifications of the manufacturer)
- With preservation approved by the manufacturer in accordance with the (→ Preservation and Represervation Specifications of the manufacturer)
- With spare parts approved by the manufacturer in accordance with the (→ Spare Parts Catalog/Rolls-Royce Solutions contact/Service partner)
- In the original as-delivered configuration or in a configuration approved by the manufacturer in writing (also applies to engine control/parameters)
- In compliance with all safety regulations and in adherence with all safety and warning notices in this manual
- In compliance with the maintenance work and intervals specified in the (→ Maintenance Schedule) throughout the useful life of the product
- Work which requires communication with the control units must only be carried out with a diagnosis software or with tools approved by the manufacturer.
- In compliance with the maintenance and repair instructions contained in this manual, in particular with regard to the specified tightening torques
- With the exclusive use of technical personnel trained in commissioning, operation, maintenance and repair

The product must not be operated in explosive atmospheres unless the engine fulfills the conditions for such use and approval has been granted.

Any other use, particularly misuse, is considered as being contrary to the intended purpose. Such improper use increases the risk of injury and damage when working with the product. The manufacturer shall not be held liable for any damage resulting from improper, non-intended use.

The specifications of the manufacturer will be amended or supplemented as necessary. Prior to operation, make sure that the latest version is used. The latest version can be found at:

- <http://www.mtu-solutions.com>

Modifications or conversions

Unauthorized changes to the product represent a contravention of its intended use and compromise safety.

Changes or modifications shall only be considered to comply with the intended use when expressly authorized by the manufacturer. The manufacturer shall not be held liable for any damage resulting from unauthorized changes or modifications.

2.3 Personnel and organizational requirements

Organizational measures of the user/manufacturer

This manual must be issued to all personnel involved in operation, maintenance, repair, assembly, installation, or transportation.

Keep this manual handy in the vicinity of the product such that it is accessible to operating, maintenance, repair, assembly, installation, and transport personnel at all times.

Personnel must receive instruction on product handling and repair based on this manual. In particular, personnel must have read and understood the safety requirements and warnings before starting work.

This is important in the case of personnel who only occasionally perform work on or around the product. Such personnel must be instructed repeatedly.

Personnel requirements

All work on the product must be carried out by trained, instructed and qualified personnel only:

- Training at the Training Center of the manufacturer
- Qualified personnel from the areas mechanical engineering, plant construction, and electrical engineering and also for work with live parts

The operator must define the responsibilities of the personnel involved in operation, maintenance, repair, assembly, installation, and transport in writing.

Personnel shall not report for duty under the influence of alcohol, drugs or strong medication.

Clothing and personal protective equipment

Always wear appropriate personal protective equipment, e.g. safety shoes, ear protectors, protective gloves, goggles, breathing mask. Follow the instructions concerning personal protective equipment in the respective descriptions of the individual activities or the manufacturer's documentation included in the delivery.

When working on live components, in particular on electrical switchgear or on high-voltage component, wear special protective clothing according to IEC 61482.

Safe handling of Substances of Very High Concern pursuant to the REACH regulation (Registration, Evaluation, Authorization and restriction of CHemicals): We recommend wearing protective gloves at all times in order to reduce risk when working.

2.4 Safety regulations for commissioning and operation

Safety regulations for commissioning

Install the product correctly and carry out acceptance in accordance with the manufacturer's specifications before commissioning the product. All necessary approvals must be granted by the relevant authorities and all requirements for commissioning must be fulfilled.

Whenever the product is subsequently put into operation ensure that:

- All personnel is clear of the danger zone surrounding moving parts of the machine.
Electrically-actuated linkages may be set in motion when the Engine Control Unit (governor) is switched on.
- All maintenance and repair work has been completed.
- All loose parts have been removed from rotating machine components.
- All protective devices are in place.
- All lines bearing media are ready for operation.
- The walkways in the operating room are unobstructed and safe.
- No persons wearing pacemakers or any other technical body aids are present.
- Adequate ventilation of the operating room is ensured for any operating status.
- In the first few hours of operation, the product emits gases as a result of smoldering e.g. lacquers or oil. These gases may be hazardous to health. Always wear respiratory protection in the operating room during this period.
- The exhaust system is leak-tight and the gases are vented to atmosphere.
- The product is free of any damage, this applies in particular to lines and cabling.
- All components are properly grounded. Ground separately by means of a grounding stake as necessary.
- The power supply (mains plug) is always freely accessible to facilitate disconnecting the device or system from the power supply at any time.
- Battery terminals, generator terminals or cables are protected against accidental contact.
- All connections have been correctly allocated e.g. +/– polarity, fuel line/reducing agent line, supply/return.

Immediately after putting the product into operation, make sure that all control and display instruments as well as the monitoring, signaling and alarm systems work properly.

Smoking is prohibited in the area of the product.

Safety regulations during operation

The operator must be familiar with the control and display elements.

The operator must be familiar with the consequences of any operations performed.

During operation, the display instruments and monitoring units must be observed with regard to present operating status, violation of limit values and warning or alarm messages.

Malfunctions and emergency stop

Practice emergency procedures, especially emergency stopping, at regular intervals.

Take the following steps if any system malfunctions are detected or signaled by the system:

- Inform supervisor(s) in charge.
- Analyze the message.
- Respond by taking any necessary emergency action, e.g. emergency stop.

After a safety shutdown, the engine may only be started after the cause of the shutdown has been eliminated.

Contact Service if the root cause of the malfunction cannot be clearly identified.

Operation

Do not remain in the operating room when the product is running unless absolutely necessary. Keep your stay as short as possible.

Keep a safe distance away from the product if possible. Do not touch the product unless expressly instructed to do so following a written procedure.

Do not inhale the exhaust gases of the product.

The following requirements must be fulfilled before the product is started:

- Wear hearing protection.
- Mop up any leaked or spilled fluids and lubricants immediately or soak up with a suitable binding agent.

Operation of electrical equipment

When electrical equipment is in operation, certain components of these appliances are electrically live.

Follow the applicable operating and safety instructions when operating the devices and heed warnings at all times.