

STANDARD OPERATING PROCEDURE

Equipment: Centrifugal Pump P-101

Revision 4

Date: 15/01/2024

Approved by: Engineering Manager

SCOPE

This procedure covers routine maintenance and inspection of pump P-101.

SAFETY PRECAUTIONS

- Isolate all energy sources before beginning work
- Wear PPE at all times (gloves, safety glasses, hard hat)
- Verify zero-energy state before opening pump casing
- Ensure hot-work permit is obtained if welding is required

PROCEDURE

Step 1: Shut down pump P-101 using control panel HMI.

Step 2: Close suction valve SV-101 and discharge valve DV-101.

Step 3: Drain pump casing via drain valve.

Step 4: Inspect impeller for wear or damage.

Step 5: Check mechanical seal for leaks.

Step 6: Torque bolts to 80 Nm per updated specification (CHANGED from Rev 3).

Step 7: Reconnect and perform leak test at 80% operating pressure.

Step 8: Log maintenance record in CMMS system.

NOTE: Rev 4 updates bolt torque from 50 Nm to 80 Nm. Old specification is SUPERSEDED.

SIGN-OFF

Technician: _____ Date: _____

Supervisor: _____ Date: _____

REVISION HISTORY

Rev 4 | 15/01/2024 | CRITICAL: Updated bolt torque to 80 Nm (was 50 Nm)

Rev 3 | 10/06/2023 | Updated safety section

Rev 2 | 15/03/2022 | Added drain step

Rev 1 | 01/01/2021 | Initial release

EQUIPMENT TAGS REFERENCED

P-101, SV-101, DV-101, HV-204, FCV-301