

Installation and Setup Guide

TechMart Electronics | Document domain: technical

TechMart Account Setup

Download the TechMart app from the Play Store or App Store, or use techmart.example.com. Register with an email address or mobile number. A 6-digit OTP is sent for verification and is valid for 10 minutes. OTP SMS can be delayed on some networks - wait 60 seconds before requesting a resend, and note that requesting a resend invalidates the previous OTP.

If you do not receive an OTP after two attempts, switch to email verification from the same screen, or use 'Sign in with Google'.

NoteBook First-Time Setup

Charge for 30 minutes before first power-on. Press and hold the power button for 2 seconds. Follow the Windows out-of-box setup: select region, connect Wi-Fi, sign in with a Microsoft account, and set up fingerprint or PIN.

Run TechMart Update Assistant, pre-installed on the desktop, before anything else. It installs the current chipset, graphics, and firmware drivers. Setup requires an internet connection and takes 10 to 20 minutes.

The first boot may take up to 5 minutes and the fan may run loudly while Windows indexes files. This is expected and settles within the first hour of use.

Pulse Buds Pairing

Open the case near the device. The buds enter pairing mode automatically on first use, indicated by a flashing white LED. Select 'TechMart Pulse Buds' from the Bluetooth menu.

To pair to a new device later, place both buds in the case, keep the lid open, and hold the case button for 5 seconds until the LED flashes white again.

To factory reset, place both buds in the case, keep the lid open, and hold the case button for 15 seconds until the LED flashes red three times. Then remove the old pairing entry from your phone's Bluetooth settings before re-pairing, otherwise the stale bond will block reconnection.

SmartHome Device Setup

Install the TechMart Home app. Connect your phone to the 2.4 GHz Wi-Fi network you want the device to use - the app copies the credentials from the phone's current network, so joining a 5 GHz network at this step is the most common cause of setup failure.

Power the device on. Press and hold its reset button for 5 seconds until the LED blinks rapidly, which indicates pairing mode. In the app, tap Add Device, select the product, and enter the Wi-Fi password.

Setup fails most often because of: a 5 GHz network, a password containing special characters the device firmware rejects, MAC address filtering enabled on the router, AP isolation or client isolation enabled, or the device being more than 10 m from the router during setup.

SoundBar 300 Installation

Connect the SoundBar to the TV's HDMI eARC or ARC port with the supplied HDMI cable. Enable HDMI-CEC on the TV (named Anynet+ on Samsung, Bravia Sync on Sony, SIMPLINK on LG) and set the TV audio output to 'External speaker' or 'Receiver'.

The subwoofer pairs automatically within 30 seconds of both units being powered on. If the subwoofer LED keeps blinking, hold the PAIR button on its rear for 5 seconds with the SoundBar already on.

For wall mounting, use the supplied bracket and keep at least 5 cm of clearance below the TV. Do not enclose the SoundBar in a cabinet - it blocks the bass ports.