

User Manual and Troubleshooting

TechMart Electronics | Document domain: technical

Login and Password

To reset your password, go to the login page, click 'Forgot Password', enter your registered email, and follow the link sent to you. The reset link is valid for 30 minutes and can be used only once. Check your spam folder if the email has not arrived within 5 minutes.

Accounts lock for 30 minutes after 5 consecutive failed login attempts. The lock clears automatically; support cannot unlock it early. Resetting your password clears the lock immediately.

If you registered with 'Sign in with Google', your account has no TechMart password. Use the Google button rather than 'Forgot Password'. To add a password, sign in with Google, then go to Account, Security, Set Password.

Being logged out repeatedly is usually caused by browser settings that block cookies, an aggressive privacy extension, or the system clock being wrong by more than 5 minutes, which invalidates the session token.

Premium Not Activating After Payment

Premium normally activates within 5 minutes of payment. If it has not activated after 30 minutes but your bank shows the amount debited, the cause is almost always a payment webhook that did not reach our servers, so the payment succeeded but the entitlement was never provisioned.

First, fully sign out and sign back in - the entitlement is cached in your session token and a stale token shows Premium as locked even after provisioning succeeds. Force-close the app rather than just backgrounding it. On the web, hard refresh with Ctrl+Shift+R.

If it is still locked, contact support with the payment reference number from your bank statement. Support can reconcile the payment and provision Premium manually, usually within 2 hours. Do not pay a second time - duplicate payments are refunded but take 3 business days to reverse.

This is a joint billing and technical issue: the payment side is confirmed by the reference number, and the entitlement side is fixed by re-provisioning and clearing the session.

NoteBook Troubleshooting

Device will not power on: hold the power button for 15 seconds to force a hard reset, connect the original charger, and wait 15 minutes. A charging LED that does not light indicates a charger or port fault - test with a second USB-C PD charger of at least 65 W before booking a service visit.

Battery draining fast: check Windows Settings, System, Power and Battery, Battery Usage for apps consuming power in the background. Battery health below 80 percent after 800 charge cycles is normal wear and is not covered under warranty.

Overheating or loud fans: ensure the vents are not blocked, run TechMart Update Assistant to install the current thermal firmware, and check Task Manager for a process pinned at high CPU. Sustained fan noise on a new machine during Windows indexing is expected for the first hour.

Wi-Fi keeps disconnecting: update the Wi-Fi driver through TechMart Update Assistant, disable 'Allow the computer to turn off this device to save power' in the adapter's Device Manager properties, and switch the router band to 5 GHz where available.

Blue screen errors: note the STOP code shown on screen. Run Windows Update, run TechMart Update Assistant, and run 'sfc /scannow' from an elevated command prompt. Recurring blue screens with the same STOP code after these steps indicate a hardware fault and need a service centre job sheet.

Pulse Buds Troubleshooting

Only one bud plays audio: place both buds in the case, close the lid for 10 seconds, and reopen. If the problem persists, factory reset the buds (hold the case button for 15 seconds with the lid open) and remove the stale pairing entry from the phone before re-pairing.

Buds will not charge: clean the metal contacts on the buds and inside the case with a dry cotton swab. Contact fouling from ear wax is the most common cause. Ensure the case itself has charge - the case LED shows red when below 20 percent.

Audio cutting out: Bluetooth interference from 2.4 GHz Wi-Fi and USB 3.0 devices is common. Move away from the router, disable multipoint if you are not using two devices, and confirm no third device is trying to auto-reconnect.

Microphone not working on calls: check the app permissions for Bluetooth on Android 12 and above, where a missing 'Nearby devices' permission silently disables the headset profile.

SmartHome Troubleshooting

Device offline in the app: confirm the router is on 2.4 GHz, check that fewer than 32 clients are connected to the 2.4 GHz band, and power-cycle the device. If it stays offline, reset it (5 second button hold) and re-add it in the app.

SmartCam feed lagging: 2K streaming needs at least 4 Mbps upload. Reduce the stream to HD in the app if your upload speed is lower. A microSD card that is not marked Class 10 or above will cause recording gaps.

SmartBulb loses its schedule after a power cut: schedules are stored in the cloud and re-sync when the bulb reconnects, which can take up to 10 minutes. If the bulb was reset by five rapid power cycles, it has returned to factory state and must be re-added.

When to Contact Support

Contact support if: the device is dead on arrival, a fault persists after the steps above, you need an RMA for a return, your refund is past the stated timeline, or you need help locating an authorised service centre. Have your order ID, the device serial number, and a description of what you have already tried.