

Export Gas Compressor — Rev A

Instrument & Equipment Schedule

Tag	Service	Setpoints	Design Press.
26-PSV-9027A	Compressor discharge relief	SP 225.4 barg	286 barg
26-PSV-9027B	Compressor discharge relief (spare)	SP 225.4 barg	286 barg
26-PDIT-9015	Compressor pressurized stop DP	H: 0.7 / HH: 1.2 barg	286 barg
26-PIT-9023	Suction scrubber pressure	LL: 110 / HH: 214 barg	286 barg
26-PIT-9019	Discharge pressure	LL: 50 / HH: 135 barg	286 barg

Notes

1. 26-PDI-9015 HH initiate pressurized compressor stop.
9. Manual drain prior to start-up. Push button with permissive to start compressor.
13. Upstream straight pipe run min. 10xD, downstream min 5xD.
19. Suction strainer (commissioning phase only). High alarm at 40% of design DP and compressor high-high trip at 50% of design DP recommended by compressor vendor.
22. Design pressure / temperature in external system downstream compressor 225 barg / 150 C.