

## STANDARD OPERATING PROCEDURE: PUMP MAINTENANCE

DOCUMENT NO: SOP-2026-088 REV: 2.0

### 1. Purpose & Safety Instructions

Always verify pressure transmitter PT-101 before opening valve VLV-302.

Inspect Centrifugal Pump P-101A for excessive vibration or noise.

### 2. Maintenance Execution Steps

Step 1: Lockout and tagout electrical feeder COMP-301.

Step 2: Flush cooling water line 6"-CW-101-CS150.