```
<RC01_CE6863H_SrvTOR01>
```

- This is typical of Huawei devices.
- `RC01` might be the device name or role.
- `CE6863H` is a specific Huawei switch model (a 25G/100G ToR switch).
- `SrvTOR01` likely indicates its function: "Server Top-of-Rack 01".

Purpose	Command
Show system version	`display version`
Show running config	`display current-configuration`
Show interface status	`display interface`
Show system info	`display device`
Help	`?` or `help`

Absolutely! Navigating the **Huawei VRP (Versatile Routing Platform)** CLI is quite structured once you know the basics. Below is a clear, step-by-step guide to help you move around confidently and get the information you need.

---

1. Understanding the Prompt

Your prompt probably looks like this:

```
<RC01_CE6863H_SrvTOR01>
```

- The **angle brackets** `< >` mean you're in **user view** (also called **user EXEC mode**).
- To configure the device, you'll need to enter **system view**.

2. Basic Navigation & Modes

Action	Command
Enter **system view** (to make config changes)	`system-view`
Return to **user view**	`return` or `Ctrl+Z`
Go back one level	`quit`
Save configuration	`save` (in user view)

> 💡 Pro tip: You can type partial commands if they're unambiguous (e.g., `dis ver` for `display version`).

3. Common `display` Commands (in user view)

Use these to **view information without changing config**:

Purpose	Command
Show OS & hardware info	`display version`
View current running config	`display current-configuration`
View saved startup config	`display saved-configuration`
Show interface status	`display interface brief`
Show detailed interface stats	`display interface <interface-name>` (e.g., `display interface 10GE1/0/1`)

Check system uptime & performance	`display device`
List all VLANs	`display vlan`
Show routing table	`display ip routing-table`
View logged-in users	`display users`
Show log buffer	`display logbuffer`

4. Entering Configuration Mode

```bash
<RC01_CE6863H_SrvTOR01> system-view
[RC01_CE6863H_SrvTOR01]
```

- Now you're in **system view** (square brackets `[ ]`).
- From here, you can enter interface, VLAN, or protocol sub-modes.

Example: Configure an interface

```bash
[RC01_CE6863H_SrvTOR01] interface 10GE1/0/1
[RC01_CE6863H_SrvTOR01-10GE1/0/1] description Server_Uplink
[RC01_CE6863H_SrvTOR01-10GE1/0/1] undo shutdown
[RC01_CE6863H_SrvTOR01-10GE1/0/1] quit
```

5. Getting Help

- Type `?` anytime to see **available commands** in the current mode.

```bash
<RC01_CE6863H_SrvTOR01> display ?
```

- Use tab completion: type part of a command and press **Tab**.

6. Saving Your Work

After making changes, **always save** (config is lost on reboot otherwise):

```bash
<RC01_CE6863H_SrvTOR01> save
Warning: The current configuration will be written to the device. Are you sure? [Y/N]: y
```

> ⚠️ Note: Some Huawei switches ask for a filename—just press **Enter** to accept the default (`vrpcfg.zip`).

7. Time & Date

Your device already shows the current time in the login banner:

```
The current login time is 2025-12-15 10:36:08-03:00.
```

To check or set time:

```bash
display clock
clock timezone BR minus 03
```

Quick Reference Cheat Sheet

Task	Command
See basic system info	`display version`
See all interfaces	`display interface brief`
Enter config mode	`system-view`
Exit config mode	`return`
Save config	`save`

Get help	`?`
View full config	`display current-configuration`