

Student Handout — Curtis Fault Code Reference (Training Aid)

Important: Flash codes vary by controller model and software. This sheet teaches **method**, not a universal code list. Always use:

1. The code chart in the **OEM/service manual for that controller model**, and/or
2. Curtis Fault Code Translator: <https://faultcodes.curtisinstruments.com/>

How to read LED flash codes (general method)

1. Note controller model number on the label.
2. Observe LED: count flashes in the sequence pattern used by that model (often sequences of flashes with pauses).
3. Record exactly what you see (e.g., “2 flashes — pause — 1 flash”).
4. Look up meaning in the **model-correct** chart.
5. Confirm with pin/voltage tests — codes point to a subsystem, not automatic parts replacement.

Families referenced in this program

- Curtis **1204 / 1205 / 1268** series (and related) — common in golf/utility conversions and OEM applications
- Mention **Alltrax** as alternate family — follow Alltrax documentation

Training practice table (fill during Week 5)

Cart ID	Controller model	Observed flash	Looked-up meaning	Confirmed by test?

HPD / SRO reminders

- **HPD (High Pedal Disable):** throttle applied at wrong power-up sequence inhibits drive.
- Teach operators: pedal up → enable/key → then throttle (confirm OEM).
- Never permanently bypass for customer return.

[DIAGRAM PLACEHOLDER: photo of Curtis label location + LED on a training cart]