

dbx: ZonePRO 640m-641m

This module controls a dbx ZonePRO 640m, or 641m Router zone over IP



GENERAL INFORMATION	
SIMPLWINDOWS NAME:	dbxZonePRO640m_41m_IP_Router.usp
CATEGORY:	Device Interface
VERSION:	V3.0
SUMMARY:	This module controls a dbx ZonePRO 640m, or 641m Router zone over IP
GENERAL NOTES:	IP CONTROL ONLY. USE "dbxZonePRO640_41_40m_41m_NODE.umc" AND "dbxZonePRO640_41_40m_41m_Router.umc" MODULE FOR SERIAL COMMUNICATION Port: 3804 TCP
	This module MUST be used in conjuction with the "dbxZonePRO640m_41m_IP_NODE.umc " module. This module will NOT work by itself! Connect the serial "module_rx" and "module_tx" signals to the NODE module. Do NOT connect them directly to the TCP-IP Client Object! (See Node module's help file for more information and setup requirements)
CRESTRON HARDWARE REQUIRED:	2-series or X-series processor

CONTROL:		
Mute	D	Pulse to mute the master output of the router
Unmute	D	Pulse to unmute the master output of the router
Input	Α	Sets the input for the router zone: 1d: Lobby Mic 2d: Phone Page 3d: CD L 4d: CD R 5d: Satelite L 6d: Satelite R 7d: Jukebox L 8d: Jukebox R



I²P Certified Module



	9d: Tv L 10d: Tv R 11d: DvD		
Volume	Sets the master volume of the router zone. A Od (0%) = -inf (less then -60 dB) 65535d (100%) = 20.0 dB		
Module_rx	S Information coming back from the NODE module. Connect to the 'rx_Module' on the NODE module.		
FEEDBACK:			
Mute_fb	D High when the master output of the router is muted		
Input_fb	A High when the master output of the router is unmated		
Volume_fb	Current master volume of the router zone A Od (0%) = -inf (less then -60 dB) 65535d (100%) = 20.0 dB		
Module_tx	S Information being sent to the NODE module. Connect to the 'tx_Module' on the NODE module.		
TESTING:			
OPS USED FOR TESTING:	V4.001.1012		
COMPILER USED FOR TESTING:	v2.12		
SAMPLE PROGRAM:	dbxZonePRO640m_41m_IP_DemoProgram.smw		
REVISION HISTORY:	 v. 1.0 – Creation v. 2.0 – Dbx manufacturer update v. 3.0 – Dbx manufacturer Added support for the 640m and 641m 		