Circuit Breaker Unit Test

Copyright (c) 2016 Massachusetts Institute of Technology

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Description:

The objectives of this test are:

- 1) To verify the generic circuit breaker model properly handles the open/close mechanical delays
- 2) To verify the generic circuit breaker trips at the current zero-crossing
- 3) To revise the operation of dynamic/parallel/series loads during various switching conditions

Initial conditions:

- Circuit Breaker: using the generic CB model with 5 cycles open/close mechanical delay. The trip signals to the breaker are send by a signal-sequencer block. The initial status of the circuit breaker will vary depending on the case being evaluated.
- Ideal source: 13.8kV, 375MVA, 7.9 X/R ratio
- Cable modeled as PI-section
- Transformer: 2500 kVA, 13.8/0.48 kV, 5.75%, 6.6 X/R ratio
- Controlled dynamic load: using one minute data for load profile
- Constant load: parallel constant 1000 kVA @ 0.9 pf
- Tmax = 8secs, dT = 100us


Cases:

- 1) Evaluating Open/Close/Open Commands (DYNAMIC LOAD ONLY)
- 2) Evaluating Open/Close/Open Commands (PARALLEL LOAD ONLY)
- 3) Evaluating Open/Close/Open Commands (SERIES LOAD ONLY)
- 4) Evaluating Close/Open/Close Commands (DYNAMIC LOAD ONLY)
 - ---- Cases having the circuit breaker close/open/close with a parallel and series PQ loads were also evaluated and the CB operated correctly.

Copyright (c) 2016 Massachusetts Institute of Technology


Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABLITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.



Case 1: Evaluating Open/Close/Open Commands (DYNAMIC LOAD ONLY)


CB delay function passed the trip signal at 4.583s (w/n 5 cycles). However, the CB begins to open at 4.5845s since it waits for zero-current crossing.





The trip at zero-crossing seems only to apply to phase A, since phases B & C seem trip together. However, the disconnection of phases B & C is inherited from the dynamic load model which shuts-off after losing voltage in phase A.

Should the dynamic load operate unbalanced? Thus, remaining connected until the breaker performs the disconnection.


10s








Zoom-in: Closing circuit breaker




Zoom-in: Opening circuit breaker

Case 2: Evaluating Open/Close/Open Commands (PARALLEL LOAD ONLY)




Note the start-up transient does not damp completely since the load is connected for a brief period of time.

Case 3: Evaluating Open/Close/Open Commands (SERIES LOAD ONLY)



Note the start-up current is nearly balanced when compared to the case of the pallalel-pq-load due to the series resistance

Case 4: Evaluating Close/Open/Close Commands (DYNAMIC LOAD ONLY)



The trip at zero-crossing seems only to apply to phase A, since phases B & C seem trip together. However, the disconnection of phases B & C is inherited from the dynamic load model which shuts-off after losing voltage in phase A. Should the dynamic load operate unbalanced? Thus, remaining connected until the breaker performs the disconnection.