Set /dev/ttyS0 permission

21 July 2022 17:00

- 1. cd /dev
- 2. sudo chown pi ttyS0 ---- here pi is username

Not doing so can throw error of

Cannot open /dev/ttyUSB0: Permission denied

From < https://github.com/esp8266/source-code-examples/issues/26>