

- With this instruction you can assemble hydraulic self leveling system to your Avant loader
- This is a retrofit instruction




- Before assembly you need to make sure that you have all of the components listed below in your retrofit kit
 - A47920 Hydraulic cylinder (for 600 series)
 - A412914 Hydraulic cylinder (for 700 series)
 - 64044 x2 Elbow fitting 90°
 - A47640 x2 Hydraulic hose
 - A47041 x2 Pin
 - 72798 x2 Grease nipple
 - 72147 x2 hexagonal screw M10x16
 - 74531 x2 Washer M10
 - 64070 T-fitting
 - 64078 L-fitting
 - 64043 Elbow fitting 90°
 - A47640 x2 Hydraulic hose



- Start the assembly by lifting the boom up and support it by servise support
- When the boom is up you can remove the front frame covers
- When covers are removed you can wash the loader so you don't contaminate the hydraulic system



 These two hoses needs to be removed from the at the start





- To top fitting you attach this coupling system
- Leave the couplings loose so you can attach the hoses to it easier
- When the hoses are attached to these couplings you can tighten these couplings






- To the lower you need to attach this fitting system
- Leave the couplings loose so you can attach the hoses to it easier
- When the hoses are attached to these couplings you can tighten these couplings






 Parallel cylinder hoses are attached to those fittings as in the picture





 Bucket tilt hoses are attached here as in the picture same way as you removed them at the start





- You need to route the hoses here inside the front frame and to parallel cylinder
- To simplify the picture there is only the hoses for parallel cylinder
- When the hoses are inside the front frame you need to route them to left side of the loader and to parallel cylinder





- Hoses are attached to parallel cylinder
- Hoses goes from the top port to top fitting of the cylinder and from the lower port to cylinder lower fitting





- When the hoses are attached you can bleed the system
- Bleed the system by lifting the boom up and then lower it, do this couple times and the system is bled when the attachment plate follows booms movement nicely
- Do the bleeding without covers so you can see if there are leaks
- When everything is ok you can put removed covers back on their place