



20.3.2025

A481774

Parts list

Avant loader safety sticker sets

Revision	Date	Description
2	3.4.2025	Added E500-series ISO warning stickers

Contents

1.	400-series ANSI Warning stickers.....	2
2.	400-series ISO Warning stickers	3
3.	500-, 600-, 700-series ANSI Warning stickers.....	4
4.	500-, 600-, 700-series ISO Warning stickers	5
5.	800-series ISO Warning stickers	6
6.	800-series ANSI Warning stickers.....	7
7.	E500-series ISO warning stickers	8

1. 400-series ANSI Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A442250	Safe shutdown procedure	ROPS	Left side of steering wheel, with L cab windshield wiper cover
1	A446498	Personal injury hazard	ROPS	Left side of steering wheel,
1	A442251	Tipping over hazard	ROPS	Right side of steering wheel
2	A417273	Keep Away From Lifted Boom	ROPS	Left wall and top of boom
1	A464324	Keep Away From Lifted Boom	ROPS	Right wall of boom
1	A446539	Hot Exhaust hazard	ROPS	Rear right cover, next to exhaust pipe
1	A446544	Hydraulic Oil Injection Hazard	ROPS	Top of boom, next to hydraulic pipes
1	A417270	Hot surface	ROPS	Engine bay, right side
1	A417271	Cutting Hazard	ROPS	Top of air filter housing
1	A417272	Burn hazard, Hot Coolant	ROPS	Right side of coolant cap
1	A446551	Leg pinching hazard	ROPS	Next to cup holder
1	A467797	Emergency hammer, cab L	L	Next to emergency hammer, left wall of cab
1	A464215	Long combination sticker	ROPS	Driver knee space
1	A411456	Hand pinching hazard	ROPS	Frame/cab rear right pole
2	AXXXXX	Decibel sticker	ROPS	Right wall of driver cab, under hour meter.
1	A467657	Position of the Operator's Manual	ROPS	Behind drivers seat, with L cab rear left wall
1	A432613	Tipping load label	ROPS	Under drivers cab roof
2	A464119	Ballasted tires	ROPS	Rear frame, both sides of articulation joint (Only if loader has ballasted tires)

2. 400-series ISO Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A454862	Compilation sticker	ROPS	Left side of steering wheel
1	A414244	Hot Exhaust pipe hazard	ROPS	Rear right cover, next to exhaust pipe
2	A417273	Keep Away From Lifted Boom	ROPS	Left and right wall of boom
1	A417270	Hot surface	ROPS	Engine bay, right side
1	A417271	Cutting Hazard	ROPS	Top of air filter housing
1	A417272	Burn hazard, Hot Coolant	ROPS	Right side of coolant cap
1	A411455	Leg pinching hazard	ROPS	Next to cup holder
1	A411021	Emergency hammer, cab L	L	Under emergency hammer, left wall of cab
1	A454525	Long combination sticker	ROPS	Top of air filter housing
1	A411456	Hand pinching hazard	ROPS	Frame/cab rear right pole
2	AXXXXX	Decibel sticker	ROPS	Right wall of driver cab, under hour meter.
1	A467657	Position of the Operator's Manual	ROPS	Behind drivers seat, with L cab rear left wall
1	A454521	Tipping load label	ROPS	Under drivers cab roof

3. 500-, 600-, 700-series ANSI Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A417274	Noise hazard	GT+ROPS	Driver cap right wall, with GT cab on roof
1	A442250	Safe shutdown procedure	GT+ROPS	Left side of steering wheel, with GT cab windshield wiper cover
1	A446538	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab top of machine shield (1-speed loaders)
1	A446537	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab top of machine shield (2-speed loaders)
1	A442251	Tipping over hazard	ROPS	Right side of steering wheel
1	A446498	Personal injury hazard	ROPS	Left side of steering wheel
1	A446500	Fire, exhaust and service warning	ROPS	Driver cap right wall, with GT cab on roof
1	A446539	Hot Exhaust hazard	GT+ROPS	Rear right cover, next to exhaust pipe
3	A446540	Keep Away From Lifted Boom	GT+ROPS	Both sides of boom and front middle
1	A446544	Hydraulic Oil Injection Hazard	GT+ROPS	Top of boom, next to hydraulic pipes
1	A446545	Burn hazard, hot surfaces	GT+ROPS	Right side of engine
1	A446548	Cutting hazard	GT+ROPS	Top of air filter housing
1	A446549	Burn hazard, hot coolant	GT+ROPS	Side of the coolant reservoir
2	A446551	Leg pinching hazard	GT+ROPS	Between tires rear frame and next to cup holder
1	A446556	Glass break hazard	GT	Cab left front pole
1	A467797	Emergency hammer, cab L	L+GT	Next to emergency hammer
1	A464215	Long combination sticker	ROPS	Driver knee space
1	A464216	Combination sticker	GT	Below driver seat
1	A464218	Crush hazard, hands	ROPS	Driver cabin left rear pole
2	AXXXXX	Decibel sticker	GT+ROPS	Right wall of driver cab
1	A467877	Position of the Operator's Manual	GT+ROPS	Behind drivers seat, with L cab rear left wall
1	A470403	Fire Hazard, DPF	GT+ROPS	Next to load tipping label, with GT cab front panel around left knee.
1	AXXXXX	Tipping load label	GT+ROPS	Under drivers cab roof

4. 500-, 600-, 700-series ISO Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A442391	Safe shutdown procedure	GT+ROPS	Driver cab right wall, with GT cab front panel around right knee
1	A441498	Safe shutdown procedure (Turbo)	GT+ROPS	Driver cab right wall, with GT cab front panel around right knee
1	A442339	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab under machine shield (1-speed loaders)
1	A441496	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab under machine shield (2-speed loaders)
1	A441497	Tipping over hazard	GT+ROPS	Right side of steering wheel, with GT cab front panel around right knee
1	A414244	Hot Exhaust hazard	GT+ROPS	Rear right cover, next to exhaust pipe
2	A417273	Keep Away From Lifted Boom	GT+ROPS	Both sides of boom
1	A417270	Burn hazard, hot surfaces	GT+ROPS	Right side of engine bay
1	A417271	Cutting Hazard	GT+ROPS	Top of air filter housing
1	A417272	Burn hazard, hot coolant	GT+ROPS	Side of the coolant reservoir
1	A411455	Leg pinching hazard	GT+ROPS	Next to cup holder
1	A452717	Glass break hazard	GT	Cab left front pole
1	A411021	Emergency hammer, cab L	L	Next to emergency hammer
1	A467705	Emergency hammer, cab GT	GT	Next to emergency hammer
1	A441476	Long combination sticker	GT+ROPS	Driver knee space
1	A411456	Crush hazard, hands	ROPS	Driver cabin left rear side outside
2	AXXXXX	Decibel sticker	GT+ROPS	Right wall of driver cab
1	A467657	Position of the Operator's Manual	GT+ROPS	Behind drivers seat, with L cab rear left wall
1	A441492	Fire Hazard, DPF	GT+ROPS	Left side of steering wheel, with GT cab in knee space.
1	AXXXXX	Tipping load label	GT+ROPS	Under drivers cab roof

5. 800-series ISO Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A442391	Safe shutdown procedure	GT+ROPS	Driver cab right wall, with GT cab front panel around right knee
1	A441498	Safe shutdown procedure (Turbo)	GT+ROPS	Driver cab right wall, with GT cab front panel around right knee
1	A442339	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab under machine shield (1-speed loaders)
1	A441496	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab under machine shield (2-speed loaders)
1	A441497	Tipping over hazard	GT+ROPS	Right side of steering wheel, with GT cab front panel around right knee
1	A414244	Hot Exhaust hazard	GT+ROPS	Rear right cover, next to exhaust pipe
2	A417273	Keep Away From Lifted Boom	GT+ROPS	Both sides of boom
1	A417270	Burn hazard, hot surfaces	GT+ROPS	Right side of engine bay
1	A417271	Cutting Hazard	GT+ROPS	Top of air filter housing
1	A417272	Burn hazard, hot coolant	GT+ROPS	Side of the coolant reservoir
1	A411455	Leg pinching hazard	GT+ROPS	Next to cup holder
1	A452717	Glass break hazard	GT	Cab left front pole
1	A411021	Emergency hammer, cab L	L	Next to emergency hammer
1	A467705	Emergency hammer, cab GT	GT	Next to emergency hammer
1	A441476	Long combination sticker	GT+ROPS	Driver knee space
1	A411456	Crush hazard, hands	ROPS	Driver cabin left rear side outside
2	AXXXXX	Decibel sticker	GT+ROPS	Right wall of driver cab
1	A467657	Position of the Operator's Manual	GT+ROPS	Behind drivers seat, with L cab rear left wall
1	A441492	Fire Hazard, DPF	GT+ROPS	Left side of steering wheel, with GT cab in knee space.
1	A467085	Tipping load label 845-850	GT+ROPS	Under drivers cab roof
1	A441493	Tipping load label 855i-860i	GT+ROPS	Under drivers cab roof

6. 800-series ANSI Warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A417274	Noise hazard	GT+ROPS	Driver cap right wall, with GT cab on roof
1	A442250	Safe shutdown procedure	GT+ROPS	Left side of steering wheel, with GT cab windshield wiper cover
1	A446538	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab top of machine shield (1-speed loaders)
1	A446537	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab top of machine shield (2-speed loaders)
1	A446539	Hot Exhaust hazard	GT+ROPS	Rear right cover, next to exhaust pipe
3	A446540	Keep Away From Lifted Boom	GT+ROPS	Both sides of boom and front middle
1	A446544	Hydraulic Oil Injection Hazard	GT+ROPS	Top of boom, next to hydraulic pipes
1	A446545	Burn hazard, hot surfaces	GT+ROPS	Right side of engine
1	A446548	Cutting hazard	GT+ROPS	Top of air filter housing
1	A446549	Burn hazard, hot coolant	GT+ROPS	Side of the coolant reservoir
2	A446551	Leg pinching hazard	GT+ROPS	Between tires rear frame and next to cup holder
1	A446556	Glass break hazard	GT	Cab left front pole
1	A467797	Emergency hammer, cab L	L+GT	Next to emergency hammer
1	A464216	Combination sticker	GT	Below driver seat
1	A464218	Crush hazard, hands	ROPS	Driver cabin left rear pole
2	AXXXXX	Decibel sticker	GT+ROPS	Right wall of driver cab
1	A442251	Tipping over hazard	ROPS	Right side of steering wheel
1	A470403	Fire Hazard, DPF	GT+ROPS	Next to load tipping label, with GT cab front panel around left knee.
1	AXXXXX	Tipping load label	GT+ROPS	Under drivers cab roof

7. E500-series ISO warning stickers

Pcs.	Sticker	Description	Cab	Position
1	A465683	Safe shutdown procedure	GT+ROPS	Driver cab right wall, with GT cab front panel around right knee
1	A442339	Sudden stop hazard	GT+ROPS	Right side of steering wheel, With GT cab under machine shield
1	A441497	Tipping over hazard	GT+ROPS	Right side of steering wheel, with GT cab front panel around right knee
2	A417273	Keep Away From Lifted Boom	GT+ROPS	Both sides of boom
1	A465950	Cutting Hazard	GT+ROPS	Battery bracket
1	A465951	Pressure washing prohibited	GT+ROPS	Battery bracket
1	A411455	Leg pinching hazard	GT+ROPS	Next to cup holder
1	A452717	Glass break hazard	GT	Cab left front pole
1	A411021	Emergency hammer, cab L	L	Next to emergency hammer
1	A467705	Emergency hammer, cab GT	GT	Next to emergency hammer
1	A465711	Long combination sticker	GT+ROPS	Driver knee space
1	A411456	Crush hazard, hands	ROPS	Driver cabin left rear side outside
2	AXXXXX	Decibel sticker	GT+ROPS	Right wall of driver cab
1	A467657	Position of the Operator's Manual	GT+ROPS	Behind drivers seat, with L cab rear left wall
1	AXXXXX	Tipping load label	GT+ROPS	Under drivers cab roof