Shortcuts / one-sheet reference

Hold the modifier first. SELECT is the rotary encoder; SEL is the button.

Hold SEL → press SEQ	Open Song and select four-track mode
Hold HOME → press SEQ	Open Mixer and select four-track mode
Hold SEL → press HOME	Toggle four-track / four-voice instrument
Hold ENV → press HOME	Select mono instrument with legato glide
Hold LFO → press HOME	Select four-voice instrument; glide off
Hold SEL → press FX	Save current FX order as personal default
Hold FX / SEQ / EDIT / GLO / LFO	After 0.8 s, return to that section’s landing page
Press HOME again on HOME	Toggle expanded oscilloscope view
Press ARP again / LFO again	Toggle the respective stored function
Hold SEL + turn an ordinary parameter knob	Use fine adjustment; context actions take priority
Hold SEL + press PLAY	Queue selected track for the next 16-step bar
Hold SEL + double-press PLAY	Queue all tracks for the next 16-step bar
NOTE EDIT: ALGORITHM / SEL	Move the logical note in time / delete it
NOTE EDIT: hold SEL + turn pitch down/up	Insert Rest / Tie
PRESETS / GLO K1	Browse sounds across banks / choose 1V,4V,4T
SAVE: choose scope, slot, action → SEL	Confirm instrument or project Save/Load

Mode changes involving 4T, SAVE/LOAD and saving a personal FX default stop playback. Track launch shortcuts are unavailable during recording.