MAIN MENU

RX Calibration Submenu (1 beep)
- Start RX Calibration (1 beep)
- Exit to Main Menu (2 beeps)

Sensors/Battery Submenu (2 beeps)
- Select LiFePO4 battery type (1 beep)
- Select Li-Polymer battery type (2 beeps)
- Enable/Disable Current Sensor (3 beeps)
- Exit to Main Menu (4 beeps)

RESET Submenu (3 beeps)
- Reset CurrentSensor Data and Exit to Main Menu (1 beep)
- Reset Configuration and Exit to Main Menu (2 beeps)
- Exit to Main Menu (3 beeps)

Render Info Select Submenu (4 beeps)
- Show/Hide System States in Serial Port (1 beep)
- Show/Hide Battery Info in Serial Port (2 beeps)
- Show/Hide RX Info in Serial Port (3 beeps)
- Show/Hide CurrentSensor Info in Serial Port (4 beeps)
- Exit to Main Menu (5 beeps)

Exit to Normal Mode (5 beeps)