



# svan

SERVICE MANUAL

SV4600



## **Service Manual on Vitroceramic Hobs**

1. No electricity.  
Possible caused:
  - 1) The power doesn't connect well or abnormal supply voltage.
  - 2) PCB failure
2. Power on but buttons have no response.  
Possible caused: Display board failure.
3. No heating on all cooking zone.  
Possible failure: PCB failure.
4. No heating on individual cooking zone.  
Possible failure:
  - 1) PCB failure
  - 2) Heating element failure
  - 3) Thermocouple failure

SVAN TRADING S.L.  
C/Ciudad de Cartagena, nº 20  
Pol. Fuente del Jarro  
Paterna - 46988