PRODUCT MANUAL

32 oz Blender Cup Replacement Kit with Flip-Top To-Go Lid & 7-Fin Blade Assembly

Product	Blender Cup Replacement Kit	**Brand**	Aftermarket replacement accessory
Configuration	32 oz cup + flip-top lid + 7-fin blade assembly	**ASIN**	B07T1KB5Q6
Compatibility	Selected models listed in this manual	**Set contents**	3 pieces

1. Product Overview

This replacement kit is designed for use with selected compatible blender models. The set includes one 32 oz blending cup, one flip-top to-go lid, and one 7-fin bottom blade assembly. Use the cup and blade assembly with a compatible blender motor base. The motor base is not included.

This is a non-original aftermarket accessory. It is not sold or created by Nutri Ninja and is not sponsored, endorsed by, or affiliated with Nutri Ninja. Brand and model names are used only to identify compatibility.

2. Package Contents

Qty.	Component	Description
1	32 oz Blender Cup	Transparent blending container with measurement markings.
1	Flip-Top To-Go Lid	Drinking lid designed to fit the supplied cup.
1	7-Fin Bottom Blade Assembly	Removable blade assembly for use with the cup and a compatible motor base.

Note: The listing describes a three-piece set and does not list a separate loose sealing ring as an additional package item. If a sealing ring/gasket is fitted to the blade assembly on your unit, keep it correctly seated in its groove. Do not remove it unless required for cleaning or inspection.

3. Compatibility – Check Your Full Model Number

Check the complete model number on your blender label before ordering or installing. Similar-looking model numbers may use different blade systems. This kit is specified for 7-fin blade systems only.

COMPATIBLE MODELS	NOT COMPATIBLE
1000W / 1100W: BL480-30, BL481-30, BL482-30, BL483-30, BL486CO-30 900W: BL450-30, BL451-30 Additional models: BL487, BL488W, BL490, BL491, BL492W, BL492, BL640, BL641, BL642, BL642W, BL642Z, BL680, BL680A, BL682	BL66x / BL77x / BL8xx series BL450-70, BL451-70, BL454-70 BL480-70, BL481-70, BL482-70 BL483-70, BL484-70 6-fin blade systems A model ending in “-30” is not interchangeable with a similar model ending in “-70”. For example, BL482-30 is listed as compatible; BL482-70 is not.

Always confirm both the full blender model number and the original blade connection/system. Do not rely on appearance or wattage alone. If your model is not listed above, do not assume compatibility.

4. Assembly and Use Instructions

Step 1 – Add Ingredients to the Cup

1. Place the cup upright on a stable, level surface.
2. Add ingredients without exceeding the MAX fill line marked on the cup.
3. Do not fill the cup with hot liquids. Leave sufficient space for ingredients to move during blending.

Step 2 – Attach the Blade Assembly

4. Make sure the cup rim and blade assembly threads are clean and free of food residue.

5. If your unit has a sealing ring/gasket fitted to the blade assembly, check that it is present, undamaged, and seated evenly in its groove.
6. Align the blade assembly with the cup opening. Turn it onto the cup carefully and evenly.
7. Tighten by hand until securely seated. Do not cross-thread, force, or use tools to overtighten.

Step 3 – Blend with a Compatible Motor Base

8. With the blender switched off and unplugged, invert the assembled cup-and-blade unit as required by the blender design.
9. Align and secure it to the compatible motor base according to the blender manufacturer's operating instructions.
10. Place the blender on a stable surface. Keep hands and utensils away from the blade area.
11. Operate the blender only as directed by the motor-base manufacturer's manual. Do not run the unit if the cup or blade assembly is loose or leaking.

Step 4 – Remove and Fit the To-Go Lid

12. When blending has completely stopped, switch off and detach the cup assembly following the blender manufacturer's instructions.
13. Return the cup to an upright position. Carefully remove the blade assembly, keeping fingers away from the sharp blades.
14. Check that the cup rim is clean. Align the flip-top lid with the cup threads and turn it on evenly until securely fitted.
15. Close the flip-top drinking cover before carrying the cup. Keep the cup upright during transport.

The illustration below shows the general sequence: fill the cup, attach the blade assembly, invert and blend using a compatible blender base, then replace the blade assembly with the flip-top to-go lid. The motor base is not included.



5. How to Confirm Correct Installation

- The cup and blade assembly start straight and thread together smoothly without tilting or cross-threading.
- The blade assembly sits evenly against the cup opening with no visible gap caused by misalignment.
- The sealing ring/gasket, if fitted, is seated evenly and is not twisted, pinched, missing, or protruding.
- The threaded connection does not wobble and there is no visible liquid leakage during a careful pre-use check.
- The flip-top lid starts straight, screws down evenly, and sits flush against the cup rim without rocking or visible gaps.
- The full blender model and blade system match the compatibility list before connecting the assembly to the motor base.

Do not test a questionable connection by powering on the blender. If a part does not fit smoothly by hand, stop and follow the troubleshooting steps.

6. Troubleshooting

Issue	Possible Cause	What to Do
Cup will not connect to blade assembly	Wrong cup/blade configuration; threads misaligned, dirty, or damaged.	Stop. Check the full model number and 7-fin system. Clean and inspect both threads. Realign and try gently by hand. Do not force or cross-thread.
Blade assembly feels loose or sits unevenly	Threads may not be engaged correctly; gasket may be displaced or damaged.	Remove the assembly. Inspect threads and gasket (if fitted), reseat the gasket evenly, then reconnect straight by hand. Do not use if it remains loose.
Cup leaks around blade assembly	Gasket may be missing, twisted, dirty, damaged, or not seated; assembly may be loose.	Stop using immediately. Empty and clean the connection. Check gasket and threads. Do not operate while leaking.
Flip-top lid will not fit cup	Lid may be misaligned, threads obstructed, or lid/cup mismatched.	Use the supplied lid with the supplied cup. Clean the rim and threads, align evenly, and turn gently. Do not force.
Model looks similar but parts do not fit	Full model suffix or blade system may differ (e.g. -30 vs -70 or 7-fin vs 6-fin).	Read the complete model number from the blender label and compare it with Section 3. Do not use if the model is not listed.
Liquid or ingredients escape during blending	Cup/blade connection may be loose, cup overfilled, or assembly incorrectly fitted.	Switch off and unplug before handling. Check the MAX line, connection, and gasket. Do not restart until corrected.

7. Safety, Cleaning and Maintenance

Before Each Use

- Confirm that the blender's full model number and blade system are listed as compatible.
- Inspect the cup for cracks or damage. Check the lid, threads, blade assembly, and sealing ring/gasket (if fitted).
- Make sure all parts are clean, correctly assembled, and securely tightened before use.
- Never exceed the MAX fill line. Do not use this cup for hot liquids.
- Keep hands and utensils away from the sharp blades. Never handle the blade edges directly.
- Do not operate if any component is cracked, damaged, loose, leaking, or incorrectly fitted.
- The motor base is not included. Follow the original blender manufacturer's instructions for attaching and operating the cup assembly.

Cleaning

- Switch off and unplug the blender before removing or cleaning any component.
- Separate the blade assembly from the cup before washing. Handle the blades carefully.
- The cup, lid, and blade assembly are described as dishwasher safe in the product listing. Place the lid and blade assembly on the top rack.
- Clean food residue from the threads and sealing-ring groove carefully so it does not prevent a secure fit.
- Allow all parts to dry fully before reassembly or storage.

Maintenance and Storage

- Inspect the blade assembly, threads, and sealing ring/gasket regularly for wear, corrosion, deformation, or damage.
- Do not use if the blade assembly is loose, the cup is cracked, the gasket is damaged, or leakage occurs.
- Store components clean and dry. Keep the blade assembly away from children and handle it carefully.
- Do not modify components or combine them with unverified cups, lids, or blade assemblies.

8. Compatibility Reference Image

Use this chart as a quick visual reference. The full model number printed on the blender remains the deciding check.



Important Notice

This is an aftermarket replacement accessory, not an original Nutri Ninja product. Compatibility is limited to the specific models and blade systems listed in this manual. Always verify the complete model number and connection type before use. Stop using the product if any component does not fit securely or shows signs of damage.