Synthetic sample document - fictional data for demos and evaluation only.

STANDARD OPERATING PROCEDURE: COMPRESSOR C-210
Document ID: SOP-COMP-210-REV2
Equipment: Rotary Screw Air Compressor C-210, Unit 4 Utilities

1. Start-Up Procedure:
- Verify the oil level in the separator sight glass is between the MIN and MAX marks.
- Open discharge isolation valve V-211 fully before starting.
- Start the compressor in unloaded mode and wait 30 seconds before loading.
- Confirm discharge pressure reaches 7.5 bar(g) within 2 minutes of loading.
- If pressure is not reached, unload, stop the machine and check for air leaks.

2. Operating Limits:

- Normal discharge temperature: 80 to 95 degC.
- Discharge temperature alarm: 105 degC. Automatic trip: 110 degC.
- Minimum oil pressure while loaded: 2.0 bar.
- Airend housing vibration must stay below 7.1 mm/s RMS (ISO 10816 zone B).
- Inlet air filter: replace the filter element when differential pressure exceeds 50 mbar.
- Never operate with the enclosure doors open; cooling airflow depends on them.

3. Maintenance Intervals:
- Change compressor oil (synthetic PAO, ISO VG 46) every 4,000 running hours.
- Replace the oil filter and the separator element every 4,000 running hours.
- Drain condensate traps daily and confirm the automatic drain valve cycles.
- Inspect drive belt tension every 500 running hours; adjust if deflection exceeds 10 mm.
- Record all readings on log sheet CL-210 and report deviations to the shift supervisor.