K44 48-PIN ECU CONNECTOR PINOUT

C8

GREY CONNECTOR

POWER GROUND (Ground at engine block with its own 1mm wire)

BLACK CONNECTOR

EXTERNAL MAP SENSOR INPUT (internal Map switch set to EXT.)

BOOS HC4	T FAN S	C3 STEP-B2	C4 STEP-B1	C5 STEP-A1	C6 STEP-A2	C7 FP LC1	C8 GND	GN SEN	D AN IN1	C3 AN IN2	C4 OXY	C5 CTS	C6 IAT	C7 TPS	C8 MAP		
B1 IGN1	B2 IGN2	B3 IGN3	B4 IGN4	B5 IDL2 HC1	B6 IDL1 HC3	B7 VVT1 HC2	B8 VVT2 HC5	B		B3 CNK- TRIG1	B4 CAM+ TRIG2	B5 CAM- TRIG2	B6 DIG IN1	B7 LAUNCH	B8 FLEX		
A1 INJ1	A2 INJ2	A3 INJ3	A4 INJ4	A5 INJ5	A6 INJ6	A7 INJ7	A8 INJ8	A +1: POV	V GND	A3 +5V OUT	A4 HC PIN43	A5 DIG IN2	A6 RXD SERIAL3	A7 TXD SERIAL3	A8 GND DIGITAL		
A1	OUTPUT		INJECTO	OR 1				A1	POWER	2		+12V PC	OWER IN	PUT Fror	n ignition re	elav	
A2	OUTPUT		INJECTO					A2		R GROUN	۱D				th its own 1		
A3	OUTPUT		INJECTO	DR 3				A3	POWER	}					KCURRENT 100r		
A4	OUTPUT		INJECTO	OR 4				A4	SPARE			SPARE	UNDEFIN	NED PIN I	FOR CUST	ГОМ АРР	LICATIONS
A5	OUTPUT		INJECTO	DR 5				A5	INPUT			DIGITAL	. INPUT 2	2			
A6	OUTPUT		INJECTO					A6	COMMS			SERIAL	3 DATA F	RXD			
A 7	OUTPUT		INJECTO					A7	COMMS	-			3 DATA T				
A8	OUTPUT		INJECTO	OR 8				A8	DIGITA	INPUT (GROUNE	(ground	at engine	block wi	th its own 1	1mm wire	
В1	OUTPUT		IGNITIOI	N 1				В1	OUTPU	Т		TACH O	UTPUT F	Pulled up	to +12v		
B2	OUTPUT		IGNITIO	N 2				B2	TRIGGE	R		CRANK	SENSOF	₹+ve			
B3	OUTPUT		IGNITIO					B3	TRIGGE			CRANK	SENSOF	₹-ve			
B4	OUTPUT		IGNITIO	N 4				B4	TRIGGE	R		CAM SE	NSOR +	ve			
B5	OUTPUT				ured for 3		e valve	B5	TRIGGE	R			NSOR -v				
B6	OUTPUT				gnd activ			B6	INPUT				. INPUT 1				
B7	OUTPUT				gnd acti			B7	INPUT				SWITC				
B8	OUTPUT		VVT2 wh	nen confi	gured for	dual VV	Т	В8	INPUT			FLEX FU	JEL SEN	SOR INP	UT		
C1	OUTPUT		BOOST	SOLENC	ID gnd a	ctive driv	е	C1	SENSO	R GND							
C2	OUTPUT		FAN REI	_AY gnd	active dri	ve		C2	INPUT			ANALOG	3 INPUT	1			
C3	OUTPUT				32 OUTP			C3	INPUT			ANALOG	3 INPUT	2			
C4	OUTPUT		IDLE ST	EPPER E	31 OUTP	UT		C4	INPUT			OXY SE	NSOR IN	IPUT 0-5\	/		
C5	OUTPUT		IDLE ST	EPPER A	1 OUTP	UT		C5	INPUT			COOLAI	NT TEMP	PERATUR	E SENSO	R	
C6	OUTPUT		IDLE ST	EPPER A	A2 OUTP	UT		C6	INPUT			INTAKE	AIR TEM	IPERATU	RE SENS	OR	
C7	OUTPUT		FUEL PL	JMP Gno	active R	elay Driv	е	C7	INPUT			THROT	TLE POS	ITION SE	NSOR		

C8

INPUT