

Workshop Zone Settings

Access

- **Menu: Settings → Locations → Areas**
 - **Used to define workshop zones and assign them to production locations for manufacturing.**
-

Workshop Zone Definition

- **A workshop zone is a defined area where manufacturing activities occur.**
 - **Once created, locations must be assigned to this zone (via Zone Management).**
 - **These assigned locations appear in the right side of the screen for reference.**
-

Approach Settings

These parameters determine how components are approached (moved) to the workshop before manufacturing begins.

Key Configuration Options

1. Manufacturing Location

- **The location where production is physically carried out.**
- **Only one location per workshop area can be defined as the manufacturing location.**

2. Replenishment Methods

- **Transfer by Support**
 - **Moves a complete support (full pallet) for production.**
 - **Configuration options:**
 - **Origin stock area: area where components are picked from.**
 - **Search rule: defines where components are moved within the workshop.**
 - **Selected item family: specifies which items are affected.**

- **Horizon (Nb days):** number of days in the MO portfolio considered for quantity calculation.
 - **Pick-List**
 - **Generates a transfer order for components matching the MO requirements (rounded to the configured Stock Unit).**
 - **Configuration options:**
 - **Recipient:** internal order destination (the workshop location).
 - **Preparation channel:** defines the channel used for the generated order.
 - **Preparation type:** must be Replenishment.
 - **Approach time (Nb days):** initializes the preparation and delivery dates for the order.
-

Purpose

- **Ensures that all required components are available in the workshop before production starts.**
- **Configures whether full pallets or quantities per pick-list are used for replenishment.**
- **Integrates with MO portfolio horizon to calculate the required quantities in advance.**