Install and execute AFF and FAS firmware Ansible automation package (Experienced Users)

Active IQ Digital Advisor

netapp-manishc, Reenu Jojo
January 15, 2021

This PDF was generated from https://docs.netapp.com/us-en/active-iq/task_install_execute_firmware_update_exp_user.html on July 13, 2021. Always check docs.netapp.com for the latest.

Table of Contents

Install and execute AFF and FAS firmware Ansible automation package (Experienced Users) 1
Firmware update with Ansible using NetApp Docker Image 1
Firmware update if Ansible is already used 2

Install and execute AFF and FAS firmware Ansible automation package (Experienced Users)

Experienced users can install and execute the AFF and FAS firmware ansible automation package quickly.

Firmware update with Ansible using NetApp Docker Image

Steps

1. Pull the Ansible Docker image to the Linux host:

```
$ docker pull schmots1/netapp-ansible
Using default tag: latest
latest: Pulling from schmots1/netapp-ansible
docker.io/schmots1/netapp-ansible:latest
```

2. Run the docker image as a container on the Linux host:

```
$ docker run -v <downloaded_playbook_path>:/<container_path> -it
schmots1/netapp-ansible:latest /bin/bash
```

> The Ansible Playbook and the inventory file should be in the same path.

3. Execute the Ansible Playbook on the Linux host. Firmware updates run in the background for a few hours.

```
$ cd <container_path>
$ ansible-playbook na_ontap_pb_upgrade_firmware.yml

Enter your ONTAP admin username: ****
Enter the password for your ONTAP admin user: ****
Enter the base URL to the firmware package (using HTTP is recommended):
 http://<web-server>/path/
PLAY [ONTAP Firmware Upgrade]
*****************************************************************
```

If the URLs for disk firmware, shelf firmware, and service processor firmware are **http://<web-server>/path/all_shelf_fw.zip**, **http://<web-server>/path/all.zip** and **http://<web-server>/path/<SP/BMC>_<version_number>_fw.zip**, provide **http://<web-server>/path/** as the input for the base URL to the firmware package. If there are a set of clusters with different login credentials, the Ansible Playbook must be run on each cluster. There are no changes required to the inventory file as the Ansible Playbook skips the clusters for which the login has failed.

4. Log in to the cluster as the cluster administrator and verify that the new drive firmware has been installed:

```
::> storage disk show -fields firmware-revision,model
 disk     firmware-revision model
--------------- ----------------- ----------------
1.11.0   NA01              X423_HCOBE900A10
1.11.1   NA01              X423_HCOBE900A10
1.11.2   NA01              X423_HCOBE900A10
1.11.3   NA01              X423_HCOBE900A10
1.11.4   NA01              X423_HCOBE900A10
```

Firmware update if Ansible is already used

Steps

1. Install Python and Ansible and then download the Python packages using PIP:

```
$ pip install netapp-lib requests paramiko

Installing collected packages: netapp-lib, requests, paramiko
Successfully installed netapp-lib-2020.3.12 requests-2.23.0 paramiko-
2.7.2
```

2. Install the NetApp Ansible Collection:

```
To install the collection only for the current user:
$ ansible-galaxy collection install netapp.ontap

For universal installation:
$ ansible-galaxy collection install netapp.ontap -p
/usr/share/ansible/collections
$ chmod -R +rw /usr/share/ansible/collections
```

3. Ensure that the Ansible Playbook and the inventory file are in the same path and then execute the Ansible Playbook. Firmware updates run in the background for a few hours.

```
$ cd <playbook_path>
$ ansible-playbook na_ontap_pb_upgrade_firmware_disk.yml

Enter your ONTAP admin username: ****
Enter the password for your ONTAP admin user: ****
Enter the base URL to the firmware package (using HTTP is recommended):
http://<web-server>/path/
PLAY [ONTAP Firmware Upgrade]
*****************************************************************
```

> If the URLs for disk firmware, shelf firmware, and service processor firmware are **http://<web-server>/path/all_shelf_fw.zip**, **http://<web-server>/path/all.zip** and **http://<web-server>/path/<SP/BMC>_<version_number>_fw.zip**, provide **http://<web-server>/path/** as the input for the base URL to the firmware package. If there are a set of clusters with different login credentials, the Ansible Playbook must be run on each cluster. There are no changes required to the inventory file as the Ansible Playbook skips the clusters for which the login has failed.

4. Log in to the cluster as the cluster administrator and verify that the new drive firmware has been installed:

```
::> storage disk show -fields firmware-revision,model
 disk     firmware-revision model
--------------- ----------------- ----------------
1.11.0   NA01              X423_HCOBE900A10
1.11.1   NA01              X423_HCOBE900A10
1.11.2   NA01              X423_HCOBE900A10
1.11.3   NA01              X423_HCOBE900A10
1.11.4   NA01              X423_HCOBE900A10
```

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.