ストレージパフォーマンスを最適化するために LACP を設定します

HCI

Michael Wallis, Ann-Marie Grissino, Aksel Davis, Dave Bagwell
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/hci_prereqs_LACP_configuration.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

ストレージパフォーマンスを最適化するために LACP を設定します 1

ストレージパフォーマンスを最適化するために LACP を設定します

NetApp HCI ストレージクラスタのパフォーマンスを最適化するには、各ストレージノードに使用するスイッチポートで Link Aggregation Control Protocol （ LACP ）を設定します。

作業を開始する前に

- NetApp HCI ストレージノードの 10 / 25GbE インターフェイスに接続されたスイッチポートを LACP ポートチャネルとして設定しておきます。
- ストレージトラフィックを処理するスイッチの LACP タイマーを「高速モード（ 1 秒）」に設定し、フェイルオーバー検出時間を最適化しておきます。導入時に、すべてのストレージノード上の Bond1G インターフェイスが自動的にアクティブ / パッシブモードに対応するように設定されます。
- ストレージネットワークを処理するスイッチで、 Cisco Virtual PortChannel （ vPC ）または同等のスイッチスタッキングテクノロジを設定しておきます。スイッチスタッキングテクノロジを使用することで LACP とポートチャネルを簡単に設定でき、ストレージノード上の 10 / 25GbE ポートとスイッチの間のトポロジでループが発生するのを防ぐことができます。

手順

1. スイッチベンダーの推奨事項に従って、 NetApp H シリーズストレージノードに使用するスイッチポートで LACP を有効にします。
2. NetApp HCI を導入する前に、ノード上のユーザインターフェイス（ターミナルユーザインターフェイスまたは TUI と呼ばれる）ですべてのストレージノードのボンディングモードを LACP に変更します。

詳細については、こちらをご覧ください

- "NetApp HCI のリソースページ"
- "vCenter Server 向け NetApp Element プラグイン"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.