SolidFire Active IQ を使用して、パフォーマンス、容量、クラスタの健全性を監視できます

HCI

Ann-Marie Grissino, Aksel Davis, Dave Bagwell
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_hcc_activeiq.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

SolidFire Active IQ を使用して、パフォーマンス、容量、クラスタの健全性を監視できます 1

SolidFire Active IQ を使用して、パフォーマンス、容量、クラスタの健全性を監視できます

SolidFire Active IQ を使用して、クラスタのイベント、パフォーマンス、容量を監視できます。SolidFire Active IQ には、 NetApp Hybrid Cloud Control Dashboard からアクセスできます。

- 始める前に *
- このサービスを利用するには、ネットアップサポートアカウントが必要です。
- 管理ノード REST API を使用するための許可が必要です。
- バージョン 12.0 以降を実行する管理ノードを導入しておきます。
- クラスタバージョンで NetApp Element ソフトウェア 12.0 以降が実行されています。
- インターネットにアクセスできる。Active IQ コレクタサービスをダークサイトから使用することはできません。
- このタスクについて * クラスタ全体の統計の履歴ビューを継続的に更新できます。クラスタで指定したイベント、しきい値、または指標について、通知を設定して迅速に対処できるようにすることができます。

ネットアップサポートは、通常のサポート契約の一環として、このデータを監視し、潜在的なシステムの問題をユーザに警告します。

- 手順 *
  1. Web ブラウザを開き、管理ノードの IP アドレスにアクセスします。例：

     ```
     https://[management node IP address]
     ```

  2. NetApp HCI ストレージクラスタ管理者のクレデンシャルを指定して NetApp Hybrid Cloud Control にログインします。
  3. ダッシュボードの右上にあるメニューをクリックします。
  4. 「 * View Active IQ * 」を選択します。

     。 "SolidFire Active IQ ダッシュボード" 表示されます。

  5. SolidFire Active IQ の詳細については、ダッシュボードで右上のメニューアイコンをクリックし、 * Documentation * をクリックしてください。
  6. SolidFire Active IQ インターフェイスで、 NetApp HCI のコンピューティングノードとストレージノードから Active IQ にテレメトリが正しく報告されていることを確認します。
     a. 複数の NetApp HCI がインストールされている場合は、 * クラスタの選択 * をクリックして、リストからクラスタを選択します。
     b. 左側のナビゲーションペインで、 * ノード * をクリックします。
  7. リストに表示されないノードがある場合は、ネットアップサポートにお問い合わせください。

ストレージリソースとコンピューティングリソースの数を表示するには、 Hybrid Cloud Control （ HCC ）ダッシュボードを参照します。を参照してください "HCC ダッシュボードを使用してストレージリソースとコンピューティングリソースを監視する"。

詳細については、こちらをご覧ください

- "NetApp SolidFire Active IQ のドキュメント"
- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.