Ansible によるコンピューティングノードのファームウェアアップグレードの自動化

HCI

amitha, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_hcc_upgrade_compute_firmware_ansible.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

Ansible によるコンピューティングノードのファームウェアアップグレードの自動化 1

Ansible によるコンピューティングノードのファームウェアアップグレードの自動化

NetApp Hybrid Cloud Control のワークフローを使用して、 NetApp HCI コンピューティングノードのシステムファームウェアを更新できます。これには、 BMC 、 BIOS 、 NIC などのコンポーネントのファームウェアも含まれます。大規模なコンピューティングクラスタを含む環境では、 Ansible を使用してクラスタ全体のローリングアップグレードを実行することでワークフローを自動化できます。

コンピューティングノードのファームウェアアップグレードを自動化する Ansible のロールはネットアップによって提供されますが、自動化は補助コンポーネントとして機能し、追加のセットアップやソフトウェアコンポーネントの実行が必要となります。Ansible 自動化の変更はベストエフォートベースでのみサポートされます。

アップグレード用の Ansible のロールは、 NetApp HCI H シリーズのコンピューティングノードでのみ機能します。サードパーティ製コンピューティングノードのアップグレードにはこのロールを使用できません。

必要なもの

- * ファームウェアのアップグレードの準備と前提条件 * ：の手順に従って、 NetApp HCI のインストール環境でファームウェアのアップグレードの準備ができている必要があります "ファームウェアのアップグレードを実行する"。
- * Ansible コントロールノード * で自動化を実行する準備：物理サーバまたは仮想サーバで Ansible でファームウェア更新の自動化を実行します。

本番環境では、 NetApp HCI インストール環境のコンピューティングノードを、 1 つずつローリング方式で更新する必要があります。NetApp Hybrid Cloud Control の API は、健全性チェックの実行、コンピューティングノード上の ESXi のメンテナンス、ファームウェアアップグレードを適用するためのコンピューティングノードのリブートなど、コンピューティングノードのファームウェアアップグレードプロセス全体を 1 つのコンピューティングノードに対してオーケストレーションします。Ansible ロールは、コンピューティングノードのグループまたはクラスタ全体に対してファームウェアアップグレードをオーケストレーションするためのオプションを提供します。

作業を開始するには、に移動します "GitHub 上の NetApp Ansible リポジトリ" および 'NAR_compute_nodes_firmware_upgrades ロールとドキュメントをダウンロードします

詳細については、こちらをご覧ください

- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.