2 ノードクラスタのストレージノードを交換

HCI

amitha, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_hci_2noderepl.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

2 ノードクラスタのストレージノードを交換 1
詳細については、こちらをご覧ください 2

2 ノードクラスタのストレージノードを交換

2 ノードクラスタの一部であるストレージノードを交換する前に、最初に 3 つ目のストレージノード（新しい IP アドレスのセットが必要）を追加し、同期を完了させてから、障害ノードを削除してください。交換用ノードがクラスタに追加されるまで、クラスタはデグレード状態のままです。

必要なもの

- 新しい管理 IP アドレスとストレージ IP アドレスを用意します。
- ノードがオフラインになった後 ' クラスタに ClusterCannotSync' アラートが表示されていることを確認しておきますこれにより、新しいノードがクラスタに再度追加されたときに、クラスタの完全な再同期が実行されます。このアラートは、ストレージノードがオフラインになってから約 6 分後に表示されます。
- ネットアップサポートに問い合わせます。交換用製品を注文する場合は、ネットアップサポートでケースをオープンする必要があります。
- 交換用ノードを入手します。
- 静電放電（ ESD ）リストバンドを装着するか、静電気防止処置を行っておきます。

VMware vSphere Web Client のアラームでは、ホストで障害が発生するとアラートが通知されます。VMware vSphere Web Client で障害が発生したホストのシリアル番号を、ノード背面のステッカーに記載されているシリアル番号と一致させる必要があります。

手順

1. 障害が発生したノードをラックから物理的に取り外します。実行する手順は、使用するストレージノードのタイプによって異なります。を参照してください "H410S ノードを交換します" および "H610S ノードを交換してください"。

   この時点では、クラスタからノードを削除しないでください。

2. 交換用ノードを同じスロットに設置します。
3. ノードをケーブル接続
4. ノードの電源をオンにします。
5. キーボードとモニタをノードに接続
6. 設定手順を実行します。
   a. IPMI / BMC IP アドレスを設定します。
   b. 新しい管理 IP アドレスとストレージ IP アドレス、およびクラスタ名を使用して新しいノードを設定します。
7. ノードをクラスタに追加したら、ドライブを追加します。
8. 同期が完了したら、障害が発生したドライブとノードをクラスタから削除します。
9. NetApp Hybrid Cloud Control を使用して、追加した新しいストレージノードを設定します。を参照してください "NetApp HCI ストレージリソースを展開します"。

詳細については、こちらをご覧ください

- "NetApp HCI ドキュメントセンター"
- "SolidFire と Element ソフトウェアドキュメントセンター"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.