管理ノードにアクセスします

HCI

Dave Bagwell, Aksel Davis, Ann-Marie Grissino
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_access_ui.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

管理ノードにアクセスします 1
管理ノードのノード UI にアクセスします 1
管理ノードの REST API UI にアクセスします 1

管理ノードにアクセスします

NetApp Element ソフトウェアバージョン 11.3 以降、管理ノードには 2 つの UI が装備されています。 REST ベースのサービスを管理するための UI と、ネットワーク / クラスタ設定の管理とオペレーティングシステムのテスト / ユーティリティを実行するためのノード UI です。

Element ソフトウェアバージョン 11.3 以降を実行するクラスタでは、次の 2 つのインターフェイスのいずれかを使用できます。

- 管理ノード UI （「 https ： // [mNode IP 〕 ： 442'] ）を使用して、ネットワークとクラスタの設定を変更したり、システムテストを実行したり、システムユーティリティを使用したりできます。
- 組み込みの REST API UI （「 https://[mNode ip 〕 /mnode 」）を使用して、プロキシサーバの設定、サービスレベルの更新、アセット管理などの管理ノードサービスに関連する API を実行したり、理解したりできます。

管理ノードのノード **UI** にアクセスします

ノード UI からは、ネットワークとクラスタの設定にアクセスし、システムのテストとユーティリティを利用できます。

手順

1. 管理ノードのノード UI にアクセスするには、と入力します 管理ノードの IP アドレスに続けて： 442 を追加します

   ```
   https://[IP address]:442
   ```

   [管理ノードのノード UI] | *mnode_per_node_442_ui.png*

2. プロンプトが表示されたら、管理ノードのユーザ名とパスワードを入力します。

管理ノードの **REST API UI** にアクセスします

REST API UI からは、管理ノード上の管理サービスを制御するサービス関連 API のメニューにアクセスできます。

手順

1. 管理サービスの REST API UI にアクセスするには、管理ノードの IP アドレスに「 /mnode 」を続けて入力します。

   ```
   https://[IP address]/mnode
   ```

   [管理ノードの REST API UI] | *mnode_swagger_ui.png*

2. Authorize * または任意のロックアイコンをクリックし、 API を使用する権限を付与するクラスタ管理者ク

レデンシャルを入力します。

詳細はこちら

- "SolidFire オールフラッシュストレージに対して Active IQ コレクタサービスを有効にします"
- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.