# リモートのネットアップサポートセッションを開始します

## HCI

Dave Bagwell, Aksel Davis, Ann-Marie Grissino
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_enable_remote_support_connections.html on July 01, 2021. Always check docs.netapp.com for the latest.

# 目次

リモートのネットアップサポートセッションを開始します . . . . . 1

# リモートのネットアップサポートセッションを開始します

NetApp HCI または SolidFire オールフラッシュストレージシステムに関するテクニカルサポートが必要な場合は、ネットアップサポートがお客様のシステムにリモートで接続できます。セッションを開始してリモートアクセスを確立するために、ネットアップサポートはお客様の環境へのリバース Secure Shell （ SSH ）接続を確立します。

ネットアップサポートとの SSH リバーストンネル接続用の TCP ポートを開くことができます。この接続を介して、ネットアップサポートはお客様の管理ノードにログインします。

作業を開始する前に

- 管理サービス 2.18 以降では、管理ノードでリモートアクセス機能がデフォルトで無効になっています。リモートアクセス機能を有効にするには、を参照してください "管理ノードで SSH 機能を管理します"。
- 管理ノードがプロキシサーバの背後にある場合は、次の TCP ポートを sshd.config ファイルで設定しておく必要があります。

| **TCP** ポート | 説明 | 接続方向 |
|---|---|---|
| 443 | オープンサポートトンネルを介したリバースポート転送用の API 呼び出し / HTTPS をクリックします | 管理ノードからストレージノードへ |
| 22 | SSH ログインアクセス | 管理ノードからストレージノードへ、またはストレージノードからに 管理ノード |

手順

- 管理ノードにログインし、ターミナルセッションを開きます。
- プロンプトで、次のように入力します。

  rst -r sfsupport.solidfire.com -u element -p <port_number>`

- リモートサポートトンネルを閉じるには、次のように入力します。

  rst — killall

- （任意）ディセーブルにします "リモートアクセス機能" をもう一度クリックします

> SSH を無効にしないと、有効なままになります。SSH を有効にした設定は、手動で無効にするまで、更新やアップグレードを通じて管理ノードで維持されます。

# 詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

**Copyright Information**

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

**Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.