# ストレージネットワークインターフェイスコントローラ（ NIC ）の設定

## HCI

Dave Bagwell, Aksel Davis, Ann-Marie Grissino
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_install_add_storage_NIC.html on July 01, 2021. Always check docs.netapp.com for the latest.

# 目次

ストレージネットワークインターフェイスコントローラ（ NIC ）の設定 . . . . . 1
タグなしのストレージネットワークインターフェイスコントローラ（ NIC ）を設定します
ネットワークインターフェイス . . . . . 1
タグ付きのストレージネットワークインターフェイスコントローラ（ NIC ）を設定します
ネットワークインターフェイス . . . . . 2

# ストレージネットワークインターフェイスコントローラ（ NIC ）の設定

ストレージに追加の NIC を使用している場合は、 SSH で管理ノードに接続するか、vCenter コンソールを使用して curl コマンドを実行し、タグ付きまたはタグなしのネットワークインターフェイスをセットアップできます。

作業を開始する前に

- eth0 の IP アドレスを確認しておきます。
- クラスタで NetApp Element ソフトウェア 11.3 以降を実行している必要があります。
- 管理ノード 11.3 以降を導入しておきます。

環境に適したオプションを選択します。

- [Configure a storage Network Interface Controller (NIC) for an untagged network interface]
- [Configure a storage Network Interface Controller (NIC) for a tagged network interface]

## タグなしのストレージネットワークインターフェイスコントローラ（ NIC ）を設定します ネットワークインターフェイス

手順

1. SSH または vCenter コンソールを開きます。
2. 次のコマンドテンプレートの値を置き換え、コマンドを実行します。

新しいストレージ・ネットワーク・インターフェイスに必要なパラメータごとに値は「 $ 」で表されます。次のテンプレート内の 'cluster' オブジェクトは必須であり ' 管理ノードのホスト名の変更に使用できます`-- 非セキュアなオプションや '-k オプションは ' 本番環境では使用しないでください

```
curl -u $mnode_user_name:$mnode_password --insecure -X POST \
https://$mnode_IP:442/json-rpc/10.0 \
-H 'Content-Type: application/json' \
-H 'cache-control: no-cache' \
-d ' {
     "params": {
               "network": {
                          "$eth1": {
                                   "#default" : false,
                                   "address" : "$storage_IP",
                                   "auto" : true,
                                   "family" : "inet",
                                   "method" : "static",
                                   "mtu" : "9000",
                                   "netmask" : "$subnet_mask",
                                   "status" : "Up"
                                   }
                          },
               "cluster": {
                          "name": "$mnode_host_name"
                          }
             },
    "method": "SetConfig"
}
'
```

# タグ付きのストレージネットワークインターフェイスコントローラ（ NIC ）を設定します ネットワークインターフェイス

手順

1. SSH または vCenter コンソールを開きます。
2. 次のコマンドテンプレートの値を置き換え、コマンドを実行します。

> 新しいストレージ・ネットワーク・インターフェイスに必要なパラメータごとに値は「 $ 」で表されます。次のテンプレート内の 'cluster' オブジェクトは必須であり ' 管理ノードのホスト名の変更に使用できます`-- 非セキュアなオプションや '-k オプションは ' 本番環境では使用しないでください

```
curl -u $mnode_user_name:$mnode_password --insecure -X POST \
https://$mnode_IP:442/json-rpc/10.0 \
-H 'Content-Type: application/json' \
-H 'cache-control: no-cache' \
-d ' {
     "params": {
               "network": {
                          "$eth1": {
                                   "#default" : false,
                                   "address" : "$storage_IP",
                                   "auto" : true,
                                   "family" : "inet",
                                   "method" : "static",
                                   "mtu" : "9000",
                                   "netmask" : "$subnet_mask",
                                   "status" : "Up",
                                   "virtualNetworkTag" : "$vlan_id"
                                   }
                          },
               "cluster": {
                         "name": "$mnode_host_name",
                         "cipi": "$eth1.$vlan_id",
                         "sipi": "$eth1.$vlan_id"
                         }
             },
    "method": "SetConfig"
}
'
```

# 詳細はこちら

- "管理ノードにアセットを追加します"
- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

**Copyright Information**

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

**Trademark Information**

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.