NetApp Hybrid Cloud Control を複数の vCenter に設定する

HCI

Dave Bagwell, Aksel Davis, Ann-Marie Grissino, Michael Wallis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_multi_vcenter_config.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

NetApp Hybrid Cloud Control を複数の vCenter に設定する 1

NetApp Hybrid Cloud Control を複数の vCenter に設定する

リンクモードを使用していない　2　つ以上の　vCenter　からアセットを管理するように NetApp Hybrid Cloud Control を設定できます。

この手順は、最初のインストール後に、最近拡張した環境のアセットを追加する必要がある場合や、新しいアセットが構成に自動的に追加されない場合に使用してください。これらの　API　を使用して、最近追加されたアセットを環境に追加します。

必要なもの

- クラスタで NetApp Element ソフトウェア 11.3 以降を実行している必要があります。
- バージョン 11.3 以降を実行する管理ノードを導入しておきます。

手順

1. "新しい vCenter をコントローラアセットとして追加する" を管理ノードの設定に追加します。
2. "コンピューティングアセットとして新しいコンピューティングノードを追加します"　を管理ノードの設定に追加します。

> 必要に応じて "コンピューティングノードの BMC クレデンシャルを変更します" NetApp Hybrid Cloud Control に表示されている「 Hardware ID not available 」または「 Unable to detect 」エラーを解決するため。

3. 管理ノードでインベントリサービス API をリフレッシュします。

```
https://[management node IP]/inventory/1/
```

> また、 NetApp Hybrid Cloud Control の UI でインベントリが更新されるまで 2 分待つこともできます。

   a. 「 * Authorize * 」（認証）をクリックして、次の手順を実行
      i. クラスタのユーザ名とパスワードを入力します。
      ii. クライアント ID を「 m node-client 」として入力します。
      iii. セッションを開始するには、 * Authorize * をクリックします。
      iv. ウィンドウを閉じます。
   b. REST API UI で、 * 一部のユーザに適用 / インストール * をクリックします。
   c. [* 試してみてください *] をクリックします。
   d. [* Execute] をクリックします。
   e. 応答から、インストールアセット ID （「 id 」）をコピーします。
   f. REST API UI で、 * GET / Installations / ｛ id ｝ * をクリックします。
   g. [* 試してみてください *] をクリックします。

h. 更新を「 True 」に設定します。

i. インストールアセット ID を **id** フィールドに貼り付けます。

j. [* Execute] をクリックします。

4. NetApp Hybrid Cloud Control のブラウザをリフレッシュして変更を確認します。

詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.