管理ノードからアセットを削除します

HCI

Aksel Davis, Dave Bagwell, Michael Wallis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_remove_assets.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

管理ノードからアセットを削除します 1

管理ノードからアセットを削除します

コンピューティングノードを物理的に交換した場合や NetApp HCI クラスタから削除する必要がある場合は、管理ノード API を使用してコンピューティングノードのアセットを削除する必要があります。

必要なもの

- ストレージクラスタで NetApp Element ソフトウェア 11.3 以降が実行されている必要があります。
- バージョン 11.3 以降を実行する管理ノードを導入しておきます。

手順

1. 管理ノードの IP アドレスの後に「 /mnode/1/' 」を入力します。

```
https://<managementNodeIP>/mnode/1/
```

2. Authorize * または任意のロックアイコンをクリックし、 API を使用する権限を付与するクラスタ管理者クレデンシャルを入力します。
   a. クラスタのユーザ名とパスワードを入力します。
   b. 値が選択されていない場合は、タイプドロップダウンリストから * リクエスト本文 * を選択します。
   c. 値がまだ入力されていない場合は、クライアント ID を「 m node-client 」として入力します。
   d. クライアントシークレットの値は入力しないでください。
   e. セッションを開始するには、 * Authorize * をクリックします。
   f. ウィンドウを閉じます。
3. [**Available Authorizations (** 使用可能な承認 **)**] ダイアログボックスを閉じます。
4. [GET/assets] をクリックします。
5. [* 試してみてください *] をクリックします。
6. [* Execute] をクリックします。
7. 応答本文を下にスクロールして「 * Compute * 」セクションに移動し、失敗した計算ノードの「 parent 」と「 id 」の値をコピーします。
8. 削除 / アセット / ｛ asset_id ｝ / コンピュートノード / ｛ compute_id ｝ * をクリックします。
9. [* 試してみてください *] をクリックします。
10. 前の手順でコピーした「 parent 」と「 id 」の値を入力します。
11. [* Execute] をクリックします。

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.