管理ノードからシステムユーティリティを実行します

HCI

Dave Bagwell, Aksel Davis, Ann-Marie Grissino
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_run_system_utilities.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

管理ノードからシステムユーティリティを実行します 1

管理ノードからシステムユーティリティを実行します

管理ノードのノード UI を使用して、クラスタサポートバンドルの作成または削除、ノード設定のリセット、ネットワークの再起動を実行できます。

手順

1. 管理ノードの管理クレデンシャルを使用して、ノード管理ノード UI を開きます。
2. [システムユーティリティ] をクリックします。
3. 実行するユーティリティのボタンをクリックします。
   a. * Control Power * ：ノードをリブート、電源再投入、またはシャットダウンします。次のいずれかのオプションを指定します。

      この処理を実行すると、ネットワーク接続が一時的に失われます。

      - * アクション *: オプションには「再起動」と「停止」(電源オフ) が含まれます。
      - * Wakeup Delay * ：ノードがオンラインに戻るまでの時間。
   b. * クラスタサポートバンドルの作成 * ：クラスタ内のノードについてネットアップサポートの診断を受けるためのクラスタサポートバンドルを作成します。次のオプションを指定します。
      - * Bundle Name * ：作成された各サポートバンドルの一意の名前。名前を指定しない場合、「 supportbundle 」とノード名がファイル名として使用されます。
      - * Mvip * ：クラスタの MVIP 。バンドルは、クラスタ内のすべてのノードから収集されます。このパラメータは、 Nodes パラメータを指定しない場合のみ必要です。
      - * Nodes * ：バンドルを収集するノードの IP アドレス。バンドルの収集元のノードを指定するには、 Nodes または Mvip のいずれかを使用します。両方を使用することはできません。このパラメータは、 Mvip を指定しない場合は必須です。
      - * Username * ：クラスタ管理者ユーザ名。
      - * Password * ：クラスタ管理者のパスワード。
      - * Allow Incomplete * ： 1 つ以上のノードからバンドルを収集できない場合でもスクリプトが引き続き実行されます。
      - * Extra Args * ：このパラメータは 's_make _support_bundle' スクリプトに渡されますこのパラメータは、ネットアップサポートから指示された場合にのみ使用します。
   c. * Delete All Support Bundles * ：管理ノードに保存されているすべてのサポートバンドルを削除します。
   d. * ノードのリセット * ：管理ノードを新しいインストールイメージにリセットします。これにより、ネットワーク設定を除くすべての設定がデフォルトの状態に変更されます。次のオプションを指定します。
      - * Build * ：ノードをリセットするリモート Element ソフトウェアイメージの URL 。
      - * オプション * ：リセット操作を実行するための仕様。詳細が必要な場合は、ネットアップサポートにお問い合わせください。

この処理を実行すると、ネットワーク接続が一時的に失われます。

e. * ネットワークの再起動 * ：管理ノード上のすべてのネットワークサービスを再起動します。

この処理を実行すると、ネットワーク接続が一時的に失われます。

詳細はこちら

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.