管理ノードの概要

HCI

Dave Bagwell, Michael Wallis, Aksel Davis, Ann-Marie Grissino
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_mnode_work_overview.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

管理ノードの概要 1

管理ノードの概要

管理ノード（ mNode ）は、システムサービスの使用、クラスタのアセットと設定の管理、システムのテストとユーティリティの実行、システム監視用の Active IQ の設定、トラブルシューティング用のネットアップサポートアクセスの有効化に使用できます。

> ベストプラクティスとして、 1 つの管理ノードを 1 つの VMware vCenter インスタンスに関連付けるだけで、同じストレージリソースおよびコンピューティングリソースまたは vCenter インスタンスを複数の管理ノードに定義することは避けてください。

Element ソフトウェアバージョン 11.3 以降を実行するクラスタでは、次のいずれかのインターフェイスを使用して管理ノードを操作できます。

- 管理ノード UI (`https://[mNode ip:442') を使用すると ' ネットワークとクラスタの設定を変更したり ' システムテストを実行したり ' システムユーティリティを使用したりできます
- 組み込みの REST API UI （「 https://[mNode ip ｝ /mnode 」）を使用すると、プロキシサーバの設定、サービスレベルの更新、アセット管理など、管理ノードサービスに関連する API を実行したり、理解したりできます。

管理ノードをインストールまたはリカバリします。

- "管理ノードをインストール"
- "ストレージネットワークインターフェイスコントローラ（ NIC ）の設定"
- "管理ノードをリカバリ"

管理ノードにアクセスします。

- "管理ノード（ UI または REST API ）へのアクセス"

管理ノード UI を使用してタスクを実行します。

- "管理ノード UI の概要"

管理ノード REST API を使用してタスクを実行します。

- "管理ノードの REST API UI の概要"

リモート SSH 機能を無効または有効にするか、ネットアップサポートとのリモートサポートトンネルセッションを開始して、トラブルシューティングに役立ててください。

- "ネットアップサポートによるリモート接続を有効にする"
- "管理ノードで SSH 機能を管理します"

詳細については、こちらをご覧ください

- "vCenter Server 向け NetApp Element プラグイン"
- "NetApp HCI のリソースページ"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system- without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.