NetApp Deployment Engine にアクセスするには、 IP アドレスを手動で割り当ててください

HCI

Michael Wallis, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_access_manual_ip.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

NetApp Deployment Engine にアクセスするには、 IP アドレスを手動で割り当ててください 1

NetApp Deployment Engine にアクセスするには、IP アドレスを手動で割り当ててください

すべての NetApp HCI ノードの Bond1G インターフェイスと Bond10G インターフェイスに静的 IPv4 アドレスを手動で割り当て、 NetApp Deployment Engine にアクセスして NetApp HCI を導入することができます。ネットワークに特別な要件がないかぎり、この方法は使用しないでください。

必要なもの

- 自分またはネットワーク管理者が、『セットアップガイド』ドキュメントのタスクを完了している。
- NetApp HCI ノードに物理的にアクセスできるようにしておきます。
- すべての NetApp HCI ノードの電源をオンにしておきます。
- NetApp HCI ネットワークで DHCP が有効になっておらず、 NetApp HCI ノードが DHCP サーバから IP アドレスを取得していません。注： NetApp Deployment Engine を使用してシステムを導入する前に手動で割り当てる IP アドレスはすべて一時的な IP アドレスであり、再利用することはできません。IP アドレスを手動で割り当てる場合は、最終的な導入時に割り当て可能な、未使用かつ永続的な IP アドレスのセットをもう 1 つ確保しておく必要があります。

この構成では、導入時にコンピューティングノードとストレージノードが静的 IPv4 アドレスを使用して他のノードを検出して通信を確立します。この構成は推奨されません。

手順

1. いずれかの NetApp HCI ストレージノードの背面に KVM を接続します（このノードが制御用ストレージノードになります）。
2. ユーザインターフェイスで Bond1G および Bond10G の IP アドレス、サブネットマスク、ゲートウェイアドレスを設定します。必要に応じて、各ネットワークの VLAN ID を設定することもできます。
3. 残りのストレージノードとコンピューティングノードについて手順 2 を繰り返します。
4. NetApp HCI 管理ネットワークにアクセスできるコンピュータで Web ブラウザを開きます。
5. 制御用ストレージノードに割り当てた Bond1G の IP アドレスにアクセスします。例：

   ```
   http://<Bond1G IP address>
   ```

   NetApp Deployment Engine のユーザインターフェイスが表示されます。

詳細については、こちらをご覧ください

- "NetApp HCI および NetApp Element のファームウェアとドライバのバージョン ソフトウェア"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.