DHCP を使用していない環境では、 NetApp Deployment Engine にアクセスします

HCI

Michael Wallis, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_access_no_dhcp.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

DHCP を使用していない環境では、 NetApp Deployment Engine にアクセスします 1

DHCP を使用していない環境では、 NetApp Deployment Engine にアクセスします

ネットワークで DHCP を使用していない場合は、 NetApp Deployment Engine へのアクセスに使用するストレージノード（制御用ストレージノード）の Bond1G インターフェイスに静的 IPv4 アドレスを設定する必要があります。制御用ストレージノードの NetApp Deployment Engine は、他のコンピューティングノードとストレージノードの Bond10G インターフェイスに自動で設定された IPv4 アドレスを使用し、これらのノードを検出して通信を確立します。ネットワークに特別な要件がないかぎり、この方法を使用してください。

必要なもの

- 自分またはネットワーク管理者が、『セットアップガイド』ドキュメントのタスクを完了している。
- NetApp HCI ノードに物理的にアクセスできるようにしておきます。
- すべての NetApp HCI ノードの電源をオンにしておきます。
- NetApp HCI ネットワークで DHCP が有効になっておらず、 NetApp HCI ノードが DHCP サーバから IP アドレスを取得していません。
- すべてのノードの Bond1G インターフェイスと Bond10G インターフェイスについて、 NetApp HCI 管理ネットワークをネイティブ VLAN として構成しておきます。

手順

1. いずれかの NetApp HCI ストレージノードの背面に KVM を接続します（このノードが制御用ストレージノードになります）。
2. ユーザインターフェイスで Bond1G の IP アドレス、サブネットマスク、ゲートウェイアドレスを設定します。必要に応じて、 Bond1G ネットワークの VLAN ID を設定することもできます。

   この IPv4 アドレスは、 NetApp Deployment Engine を使用した以降の導入時に再利用することはできません。

3. NetApp HCI 管理ネットワークにアクセスできるコンピュータで Web ブラウザを開きます。
4. 制御用ストレージノードに割り当てた IP アドレスにアクセスします。例：

   ```
   http://<Bond1G IP address>
   ```

   NetApp Deployment Engine のユーザインターフェイスが表示されます。

詳細については、こちらをご覧ください

- "NetApp HCI および NetApp Element のファームウェアとドライバのバージョン ソフトウェア"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.