NetApp HCI システムのストレージリソースの電源をオフにします

HCI

Michael Wallis, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_hci_power_off_storage.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

NetApp HCI システムのストレージリソースの電源をオフにします 1

NetApp HCI システムのストレージリソースの電源をオフにします

NetApp HCI のストレージリソースの電源をオフにする場合は、「 Element API メソッド」を使用してストレージノードを適切に停止する必要があります。

コンピューティングリソースの電源をオフにしたら、 Web ブラウザを使用して、 NetApp HCI ストレージクラスタのすべてのノードをシャットダウンします。

1. ストレージクラスタにログインし、正しい MVIP に接続していることを確認します。
2. iSCSI セッション数が 0 であることを確認します。
3. クラスタ > ノード > アクティブ * と進み、クラスタ内のすべてのアクティブノードのノード ID を記録します。
4. NetApp HCI ストレージクラスタの電源をオフにするには、 Web ブラウザを開き、次の URL を使用して電源オフおよび停止の手順を実行します。 '{MVIP}' は NetApp HCI ストレージ・システムの管理 IP アドレスで 'nodes=[]' アレイには ' 手順 2 で記録したノード ID が含まれています例：

   ```
   https://{MVIP}/json-rpc/1.0?method=Shutdown&nodes=[1,2,3,4]&option=halt
   ```

5. クラスタ管理者のユーザ名とパスワードを入力します。
6. すべてのストレージクラスタノードが API 結果の「必要」セクションに含まれていることを確認して、API 呼び出しが正常に返されたことを検証します。

   すべての NetApp HCI ストレージノードの電源がオフになりました。

詳細については、こちらをご覧ください

- "NetApp HCI および NetApp Element のファームウェアとドライバのバージョン ソフトウェア"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.