ネットワークトポロジを選択してください

HCI

Michael Wallis, Aksel Davis
June 21, 2021

This PDF was generated from https://docs.netapp.com/ja-jp/hci/docs/task_nde_select_net_topology.html on July 01, 2021. Always check docs.netapp.com for the latest.

目次

ネットワークトポロジを選択してください 1

ネットワークトポロジを選択してください

NetApp HCI ノードのケーブル接続には、ニーズに応じて異なるネットワークケーブル構成を使用できます。コンピューティングノードについては、 6 つのすべてのネットワークポートを使用して各ポートペアに異なるタイプのトラフィックを割り当てることも、 2 つのポートを使用してすべてのタイプのトラフィックをポートに割り当てることもできます。ストレージノードでは標準的なケーブル 4 本の構成を使用します。選択すると、インベントリでどのコンピューティングノードを選択できるかに影響します。

コンピューティングノードにケーブル 2 本のネットワークトポロジを使用する場合は、次の要件を考慮してください。

- 導入完了後に適用する VMware vSphere Enterprise Plus ライセンスが必要です。
- ネットワークとネットワークスイッチの構成が正しいことを確認しておきます。
- すべてのコンピューティングノードおよびストレージノードのストレージネットワークと vMotion ネットワークに VLAN タギングが必要です。

手順

1. Network Topology * ページで、 NetApp HCI 用のコンピューティングノードのインストール方法に適したコンピューティングノードトポロジを選択します。
    - *6 ケーブルオプション *: 6 ケーブルオプションでは、トラフィックの種類 (管理、仮想マシン、ストレージ) ごとに専用ポートを提供します。必要に応じて、 vSphere Distributed Switch （ VDS ）を有効にすることができます。VDS を有効にすると、分散スイッチが構成され、 NetApp HCI の導入完了後に仮想マシンのネットワーク構成を簡単かつ一元的に管理できるようになります。有効にした場合は、導入後に適用する vSphere Enterprise Plus ライセンスが必要です。
    - * 2 Cable Option * ：管理、仮想マシン、およびストレージのトラフィックを 2 つのボンディングポートに統合します。このケーブル接続オプションでは VDS は必須で、自動的に有効になります。導入後に適用する vSphere Enterprise Plus ライセンスが必要です。
2. 一部のケーブル配線オプションでは、ノードハードウェアのタイプ別に複数の背面パネル図が表示されます。背面パネル図を順に参照して、該当するノードモデルのネットワークケーブルとケーブル配線オプションを確認してください。
3. 完了したら、 [* Continue （続行）] をクリックします。

詳細については、こちらをご覧ください

- "NetApp HCI および NetApp Element のファームウェアとドライバのバージョン ソフトウェア"

Copyright Information

Copyright © 2021 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means-graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system-without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP “AS IS” AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NETAPP, the NETAPP logo, and the marks listed at http://www.netapp.com/TM are trademarks of NetApp, Inc. Other company and product names may be trademarks of their respective owners.